

GSK 218M CNC System

Connection and PLC Manual



广州数控设备有限公司
GSK CNC EQUIPMENT CO., LTD.

 The user manual describes all items concerning the operation of this CNC system in detail as much as possible. However, it's impractical to give particular descriptions for all unnecessary and/or unavailable operations on the motor due to the limit of the manual, specific operations of the product and other causes. Therefore, the operations not specified in this manual may be considered impossible or unallowable.

 This manual is the property of GSK CNC Equipment Co., Ltd. All rights reserved. It is against the law for any organization or individual to publish or reprint this manual without the express written permission of GSK CNC Equipment Co., Ltd. and the latter reserves the right to ascertain their legal liability.

Company profile

GSK—GSK CNC Equipment Co., Ltd is the largest production and marketing enterprise of the CNC system in China currently. It is the Numerical Control industrial base of South China, and the undertaking enterprise of the 863 national main project Industrialization Support Technology for Medium Numerical Control System as well as one of the 20 basic equipment manufacture enterprises in Guangdong province. It has been taking up the research and development, design and the manufacture of machine CNC system (CNC device, drive unit and servo motor) in recent 10 years. Now it has developed into a large high-tech enterprise integrated with research, education, industry and trade by enhancing the popularization and trade of CNC machine tools. There are more than 1400 staffs in this company that involves 4 doctors, more than 50 graduate students and 500 engineers and more than 50 among them are qualified with senior technical post titles. The high performance-cost ratio products of GSK are popularized in China and Southeast Asia. And the market occupation of GSK's product dominates first and the turnout and sale ranks the top in internal industry for successive 7 years from the year 2000 to 2006, which makes it the largest CNC manufacture base throughout China.

The main products provided by our company includes the NC equipments and devices such as GSK series turning machine, milling machine, machining center CNC system, DA98, DA98A, DA98B, DA98D series full digital stepper motor drive device, DY3 series compound stepper driver device, DF3 series response stepper motor driver device, GSK SJT series AC servo motors, CT-L NC slider and so on. The current national standard (and international standard), industry standard, as well as the enterprise standard (or enterprise internal standard) as a supplementary, are completely implemented in our production process. The capability of abundant technology development and complete production and quality system qualified by us will undoubtedly ensure the reliable product to serve our customers. 24~48 hours technological support and service can be easily and promptly provided by our complete service mechanism and tens of service offices distributed in provinces around China and abroad. The pursuit of “excellent product and superexcellent service” has made the GSK what it is now, and we will spare no efforts to continue to consummate this South China NC industry base and enhance our national NC industry by our managerial concept of “century enterprise, golden brand”.

Technological Spot Service

You can ask for spot service if you have the problems that can't be solved by telephone. We will send the engineers authorized to your place to resolve the technological problems for you.

Foreword

Dear user,

It's our pleasure for your patronage and purchase of this GSK GSK218M CNC system made by GSK CNC Equipment Co., Ltd.
The manual is "Connection and PLC Manual".



Accident may occur by improper connection and operation! This system can only be operated by authorized and qualified personnel. Please carefully read this manual before usage!

This manual is reserved by final user.

All specifications and designs herein are subject to change without further notice.
We are full of heartfelt gratitude to you for supporting us in the use of GSK's products.

Warning and precautions

Warning, notice and explanation

This manual contains the precautions to protect user and machine. The precautions are classified as warning and notice by safety, and supplementary information is regarded as explanation. Read the warnings, notes and explanations carefully before operation.

Warning

User may be hurt or equipment can be damaged if operations and steps are not observed.

Notice

Equipment may be damaged if operation instructions or steps are not observed by user.

Explanation

It is used for the supplementary information except for warning and notice.

- Copy right is reserved.

Contents

I	PROGRAMMING	1
1	Sequence Program Creating Process	2
1.1	GSK218M PLC specification	2
1.2	What is a sequence program	2
1.3	Establishment of interface specifications (step 1)	2
1.4	Establishment of ladder diagram (step 2)	2
1.5	Sequence program check (step 3)	3
2	Sequence Program	4
2.1	Execution process of sequence program	4
2.2	Repetitive cycle	5
2.3	Priority of execution(1 st level, and 2 nd level)	5
2.4	Sequence program structure	6
2.5	Processing I/O (input/output) signals	7
2.5.1	Input signal processing	8
2.5.2	Output signal processing	8
2.5.3	Synchronous processing short pulse signal	8
2.5.4	Difference state of signals between 1 st level and 2 nd level	9
2.6	Interlocking	10
3	Address	11
3.1	Addresses from Machine tool to PLC (X)	11
3.1.1	Assignment of IO module X address	11
3.1.2	Assignment of MDI panel X address	11
3.2	Address (Y) from PLC to machine tool	13
3.2.1	Assignment of IO module Y address	13
3.2.2	Assignment of IO module Y address	13
3.3	Address (G) from PLC to CNC	15
3.4	Address (F) from CNC to PLC	16
3.5	Internal relay address (R)	16
3.6	Address of keep relay (K)	17
3.7	Addresses(A) for message selection displayed on CRT	17
3.8	Address of meter (C)	18
3.9	Meter preset address(DC)	18
3.10	Timer addresses (T)	18
3.11	Addresses of timer preset value (DT)	18
3.12	Address of data table (D)	18
3.13	Label address (L)	19
3.14	Subprogram numbers (P)	19
4	PLC Basic Instruction	20
4.1	RD, RD.NOT, WRT, WRT.NOT	20
4.2	AND, AND.NOT instructions	21
4.3	OR, OR.NOT instructions	21
4.4	OR. STK instruction	22
4.5	AND.STK instruction	22
5	PLC Functional Instructions	24
5.1	END1 (1 st level sequence program end)	25
5.2	END2 (2 nd level sequence program end)	25
5.3	CALL (call subprogram)	25
5.4	SP (Subprogram)	26
5.5	SPE (subprogram end)	26
5.6	SET (set)	27

5.7	RST (reset)	27
5.8	JMPB (label jump)	27
5.9	LBL (Label)	28
5.10	TMR (timer)	29
5.11	CTR (binary counter)	29
5.12	DEC (binary decode)	30
5.13	COD (binary code conversion)	31
5.14	COM (common line control)	33
5.15	COME (common line control end)	33
5.16	ROT (Binary rotation control)	34
5.17	SFT (shift register)	36
5.18	DIFU (rising edge check)	37
5.19	DIFD (falling edge check)	37
5.20	COMP (binary comparison)	38
5.21	COIN (coincidence check)	39
5.22	MOVN (transfer of data)	39
5.23	XMOV (Binary index data transfer)	40
5.24	DSCH (binary data search)	42
5.25	ADD (addition)	43
5.26	SUB (binary subtraction)	44
5.27	ANDF (functional and)	45
5.28	ORF (functional or)	46
5.29	NOT (logical not)	47
5.30	EOR (exclusive or)	48
6	Ladder Writing Limit	49
II	FUNCTION	50
1	Controlled Axis	51
1.1	Outputting of movement state of an axis	51
1.2	Servo ready signal	52
2	Preparation for Operation	53
2.1	Emergency stop	53
2.2	CNC overtravel signal	53
2.3	Alarm signal	54
2.4	Mode selection	55
2.5	Status output signal	55
3	Manual Operation	56
3.1	JOG feed/incremental feed	56
3.2	MPG/Step feed	57
4	Reference Point Return	58
4.1	Manual reference point return	58
4.2	Reference point return check signal	59
4.3	Area check signal	60
5	Automatic Operation	63
5.1	Cycle start/feed hold	63
5.2	Reset	66
5.3	Testing a program	66
5.3.1	Machine tool lock	66
5.3.2	Dry run	67
5.3.3	Single block	68
5.4	Optional block skip	68
5.5	Program restart	69

6 Feedrate Control	71
6.1 Rapid traverse rate	71
6.2 Feedrate override.....	71
6.3 Override cancel	72
7 Auxiliary Function	73
7.1 Miscellaneous function (M code)	73
7.4 Auxiliary function lock.....	77
8 Spindle Speed Function	79
8.1 Spindle speed control mode	79
8.1.1 Gear spindle.....	79
8.1.2 Analog spindle	79
8.2 Rigid tapping	81
9 Programmng Instructon	82
9.1 Custom macro program	82
9.2 Canned cycle	84
10 Display/Set	86
10.1 Clock Function.....	86
10.2 Displaying operation history	86
10.3 Help function.....	86
11 Measurement	87
11.1 Skip function	87
12 Panel locked setting	88
Appendix	89
Signal list (During order of address)	89
III OPERATION	93
1 PLC Window Display	94
1.1 Automatic operation when GSK218M PLC power on.....	94
1.2 INFO window display	94
1.2.1 INFO window	94
1.2.2 PLCGRA window.....	96
1.2.3 PLCPAR window	96
1.2.4 PLCGND window	97
1.2.5 PLCTRA window	98
2 PLC Programming Operation	100
2.1 General	100
2.2 Basic instruction(B. INST).....	101
2.3 Operations of ladder	102
2.4 Function instruction.....	104
2.5 Instruction list.....	104
2.6 Edit instruction	106
2.7 PLC operation step	106
3 PLC Address, Parameter Setting	108
3.1 Counter	108
3.2 Timer	109
3.3 Data list.....	110
3.4 Keep relay	111
3.5 F address corresponded to M function	111
4 PLC address check operation	113

5 Ladder edit software use	114
5.1 Summary.....	114
5.2 Software introduction.....	114
5.2.1 Starting software	114
5.2.2 Function introduction.....	114
5.3 Software operation.....	115
5.3.1 Tool bar	115
5.3.2 Selecting a graph	116
5.3.3 Editing a graph.....	117
5.3.4 Ladder comment.....	118
IV CONNECTION	121
1 System Structure and Installation	122
1.1 System composition	122
1.2 System installation & connection.....	122
1.3 CNC system installation dimension.....	123
2 Device Connection	127
2.1 CNC external connection.....	127
2.2 Connection between system and driver	127
2.2.1 System interface	127
2.2.2 Interface signal list	128
2.2.3 Signal specification	128
2.2.4 Cable connection	130
2.3 RS232 standard serial interface.....	131
2.4 MPG (handwheel), hand unit connection	132
2.4.1 Interface signal list	132
2.4.2 Interface signal.....	132
2.5 Spindle unit connection	134
2.5.1 Interface signal list	134
2.5.2 Interface signal.....	134
2.6 Power supply interface.....	134
3 Machine Control I/O Interface	135
3.1 Interface signal list.....	135
3.2 Input interface.....	135
3.2.1 Input interface method	135
3.2.2 Input signal interface definition.....	136
3.3 Output signal.....	138
3.3.1 Output interface method.....	138
3.3.2 Output signal interface definition	138
4 Debugging Machine	140
4.1 Debug preparation	140
4.2 System power on	140
4.3 Emergency stop and limit	141
4.4 Gear ratio adjustment.....	142
4.5 Backlash compensation	142
4.6 Parameter of servo	143
4.7 Machine pitch compensation.....	144
4.8 Machine zero return.....	146
4.9 Input/output signal control of spindle CW/CCW	147
4.10 Spindle automatic gear change control	148
4.11 External cycle start and feed hold	149
4.12 Cooling, lubricant and chip removal control.....	150
4.13 Parameters of axis control.....	151
4.14 Parameter of coordinate system.....	152
4.15 Parameter of feedrate	152
4.16 Parameters of MDI, display and edit.....	154

4.17 Parameters of tool compensation..... 156

Appendix: 158

 Guide for GSK218M matching with ladder 158

 1. Notices of GSK218M matching with turret tool magazine..... 158

 2. Allocation and definition of PLC IO address, auxiliary relay and register 158

 3. Usage and maintenance of GSK 218M CNC System matching with turret tool magazine ... 177

 4. Macro program statement of GSK218M CNC System matching with turret tool magazine .. 180

I Programming

1 Sequence Program Creating Process

1.1 GSK218M PLC specification

Specifications of GSK218M PLC are as follows:

Specification	GSK218M PLC
Programming method language	Ladder
Number of ladder level	2
1 st level execution period	8ms
Mean processing time of basic instruction	10μs
Program capacity	4700 step
Instruction	Basic instruction +function instruction
Internal relay (R)	0~511 byte
PLC message request (A)	0~31 byte
Keep memory	
* Timer (T)	0~127 byte
* Meter (C)	0~127 byte
* Data table (D)	0~255 byte
* Keep relay (K)	0~63 byte
* Meter preset value data register (DC)	0~127 byte
* Timer preset value data register (DT)	0~99
Subprogram (P)	0~99
Label (L)	
I/O module (X)	0~63 byte
(Y)	0~47 byte

1.2 What is a sequence program

A sequence program is a program for sequence control of machine tools and other systems. The program is converted into a format to enable CPU execute encoding and arithmetic processing, and stored into RAM. CPU reads out instructions of the program stored into the memory at the high-speed every instruction and execute the program by arithmetic operation. The sequence program is written firstly from ladder.

1.3 Establishment of interface specifications (step 1)

After deciding the control object specification, calculate the number of input/output signal points, create the interface specification.

For input/output interface signals, see **Chapter 4**.

1.4 Establishment of ladder diagram (step 2)

Express the control operations decided by 218M ladder diagram. For the timer, meter, etc, which

cannot be expressed with the functional instructions.

The edited ladder should be converted into the corresponding PLC instruction to store.

1.5 Sequence program check (step 3)

The sequence program can be checked in two ways:

1) Check by simulator

Instead of the machine, connect a simulator (consisting of lamps and switches). Switch ON/OFF stands for the input signal state of machine, lamp ON/OFF for the output signal state.

2) Actual operation debugging

Debug sequence program through operating the machine. Do measures against the unexpected affairs before debugging.

Since PLC sequence control handled by software and operates on principle difference from a general relay circuit, the sequence control method must be fully understood in order to design PLC sequence program.

2.1 Execution process of sequence program

In general relay control circuit, each relay operates at approximately the same time, in the figure below for example, when relay A operate, the relay D and E operate at approximately the same time(when contacts B and C are off)., In PLC sequence control, each relay of circuit operates sequentially. When relay A operates, relay D operates, then relay E(see the below figure). Thus each relay operates in sequence which can be written as a ladder diagram. (programmed sequence).




Fig. 2.1(a) circuit example

Fig.(b) and (c) illustrate operations varying from the relay circuit to PLC program.




Fig. 2.1(b)




Fig. 2.1(c)

(1) Relay circuit

In Fig. (A) and (B), the operations are the same. Turning on A turns on B and C. Turning on C turns off B.

(2) 218M PLC program

In Fig.(B), as in the relay circuit, turning on A turns on B and C, and after one cycle of the PLC

sequence, turns off B. But in Fig.(C), turning on A turns on C, but does not turn on B.

2.2 Repetitive cycle

The sequence program is executed from the beginning of coding to the end of coding of the ladder diagram in the sequence written. When the sequence program ends, the program starts over from the beginning. This is called repetitive operation.


The execution time from the beginning to the end of the ladder diagram is called the sequence processing time. The shorter the process time is, the better the signal response becomes.

2.3 Priority of execution(1st level, and 2nd level)


GSK218M PLC consists of two parts: 1st level sequence part, 2nd level sequence part. They have different execution period.

The 1st level sequence part operates every 4ms, which can operate the short pulse signal with high-speed response).

The 2nd level sequence part operates every 4*n ms. Here n is a dividing number for the 2nd level sequence part. The 2nd level sequence part is divided into n part, and every part is executed every 4ms.



218M PLC is solely executed in PLC-AVR single unit, and the second 2ms of every 4ms is the communication time of CNC reading or writing PLC data.



After the last 2nd level sequence part (division n) is executed, the sequence program is executed again from the beginning. Thus, when the dividing number is n, the cycle of execution is 4*n ms. The 1st level sequence operates every 4ms, and the 2nd level sequence every 4*n ms. If the steps of the 1st level sequence is increased, the steps of the 2nd level sequence operating within 4ms becomes less, thereby increasing the dividing number and making the processing time longer. Therefore, it is desirable to program so as to reduce the 1st level sequence to a minimum.

2.4 Sequence program structure


With the conventional PLC, a ladder program is described sequentially. By employing a ladder language that allows structured programming, the following benefits are derived:

1. A program can be understood and developed easily
2. A program error can be found easily.
3. When an operation error occurs, the cause can be found easily.

Three major structured programming capabilities are supported:


1) Subprogram

A subprogram can consist of a ladder sequence as the processing unit.



2) Nesting


Ladder subprograms established are combined to structure a ladder sequence.



3) Conditional branch


The main program loops and checks whether conditions are satisfied. If a condition is satisfied, the

corresponding subprogram is executed. If the condition is not satisfied, the subprogram is skipped.




2.5 Processing I/O (input/output) signals

Input signal processing:



Output signal processing:



2.5.1 Input signal processing

(1) Input memory of NC

The input signals from NC are loaded in memory of NC and are transferred to the PLC at intervals of 4ms. Since the 1st level sequence part directly refer to these signal and process operations.

(2) Input signal memory to machine tool

The input signal memory stores signals transferred from the machine tool at intervals of 2ms period. Since the 1st level sequence part directly refer to these signal and process operations.

(3) 2nd level input signal memory

The 2nd level input signal memory is also called as 2nd level synchronous input signal memory. The stored signals are processed by the 2nd level sequence part. State of the signals set this memory synchronizes with that of 2nd level sequence part.

Input memory Signals from NC and machine tool are transferred to the 2nd level input signal memory only at the beginning of execution of the 2nd level sequence part. Therefore, the state of the 2nd level synchronous input signal memory does not change from the beginning to end of the execution of the 2nd level sequence part.

2.5.2 Output signal processing

(1) NC output memory

The output signals are transferred form the PLC to the NC output memory at intervals of 4ms.

(2) Output signals to machine tool


Output signal to the machine tool from PLC output signal memory to the machine tool.

Note:


The state of the NC input memory, NC output memory, input signals from machine, input/output memory signals to machine can be checked by using the PC self-diagnosis function. The self-diagnosis number specified is the address number used by the sequence program.

2.5.3 Synchronous processing short pulse signal

1st level sequence part is used for processing the short pulse signal. But when it is less than 4ms, namely, when 1st level sequence is executed, the state of input signal may change as follows:



When A=0, and B1=1, A becomes 1, at this time, the next line of ladder is executed, B2=1. B1 and B2 are also 1




B1 and B2 are not 1 simultaneously after the signal A is processed synchronously by the medium relay.

2.5.4 Difference state of signals between 1st level and 2nd level

The state of the same input signal may be different in the 1st level and 2nd level sequences. That is, at 1st level, processing is performed using input signal memory and at 2nd level, processing is performed using the 2nd level synchronous input signal memory. Therefore, it is possible for a 2nd level sequence execution at the worst, compared with a 1st level input signal.

This must be kept in mind when writing the sequence program.



When the processing is 1st 4ms, A=1, and B=1 after 1st sequence part is executed. At the same time, 2nd sequence part is started to execute A=1 is stored to the 2nd sequence part and the 1st division of 2nd sequence part is executed.

When the processing is 2nd 4ms, A=0, and B=0 after 1st sequence part is executed. And then

2nd division of 2nd sequence part is executed, at this time, A is still 1. So C=1.

So, B and C are different.

2.6 Interlocking

Interlocking is externally important in sequence control safety.

Interlocking with the sequence program is necessary. However, interlocking with the end of the electric circuit in the machine tool magnetic cabinet must not be forgotten. Even though logically interlocked with the sequence program (software), the interlock will not work when trouble occurs in the hardware used to execute the sequence program. Therefore, always provide an interlock inside the machine tool magnetic cabinet panel to ensure operator safety and to protect the machine from damage.

3 Address

An address shows a signal location. Addresses include input/output signals with respect to the machine, the input/output signals with respect to the CNC, the internal relays, the meters, the keep relays, and data table. Each address consists of an address number and a bit number. Its serial number regulations are as follows:

Address regulations:

The address comprises the address type, address number and the bit number in the format as shown below:

X 000 . 6

Type Address number Bit number

Type: including X, Y, R, F, G, K, A, D, C, P, L, T

Address number: decimal serial number stands for one byte.

Bit number: octal serial number, 0~7 stands for 0~7 bit of byte of front address number

218M PLC address type is as follows:

Character	Signal description	Length
X	Machine tool→PLC(64 byte)	INT8U
Y	PLC→machine tool (64 byte)	INT8U
F	CNC→PLC(64 byte)	INT8U
G	PLC→CNC(64 byte)	INT8U
R	Internal relay(512 byte)	INT8U
D	Data register (0~255)	
DC	Counter preset data register	
C	Meter (0~127)	
A	PLC message request signal	INT8U
T	Timer (0~127)	
DT	Timer preset data register	
K	Keep relay (64 byte)	INT8U

3.1 Addresses from Machine tool to PLC (X)

X addresses of GSK218M PLC are divided into two:

1. X addresses are assigned to IO input interface of XS43, XS44 and XS45.
2. X addresses are assigned to the input press keys on MDI panel.

3.1.1 Assignment of IO module X address

The addresses are from X0 to X5. Its type is INT8U, 48 types. They are assigned to three IO input interface of XS 43, XS44 and XS45.

The signal specification of X addresses can be customized by customer according to the actual operation. X addresses are used to connect the machine tool with the ladder. For the initial definition of input address, see Connection.

3.1.2 Assignment of MDI panel X address

The addresses are from X20 to X30, 11bytes. They correspond to the press keys on MDI panel,

and their signal definitions cannot be changed by user.

Addresses and press keys are as follows:

Input key on operator panel	PLC address
Edit mode	X20.0
Auto mode	X20.1
MDI mode	X20.2
Machine zero return mode	X20.3
Single step mode	X20.4
Manual mode	X20.5
MPG mode	X20.6
DNC mode	X20.7
Skip	X21.0
Single block	X21.1
Dry run	X21.2
Miscellaneous(M, S, T) lock	X21.3
Machine lock	X21.4
Selection stop	X21.5
Program restart	X21.6
Spindle CW	X22.0
Spindle stop	X22.1
Spindle CCW	X22.2
Spindle negative override	X22.3
Spindle override cancel	X22.4
Spindle positive override	X22.5
Spindle jog	X22.6
Lubrication	X23.0
Cooling	X23.1
Chip removal	X23.2
Cycle start	X23.6
Feed hold	X23.7
Feedrate positive override	X24.0
Feedrate override cancel	X24.1
Feedrate negative override	X24.2
Rapid	X24.7
Rapid F0 / 0.001	X26.0
Rapid 25% / 0.01	X26.1
Rapid 50% / 0.1	X26.2
Rapid 100% / 1	X26.3
Manual feed axis +X	X27.0
Manual feed axis +Y	X27.1
Manual feed axis +Z	X27.2

Manual feed axis +Th4	X27.3
USER1	X27.4
Manual feed axis -X	X28.0
Manual feed axis -Y	X28.1
Manual feed axis -Z	X28.2
Manual feed axis -Th4	X28.3
USER2	X28.4
USER3	X28.7
Spindle orientation	X29.0
Tool magazine zero return	X29.1
Tool clamp/ release	X29.2
Tool magazine CW	X29.3
Tool magazine CCW	X29.4
tool infeed	X29.5
tool retraction	X29.6
Tool change manipulator	X29.7
Overtravel release	X30.0

3.2 Address (Y) from PLC to machine tool

Y addresses of GSK218M PLC are divided into two:

1. Y addresses are assigned to IO input interface of XS40, XS41 and XS42.
2. Y addresses are assigned to the indicators on MDI panel.

3.2.1 Assignment of IO module Y address

- a) The addresses are from Y0 to Y5. Its type is INT8U, 48 types. They are assigned to three IO input interface of XS40, XS41 and XS42.

The signal specification of Y addresses can be customized by customer according to the actual operation. Y addresses are used to connect the machine tool with the ladder. For the initial definition of input address, see Connection.

3.2.2 Assignment of IO module Y address

The addresses are from Y12 to Y19, 8 bytes. They correspond to the indicators on MDI panel, and their signal definitions cannot be changed by user.

Addresses and indicators are as follows:

Output key on operator panel	PLC address
Edit key indicator	Y12.0
Auto key indicator	Y12.1
MDI key indicator	Y12.2
Machine zero return indicator	Y12.3

Single step key indicator	Y12.4
Manual key indicator	Y12.5
MPG key indicator	Y12.6
DNC key indicator	Y12.7
Spindle CW indicator	Y13.0
Spindle CCW indicator	Y13.1
Spindle override cancel indicator	Y13.2
X machine zero return indicator	Y13.3
Y machine zero return indicator	Y13.4
Z machine zero return indicator	Y13.5
TH4 machine zero indicator	Y13.6
DEF(program restart) indicator	Y13.7
Skip indicator	Y14.0
Single block indicator	Y14.1
Dry run indicator	Y14.2
Miscellaneous(M, S, T) lock indicator	Y14.3
Machine tool lock indicator	Y14.4
Machine tool lamp indicator	Y15.0
Lubrication indicator	Y15.1
Cooling indicator	Y15.2
Chip removal indicator	Y15.3
Feedrate override cancel indicator	Y16.0
Rapid switch indicator	Y16.1
0.001/F0 indicator	Y16.2
0.01/25% indicator	Y16.3
0.1/50% indicator	Y16.4
1/100% indicator	Y16.5
Spindle orientation indicator	Y15.7
Tool magazine zero return indicator	Y16.0
Tool magazine CCW indicator	Y16.1
Tool magazine CW indicator	Y16.2
Tool magazine infeed indicator	Y16.3
Tool magazine retraction indicator	Y16.4
Tool magazine clamp indicator	Y16.5
Tool change manipulator indicator	Y16.6
USER3 (tool change position) indicator	Y16.7
+X indicator	Y17.0
+Y indicator	Y17.1
+Z indicator	Y17.2
+TH4 indicator	Y17.3
USER1 indicator	Y17.4
-X indicator	Y18.0
-Y indicator	Y18.1
-A indicator	Y18.2

-TH4 indicator	Y18.3
USER2 key indicator	Y18.4
Overtravel completion indicator	Y19.0
Feed hold indicator	Y19.1
Cycle start indicator	Y19.2
Tool magazine zero return indicator	Y19.3

3.3 Address (G) from PLC to CNC

Addresses are from G0 to G63. Type: INT8U, 64 bytes.

For signals, see Volume Function.

Key signals on the operator panel

Key signal on operator panel	PLC address
Edit mode	G20.0
Auto mode	G20.1
MDI mode	G20.2
Machine zero return mode	G20.3
Single step mode	G20.4
Manual mode	G20.5
MPG mode	G20.6
DNC mode	G20.7
Skip	G21.0
Single block	G21.1
Dry run	G21.2
Miscellaneous (M,S, T) lock	G21.3
Machine tool lock	G21.4
Selection stop	G21.5
Program restart	G21.6
Spindle CW	G22.0
Spindle stop	G22.1
Spindle CCW	G22.2
Spindle negative override	G22.3
Spindle override cancel	G22.4
Spindle positive override	G22.5
Spindle jog	G22.6
Lubrication	G23.0
Cooling	G23.1
Chip removal	G23.2
Cycle start	G23.6
Feed hold	G23.7
Feedrate positive override	G24.0
Feedrate override cancel	G24.1

Feedrate negative override	G24.2
Rapid switch	G24.7
Rapid F0	G25.0
Rapid 25%	G25.1
Rapid 50%	G25.2
Rapid 100%	G25.3
Incremental step 0.001	G26.0
Incremental step 0.01	G26.1
Incremental step 0.1	G26.2
Incremental step 1	G26.3
Manual feed axis +X	G27.0
Manual feed axis +Y	G27.1
Manual feed axis +Z	G27.2
Manual feed axis +Th4	G27.3
Manual feed axis -X	G28.0
Manual feed axis -Y	G28.1
Manual feed axis -Z	G28.2
Manual feed axis -Th4	G28.3
Spindle orientation	G29.0
Tool magazine zero return	G29.1
Tool clamp/release	G29.2
Tool magazine CW	G29.3
Tool magazine CCW	G29.4
Tool infeed	G29.5
Tool retraction	G29.6
Tool change manipulator	G29.7
Overtravel release	G30.0

Bit signal of G63 byte is used by the internal of the system, G63.0 and G63.1 should be carefully specified when the user compiles M and S instructions.


3.4 Address (F) from CNC to PLC

Addresses are from F0 to F63. Type: INT8U, 64 bytes.
For signals, see Volume Function.

3.5 Internal relay address (R)

The address area is cleared to zero when the power is turned on.
Type: INT8U, with 512 bytes.


R255.0~R255.7 are used by the system, cannot be defined by the user.



3.6 Address of keep relay (K)


The area is used as keep relays and PLC parameters. In each modal, the following number of bytes can be used. Since this area is nonvolatile, the content of the memory do not disappear even when the power is turned off. **K000~~K005 are used by the system, and cannot be defined by the user.**

Type: INT8U, with 64 bytes.



3.7 Addresses(A) for message selection displayed on CRT

The address area is cleared to zero when the power is turned on.
Type: INT8U, with 32 bytes.



3.8 Address of meter (C)

The area is used as storing current counting value in meter. The address area is cleared to zero when the power is turned on.

Type: 128 addresses.

3.9 Meter preset address(DC)

The address area is used to store the meter preset value. Since this area is nonvolatile, the content of the memory do not disappear even when the power is turned off.

Type: 128 addresses.

3.10 Timer addresses (T)

The area is used as storing current counting value in timer. The initial data is the preset value when the system is turned off. When preset value is 0, the current data is preset value.

Type: 128 addresses.

3.11 Addresses of timer preset value (DT)

The address area is used as storing preset value. Since this area is nonvolatile, the content of the memory do not disappear even when the power is turned off.

Type: 128 addresses.

3.12 Address of data table (D)

The content of the memory do not disappear even when the power is turned off.

Type: 256 addresses. D240~247 are for tool magazine. D240~247 are used by the system and cannot be defined.

3.13 Label address (L)

Label addresses are used to specify jump destination labels and LBL labels in JMPB instructions.
Range: 0~99

3.14 Subprogram numbers (P)

Subprogram numbers are used to specify jump destination subprogram labels and SP instruction subprogram labels in CALL instruction.
Range: 0~99

4 PLC Basic Instruction

Designing a sequence program begins with writing a ladder diagram. The ladder diagram is written using relay contact symbols and functional instruction code. Logic written in the ladder diagram is entered as a sequence program in the Programmer. There are two sequence program entry methods. One is the entry method with the mnemonic language (PLC instructions such as RD, AND, OR). The other is the relay symbols of the ladder diagram. When the relay symbol method is used, the ladder diagram format can be used and programming can be performed without understanding the PLC instruction format.

Actually, however, the sequence program entered by the relay symbol method is also internally converted into the instruction corresponding to the PLC instruction.

The basic instructions are often used when the sequence program is designed, and the execute one-bit operation.

GSK218M basic instructions are as follows:

Instruction	Function
RD	Shifts left the content by one bit in register and sets the state of a specified signal in ST0.
RD.NOT	Shifts left the content by one bit in register and sets the logic state of a specified signal in ST0.
WRT	Outputs the results of logic operation to a specified address.
WRT.NOT	Inverts the results of logical operations and output it to a specified address.
AND	Induces a logical product.
AND.NOT	Inverts the state of a specified signal and induces a logical product.
OR	Induces a logical sum.
OR.NOT	Inverts the state of a specified signal and induces a logical sum.
OR._STK	Sets the logical sum of ST0 and ST1, and shifts the stack register right by one bit.
AND.STK	Sets the logical product of ST0 and ST1, and shifts the stack register right by one bit.

4.1 RD, RD.NOT, WRT, WRT.NOT


Instructions and functions

Instruction	Function
RD	Shifts left the content by one bit in register and sets the state of a specified signal in ST0.
RD.NOT	Shifts left the content by one bit in register and sets the logic state of a specified signal in ST0.
WRT	Outputs the results of logic operation to a specified address.
WRT.NOT	Inverts the results of logical operations and output it to a specified address.

Instruction specifications:

- WRT, WRT. NOT are the output relay, internal relay instructions. They cannot be used to input relay.
- The parallel WRT instruction can be continuously used many times.

Programming



4.2 AND, AND.NOT instructions


Instructions and functions

Instruction	Function
AND	Induces a logical product.
AND.NOT	Inverts the state of a specified signal and induces a logical product.

Instruction specifications:

- AND, AND NOT can connect with one contact in serial. The serial contact numbers are not limited and they can be used many times.

Programming



4.3 OR, OR.NOT instructions

Instructions and functions

Instruction	Function
OR	Induces a logical sum.
OR.NOT	Inverts the state of a specified signal and induces a logical sum.

Instruction specification:

- OR, OR_NOT can connect with one contact in parallel.
- OR, OR.NOT begins from their step, which can connect with the for the mentioned step in parallel.

Programming:



```
RD X002.1
OR_NOT F100.3
WRT Y003.7
```

4.4 OR.STK instruction


Instruction and function:

Instruction	Function
OR.STK	Sets the logical sum of ST0 and ST1, and shifts the stack register right by one bit.

Instruction specification:

- OR.STK a sole instruction without other address.

Programming



```
RD X002.1
AND_NOT X002.2
RD_NOT F100.3
AND F100.6
OR.STK
RD R022.1
WRT Y003.7
```

As the above figure, there are three branch circuit ①, ②, ③ from left bus to the node N1, among which ①, ② is circuit block in series; when there is the serial circuit block in the parallel from the bus to node or between nodes, the following branch end uses RD instruction except for the first branch. The branch ③ is not serial circuit block to use OR instruction.

OR.STK and AND.STK are instructions without operation components, indicating the OR, AND relationship between circuit blocks.

4.5 AND.STK instruction


Instruction and function

Instruction	Function
AND.STK	Sets the logical product of ST0 and ST1, and shifts the stack register right by one bit.

Instruction specification

- When the branch loop (parallel loop block) is connected to the previous loop in series, use AND.STK instruction. The starting point of branch uses RD, RD.NOT instruction, after the parallel loop block ends, AND,STK instruction is connected to previous loop in series.
- AND.STK a sole instruction without other address.

Programming



```

RD X002.1
OR.NOT F100.3
OR.NOT X011.0
RD R100.0
AND.NOT R100.3
RD G003.3
AND R009.7
OR.STK ← (1)
AND.STK ← (2)
WRT Y003.7
    
```

As the above figure and instruction list, (1)RD reports the circuit block in series is connected parallel (2)AND.STK reports the block ① and ② are connected in series.

5 PLC Functional Instructions

Basic instructions such as controlling operations of machine tool are difficult to program, therefore, functional instructions are available to facilitate programming.

218M functional instruction as follows:

No.	Instruction	Processing
1	END1	End of a first-level ladder program
2	END2	End of a second-level ladder program
3	CALL	Calling subprogram
4	SP	Subprogram
5	SPE	End of subprogram
6	SET	Set
7	RST	Reset
8	JMPB	Label jump
9	LBL	Label
10	TMR	Timer
11	CTR	Binary meter
12	DEC	Binary decoding
13	COD	Binary code conversion
14	COM	Common line control
15	COME	End of common line control
16	ROT	Binary rotation control
17	SFT	Register shift
18	DIFU	Rising edge check
19	DIFD	Falling edge check
20	COMP	Binary comparison
21	COIN	Coincidence check
22	MOVN	Transfer of an arbitrary number of bytes
23	XMOV	Indexed data transfer
24	DSCH	Binary data search
25	ADD	Binary addition
26	SUB	Binary subtraction
27	ANDF	Functional AND
28	ORF	Functional OR
29	NOT	Logical Negation
30	EOR	Exclusive OR

5.1 END1 (1st level sequence program end)

Function:

Must be specifies once in a sequence program, either at the end of the 1st level sequence, or at the beginning of the 2nd level sequence when there is no 1st level sequence. It can write 100 steps.

Format:




5.2 END2 (2nd level sequence program end)

Function

Specify at the end of 2nd level sequence.

Format:



5.3 CALL (call subprogram)


Function

Call a specified subprogram.

CALL has the following additional functions:

- * More than one call instructions can call the same subprogram.
- * Calling instruction can be nested.
- * Cannot call subprogram in 1st level sequence program.
- * Subprogram must be written after END2.

Format:



Control condition:

ACT=0, execute the next instruction behind CALL.

ACT=1, call subprogram which number is specified.

Parameter:

Subprogram: specifies the subprogram number of a subprogram to be coded following this instruction. Range: 0~99.

5.4 SP (Subprogram)


Function:

The SP functional instruction is used to create a subprogram. A subprogram number is specified as a subprogram name. SP is used with the SPE functional instruction to specify the subprogram range.

Note:

1. A subprogram must be written after END2.
2. Another subprogram cannot be nested into a subprogram.

Format:



Parameter:

Subprogram number: specifies the subprogram label of a subprogram to be coded following this instruction. Range: 0~99.

5.5 SPE (subprogram end)


Function:

- * it is used to specify the range of subprogram when SPE is used with the S P.
- * the control will return to the main program which called the subprogram when the instruction is executed.
- * the subprogram is written after END2.

Format:



Example:




5.6 SET (set)

Function:

Set to 1 for the specified address.

Format:



Control condition:

ACT=0, add.b keep invariably.

ACT=1, add.b set to1.

Parameter:


Add.b: set element address bit can be the output coil, Add= Y, G, R, K, A.

5.7 RST (reset)

Function:

Set to 0 for the specified address.

Format:



Control condition:

ACT=0, add.b keep invariably.

ACT=1, add.b set to1.

Parameter:

Add.b: reset element address bit can be the output coil, Add= Y, G, R, K, A.

5.8 JMPB (label jump)


Function:

The JUMP functional instruction transfer control to a Ladder immediately after the lable set in a Ladder program.

JMPB has the following additional functions:

- * More than one jump instruction can be coded for the same label.
- * Jumped END1 and END2 are forbidden.
- * Jump instructions can transfer control freely before and after the instruction within the program unit in which the instruction is coded.
- * Jump can be executed.

Format:



Control conditions:

ACT=0: The next instruction after the JMPB instruction is executed.

ACT=1: Control is transferred to the Ladder immediately after the specified label.

Parameter:

Lx: specifies the label of the jump destination. A value from 0 to 99 can be specified.


5.9 LBL (Label)

Function:

The LBL functional instruction specifies a label in a ladder program. It specifies the jump destination for JMPB functional instruction.

Note: one Lx label is only specified one time with LBL. Otherwise, the system alarms.


Format:



Parameter:

Lx: specifies the label of the jump destination. Label number range: 0~99

Example:




5.10 TMR (timer)

Function:

This is an on-delay timer.

Format:




Control condition:

ACT=0: turns off the timer relay.

ACT=1: initiates the timer. i.e. timing from 0.

Detailed functions:



Parameter:

TIMER : timer serial number is named with xxx which are numbers (0~127).

Output:

W : output coil. W=1 when the output reaches the preset value. W=0 when the output does not reach the preset value.

Note:

The setting time is every 4ms for the timer.

The timer can be set via **【TMR】** in **【PLCPAR】** .


5.11 CTR (binary counter)

Function:

The data in the counter are binary and their functions are as follows:

- 1) Preset counter
Preset the count. It outputs a signal when the preset count is reached.
- 2) Ring counter
Upon reaching the preset count, returns to the initial value by issuing another counter signal.
- 3) Up/down counter
The count can be either up or down.
- 4) Selection of initial value
Its initial value is 0 or 1.

Format:



Control condition:

Specifies the initial value(CN0):

CN0=0: begins the value of the counter with 0.

CN0=1 begins the value of the counter with 1.

Specify up or down counter (UPDOWN):

UPDOWN=1: Up counter

UPDOWN=0: Down counter

Reset (RST):

RST=0: release reset.

RST=1: enable reset. When W=0, the integrated value is reset to the initial value.

RST is set to 1 only when reset is required.

Count signal(ACT):

ACT=1: count is made by catching the rise of ACT.

ACT=0: counter does not operate. W does not change.

Parameter:

METER: specifies the counter serial number with xxx which are numbers (0~127).

Output:

W: coil output. W=1 when the counter reaches the preset value.

Note: When the counter is rise edge to count, and the counter number is duplicated, or falls outside the valid range, the operation will be unpredictable.

The timer can be set via **【TMR】** in **【PLCPAR】** .


5.12 DEC (binary decode)

Function:

DEC can decode binary code data. Outputs 1 when the eight-digit BCD signal is equal to a specified number, and 0 when not.

It is mainly used to decode M or T function.

Format:



Control condition:

- ACT=0 : resets all the output data bit.
- ACT=1 : decode data. Results of processing is set in the output data address.

Parameter:

- length : Set the size of code data to the 1st digit of the parameter.
0001: code data is in binary format of 1 byte length.
0002: code data is in binary format of 2 byte length.
- S1 : code data address. Specifies an address at which code data is stored.
- S2 : number specification decode designation. Specifies the first of the 8 continuous numbers to be decoded.
- S3 : decode result address. Specifies an address where the decoded result shall be output. A one-byte area is necessary in the memory for the output.

Example:

DEC 1 F10 8 R4


- When ACT=1 and F10=8, R4=0000,0001;
- When ACT=1 and F10=9, R4=0000,0010;
-
- When ACT=1 and F10=15, R4=1000,0000;

5.13 COD (binary code conversion)

Function:

COD instruction automatically creates a table with corresponding size used for user inputting conversion table data when it inputs the data capacity. Each table has 10 lattices and if it is not divided by 10, count the lattices by its quotient adding 1, but its capacity data does not change.

Format:



S1	0	1	2	N-1
S2	XXX	YYY	AAA	UUU

Control conditions:

Reset (RST):


RST=0: do not reset.

RST=1: reset error output W.

Activate instruction (ACT):

ACT=0 : do not execute COD.

ACT=1 : execute COD. Take value of "Conversion input data address(S1)" as the table number of conversion table, take out of 1 conversion data which corresponds to the table number from the conversion table, output the output address used for the conversion data (S2).



Parameter:

Length1 : designates binary numerical size in the conversion table.

- 1: Numerical data is binary 1-byte data.
- 2: Numerical data is binary 2-byte data.

length2 : Number of conversion table data. 100 data can be made. 100 bytes when designating 1 byte format, and 100 words when 2 byte format. All number is at most 512 bytes in COD conversion table.

- 1: 2 bytes
- 2: 4 bytes
- 3: 8 bytes
- 4: 16 bytes
- 5: 32 bytes
- 6: 64 bytes
- 7: 128 bytes
- 8: 256 bytes

S1 : Data in the conversion data table can be taken out by specifying the table number. The address specifying the table number is called conversion input data address, and 1-byte memory is required from the specified address.

S2 : Conversion data output address. Memory of the byte length specified in the format designation is necessary from the specified address.

Output:

If there are any abnormality when executing the CODB instruction, W=1, and error will be

output.


Note: Size of the conversion data table is maximum 256. This conversion data table is programmed between the parameter conversion data output address of this instruction and the error output(W).

5.14 COM (common line control)

Function:

This function can be used for specifying the number of coil only on the PLC-SB/SC. If the common line end instruction is not specified, the system will alarm.

Format:



Control condition:

ACT=0: The specified number of coils or the coils within the region specified are unconditionally turned off (W=0).

ACT=1: No processing is performed.

Note:


1. In the range specified with a COM instruction, no additional COM instruction can be specified.
2. the coil for WRT.NOT in the range specified with a COM instruction is singly set to 1 when COM ACT=0.
3. do not use the function block between COM and COME, otherwise, the system will alarm.

5.15 COME (common line control end)

Function:

The instruction reports the division in the region specification of the common line control instruction (COM). This instruction cannot be used alone. It must be used together with the COM instruction.

Format:




5.16 ROT (Binary rotation control)

Function:

Controls rotors, such as the toolpost, rotary table, etc., and is used for the following functions.

1. Selection of the rotation direction via the shorter path.
2. Calculation of the number of steps between the current position and the goal position; calculation of the position on position before the goal to the number of steps up to one position before the goal.
3. Calculation of the position one position before the goal or of the number of steps up to one position before the goal.

Format:



Control conditions:

Specify the starting number of the rotor(CNO):

CNO=0: begins the number of the position of the rotor with 0.

CNO=1: begins the number of the position of the rotor with 1.

Select the rotation direction via the shorter path or not: (DIR):

DIR=0: no direction is selected. The direction of rotation is only forward.

DIR=1: selected. The direction of rotation is forward/backward.

Specify the operating conditions (POS):

POS=0: calculate the goal position.

POS=1: calculates the position one position before the goal position.

Specify the position or the number of steps(INC):

INC=0: calculates the number of the position. If the position one position before the goal position is to be calculated, specify INC=0 and POS=1.

INC=1: calculates the number of steps. If the difference between the current position and the goal position is to be calculated, specify INC=1 and POS=0.

Execution instruction (ACT):

ACT= 0: the ROT instruction is not executed. W does not change.

ACT=1: executed. Normally, set ACT=0. If the operation results are required, set ACT=1.

Parameter:



- S1 : specify the rotor indexing number.
- S2 : specify the address storing the current position.
- S3 : specify the address storing the goal position(or instruction value), for example the address storing the CNC output T code.
- S4 : calculate the number of steps for the rotor to rotate, the number of steps up to the position one position before, or the position before the goal. When the calculating result is to be used, always check that ACT=1.

Output:

W: The direction of rotation for control of rotation via the shorter path is output to W. When W=0, the direction is forward (FOR) when 1, reverse (REV). The definition of FOR and REV is shown in the following figure. If the number given to the rotor is ascending, the rotation is FOR; if descending, REV. The address of W can be determined arbitrarily. When, however, the result of W is to be used, always check that ACT=1.

Example:

Rotor rotation direction:



Perform the short path rotation, and calculate the position number of previous one position of goal position.

Current position number S2=1, position number of rotation graduation S1=12, RNO=1, DIR=1 POS=1, INC=0:

- When S3=10 goal position is A, and ACT=1, S4=11, W=1.
- When S3=8 goal position is B, and ACT=1, S4=9, W=1.
- When S3=5 goal position is C, and ACT=1, S4=4, W=0.


When S3=3 goal position is D, and ACT=1, S4=2, W=0.

5.17 SFT (shift register)

Function:

The instruction shifts 1-byte (8-bit) data by a bit to the left or right. Note that W=1 when data “1” is shifted from the left extremity (bit 8) in left shift or from the right extremity (bit 0) in right shift.

Format:



Control conditions:

Shift direction specification (DIR)

DIR=0: Left shift

DIR=1: Right shift

Condition specification (CONT)

CONT=0: do not cycle shift

CONT=1: cycle shift

Reset (RST)

The shifted out data(W=1) is reset (W=0).

RST=0: W is not reset.

RST=1: W is reset (W=0).

Actuation signal (ACT)


ACT=0: do not execute SFT instruction.

ACT=1: shifting processing is done when ACT=1. For shifting one bit only, execute an instruction when ACT=1, and then, set ACT to 0.

Parameters:

S1 : sets shift data addresses. These designated addresses require a continuous 1-byte memory for shift data.

Length : a 4-bit number, and its definition is as follows:



L : range: 0~8.

A : bit parameter. A=0: When ACT=1 is shifting, the shift period is one bit.

A=1: ACT is taken as pulse signal, it is 1 from 0, shift one bit.

Output:

W : W=0: "1" was not shifted out because of the shift operation.


W=1: "1" was shifted out because of the shift operation.

5.18 DIFU (rising edge check)

Function:

The DIFU instruction sets the output signal to 1 for one scanning cycle on a rising edge of the input signal.

Format:



Control condition:


Input signal: On a rising edge (0→1) of the input signal, the output signal is set to 1.

Output signal: The output signal level remains at 1 for one scanning cycle of the ladder level where this functional instruction is operating.

Parameter: Rising edge number

Parameter: L :rising edge number, range 0~255. Another DIFU instruction or DIFD instruction in the ladder uses the same number, the system will alarm.

Operation:




5.19 DIFD (falling edge check)

Function:

The DIFD instruction set the output signal to 1 for one scanning period on a falling edge of the input signal.

Format:



Control conditions:


Input signal: on a falling edge (1→0) of the input signal, the output signal is set to 1.

Output signal: the output signal level remains at 1 for one scanning period of the ladder level where this functional instruction is operating.

Parameter:

L : rising edge number, range 0~255. Another DIFU instruction or DIFD instruction in the ladder uses the same number, the system will alarm.

Operation:




5.20 COMP (binary comparison)

Function:

Compares binary values. Specifies enough byte to store the input data and the comparison data in the memory.

Format:




Control conditions:

ACT=0: The COMP instruction is not executed. W does not alter.

ACT=1: The COMP instruction is executed.

Parameter:

Length: specification format(constant or address) and data length(1 or 2 bytes) for the input data.



S1, S2: content of comparison source 1 and comparison source 2. It can be constant and also be address number.

Address number: R, X, Y, F, G, K, A, D, T, C.

Output:


- W=0: input data > comparison data
- W=1: input data ≤ comparison data

5.21 COIN (coincidence check)

Function:

Checks whether the input value and comparison value coincide.

Format:




Control conditions:

- ACT=0, the COIN instruction is not executed. W does not change.
- ACT=1, the COIN instruction is executed.

Parameter:

Length: specification format(constant or address) and data length(1 or 2 bytes) for the input data.



- S1 : The input data can be specified as either a constant or an address storing it.
- S2 : address storing of comparison data

Output:

- W : W=0: input value ≠ comparison value
- W=1: input value = comparison value


5.22 MOVN (transfer of data)

Function:

The MOVN instruction transfers data from source address and a specified binary data to a

specified destination address.

Format:



Control condition:

ACT=0: No data is transferred.

ACT=1: The byte of specified number is transferred.

Parameter:

Length : transferred byte number.


S1 : stating byte of address or constant of source data.

Selecting transfer format according to S1:

1. S1 is constant: if S2 is single byte address, S1 in byte unit is copied to address corresponding to Length byte which takes S2 as the initial; if S2 is in word unit, it is copied in word address;
2. S1 is address: S1 and S2 transmit the data in byte in spit if S1 and S2 address classifications are matched.

S2 : starting byte of destination address.

Example:




1. When S1 is the constant 5 and S2 is R60, R60=00000101, R61=00000101
2. When S1 is the constant 5 and S2 is D60, D60=1285
3. When S1 is the constant 500 and S2 is D60, D60=62708
4. When S1 is the constant D50 and S2 is D60, D60=D50

5.23 XMOV (Binary index data transfer)

Function:

This function instruction instructs reading and rewriting of data in the data. The number of data(table capacity) in the data table can be specified by specifying the address, thus allowing change in table capacity even after writing the sequence program in the ROM.

Format:



Control condition:

Specify the reading or rewriting (RW)

RW=0: data is read from the data table.

RW=1: data is written in the data table.

Reset (RST)

RST=0: release reset.

RST=1: reset W=0.

Execution instruction (ACT):

ACT=0 : The XMOV instruction is not executed. W does not change.

ACT=1 : The XMOV instruction is executed.

Parameter:

Length : Specify the data long.

1: 1-byte long data.

2: 2-byte long data.

S1 : Storage address of number of data table elements. The address is used to store the data number of data table, its byte should correspond to the length specified in Length format specification, and the effective range of number of data table element is as follows with the byte length which set in Length1 format.

1 byte length: 1 to 255.

2 byte length: 1 to 32767 (Actually, set a value below the size of the D area.

S2 : Sets head address in the data table. The memory of (byte length)X (number of data table elements).

S3 : Input/output data storage address. In case of the reading, set the address of the memory which stores a reading result a writing result. The memory with the byte length which set in Length format specification is necessary.

S4 : Index storage address. Set the address of the memory in which an index value is stored. The memory with the byte length set in Length format specification is necessary. When setting an index value above the value to set in S1 storage address of number of data table elements, it causes an error output W=1. Actually, the number of data table elements does not exceed 255.

Output:

The index value set in Index storage address exceeds the value set in S1, W=1, the reading or writing of the data table isn't executed.

W=0, No error.


W=1, Error found.

5.24 DSCH (binary data search)

Function:

The DSCH instruction is used to search the binary data in data table. The number of data (table capacity) in the data table can be specified by specifying the address. Thus allowing change in table capacity even after writing the sequence program in the ROM.

Format:



Control conditions:

Reset (RST)

RST=0: Release reset.

RST=1: Reset. W=0.

Activation instruction (ACT):

ACT=0 : Do not execute DSCH instruction, W does not change.

ACT=1 : Execute DSCH instruction. If the search data is found, table number where the data is stored will be output. If the search data is not found, W becomes 1.

Parameter:

Length : Specifies data length

1: 1-byte long data.

2: 2-byte long data.

S1 : Storage address of number of data in data table. This address requires memory of number of byte according to the format designation. Number of data in the table is n+1(head number in the table is 0 and the last number is n).

S2 : Data table head address.

S3 : Search data input address.

S4 : Search result output address. After searching, if search data is found, the table number where the data is stored will be output. the searched table number is output in this search result output address. This address requires memory of number of byte according to the format designation.

Output:

W=0, Search data found.


W=1, Search data not found.

5.25 ADD (addition)

Function:

This instruction performs binary addition between 1-, 2-byte data. In the operation result register, operation data is set besides the numerical data representing the operation results. The required number of bytes is necessary to store each augend, the added, and the operation output data.

Format:



Control conditions:

Reset (RST):

RST=0: Release reset.

RST=1: Reset. W=1.


Activation instruction (ACT):

ACT=0 : Do not execute ADD. W does not change.

ACT=1 : Execute ADD.

Parameter:

Length : Specifies data length(1 or 2 bytes) and the format for the addend(constant or address).



S1 : Augend address.

S2 : Addend data specification determines the format of the addend.

S3 : Specify the address to contain the result of output operation.

Output:

W=0: Operation correct.

W=1: Operation incorrect.


When W=1, the result of addition exceeds the specified data length.

5.26 SUB (binary subtraction)

Function:

This instruction executes the subtraction operation in the binary format of 1 or 2 bytes. In the operation result register, operation data is set besides the numerical data representing the operation. A required number of bytes is necessary to store the subtrahend, and the result.

Format:



Control conditions:

Reset (RST):

RST=0: Release reset.

RST=1: Reset. W=0.


Activation instruction (ACT):

ACT=0 : Do not execute SUB. W does not change.

ACT=1 : Execute SUB.

Parameter:

Length : Specifies data length(1 or 2 bytes) and the format for the subtrahend(constant or address).



S1 : Address containing the minend.

S2 : Specification determines the Length.

S3 : Specifies the address to contain the result of operation.

Output:

W=0: Operation correct.

W=1: Operation incorrect.


When W=1, the result of subtraction exceeds the specified data length.

5.27 ANDF (functional and)

Function:

The ANDF instruction ANDFs the contents of address A with a constant(or the contents of address B), and stores the result at address C.

Format:




Control conditions:

- ACT=0 : The ANDF instruction is not executed.
- ACT=1 : The ANDF instruction is executed.

Parameter:

Length : Specify a data length (1 or 2 bytes), and an input data format(constant or address specification).




- S1 : Input data to be ANDed. The data that is held starting at this address and has the data length specified in Length format specification is treated as input data.
- S2 : Input data to be ANDed with. When address specification is selected in format specification, the data that is held starting at this address and has the data length specified in Length format specification is treated as input data.
- S3 : Address used to store the result of an ANDF operation. The result of and ANDF operation is stored starting at this address, and has the data length specified in Length format specification.

Example::

When address A and address B hold the following data:

Address A	1	1	1	0	0	0	1	1
Address B	0	1	0	1	0	1	0	1

The result of the ANDF operation is as follows:




5.28 ORF (functional or)

Function::


The ORF instruction ORFs the contents of address A with a constant (or the contents of address B), and stores the result at address C.

Format:



Control conditions:

- ACT=0 : The ORF instruction is not executed.
- ACT=1 : The ORF instruction is executed.




Parameter:

- Length:** Specify a data length(1 or 2 bytes), and an input data format(constant or address specification).
- S1** : Specify the input data to ORed. The data that is held starting at this address and has the data length specified in Length format specification is treated as input data.
- S2** : Input data to be ORed with. When address specification is selected in format specification, the data that is held starting at this address and has the data length specified in Length format specification is treated as input data.
- S3** : Address used to store the result of an ORF operation. The result of an ORF operation is stored starting at this address, and has the data length specified in format specification.

Example:

When address A and address B hold the following data:



Address B	0	1	0	1	0	1	0	1
-----------	---	---	---	---	---	---	---	---

ORF operates are as follows:


Address C	1	1	1	1	0	1	1	1
-----------	---	---	---	---	---	---	---	---

5.29 NOT (logical not)

Function:

The NOT instruction inverts each bit of the contents of address A, and stores the result at address B.

Format:




Control condition:

ACT=0: The NOT instruction is not executed.

ACT=1: The NOT instruction is executed.

Parameter:

Length : Specifies a data length(1 or 2 bytes).



S1 : Input data to be inverted bit by bit. The data that is held starting at this address and has the data length specified in Length format specification is treated as input data.

S2 : Address used to output the result of a NOT operation. The result of a NOT operation is stored starting at this address. And has the data length specified in Length format specification.

Example:

When address A holds the following data:

Address A	1	1	1	0	0	0	1	1
-----------	---	---	---	---	---	---	---	---

The result of the NOT operation is as follows:


Address B	0	0	0	1	1	1	0	0
-----------	---	---	---	---	---	---	---	---

5.30 EOR (exclusive or)

Function:

The EOR instruction exclusive-Ors the contents of address A with a constant(or the contents of address B), and stores the result at address C.

Format:




Control conditions:

- ACT=0 : The EOR instruction is not executed.
- ACT=1 : The EOR instruction is executed.

Parameter:

Length : Specify a data length (1 or 2 bytes) and an input data format(constant or address specification).



- S1 : Input data to be exclusive-ORed. The data that is held starting at this address and has the data length specified in Length format specification is treated as input data.
- S2 : Input data to be exclusive-ORed with. When address specification is selected report that specification, the data that is held starting at this address and has the data length specified in Length format specification is treated as input data.
- S3 : Address used to store the result of an exclusive EOR operation. The result of an exclusive EOR operation is stored starting at this address, and has the data length specified in Length format specification.

Example:

When address A and B hold the following data:

Address A

1	1	1	0	0	0	1	1
---	---	---	---	---	---	---	---

Address B

0	1	0	1	0	1	0	1
---	---	---	---	---	---	---	---

The result of the exclusive EOR operation is as follows:


Address C

1	0	1	1	0	1	1	0

6 Ladder Writing Limit

1. Sequence program must have END1 and END2 which are taken as the end marks of 1st level and 2nd level sequence part, and END1 must be before END2.
2. They only support the parallel output and do not support the multi-level output.
3. The result output address in all basic instructions and output function instruction are not set the following addresses:
 - (1) Counter preset address DC, timer preset address DT.
 - (2) K0~K5 address are occupied by the system.
 - (3) G63, R255 address are occupied by the system.
 - (4) X address on IO input interface and CNC→PLC F address.

The followings are the phrasing error, and the system will alarm.



II Function

1 Controlled Axis

1.1 Outputting of movement state of an axis

General The movement state of each axis can be output to the PLC.

Signal Axis moving signals

MV1~MV4 (F017#0~F017#3)

[Classification] Output signal

[Function] These signals indicate that a controlled axis is moving.

MV1: X is moving.

MV2: Y is moving.

MV3: Z is moving.

MV4: A is moving.

[Output conditions]

The signals become 1 when:

- The corresponding axis has started moving.

The signals become 0 when:

- The corresponding axis has stopped moving.

Axis moving direction signals

MVD1~MVD4 (F019#0~F019#3)

[Classification] Output signal

[Function] These signals indicate the movement direction of controlled axis.

MV1: movement direction of X.

MV2: movement direction of Y.

MV3: movement direction of Z.

MV4: movement direction of A.

[Output conditions] When parameter 0003#1~~0003#4 is 1:

“1” indicates the corresponding axes are negatively moving,

“0” indicates the corresponding axes are positively moving.

When parameter 0003#1~~0003#4 is 0:

“0” indicates the corresponding axes are negatively moving,

“1” indicates the corresponding axes are positively moving.

Caution:

These signals maintain their condition during a stop, indicating the direction of the axes' movement before stopping.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
F017					MV4	MV3	MV2	MV1
F019					MVD4	MVD3	MVD2	MVD1

1.2 Servo ready signal

Signal **servo ready signal**
SA (F000#6)

[Classification] Output signal

[Function] After the servo is ready, SA signal becomes 1. For the axis with absorption brake, release the brake when outputting the signal, execute the brake when the system does not output the signal.


Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
F000		SA						

2 Preparation for Operation

2.1 Emergency stop

General If you press Emergency Stop button on the machine operator's panel, the machine movement stops in a moment.



The button is locked when it is pressed, Although it varies with the machine too builder, the button can usually be unlocked by twisting it.

Signal Emergency stop signal

***ESP (G001.0)**

[Classification] Input signal

[Function] Activating an emergency stop signal stops the machine instantly.

[Operation] When the emergency stop *ESP becomes 1, the emergency stop is applied to the machine and the CNC is reset.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
X001				*ESP				
G001								*ESP

2.2 CNC overtravel signal

General When the tool tries to move beyond the stroke end set by the machine tool limit switch, the tool decelerates and stops as a result of tripping the limit switch, and an Over TRAVEL is displayed. The signal can be output with an alarm.

Signal Overtravel signal

+L1~+L4(G12#0~G12#3)


-L1~-L4(G13#0~G13#3)

[Classification] Input signal

[Function] Indicates that the control axis has reached its stroke limit. There are

individual signals for each direction in every control axis.

The + /- in the signal name indicate the direction and the number corresponds to the control axis.



[Operations] "0": the controlled unit operates as follows:

Automatic operation: If even one axis overtravel signal becomes, all axes are decelerated to stop, an alarm is given and operation is halted.

Manual operation: Only the axis whose overtravel signal has become 0 is decelerated to a stop, and the axis can be moved in the opposite direction.

Once the axis overtravel signal has become 0, the axis direction is registered. Even if the signal returns to 1, it is not possible to move that axis in that direction until the alarm is cleared.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G012					+L4	+L3	+L2	+L1
G013					-L4	-L3	-L2	-L1

2.3 Alarm signal

General When an alarm is triggered in the CNC, the alarm is displayed on the screen, and the alarm signal is set to 1. If the voltage level of the memory backup battery falls to below a specified level while the CNC is turned off, the battery alarm signal is set to 1.

Signal Alarm signal
AL (F001 #0)

[Classification] Output signal

[Function] Alarm signal reports CNC is in an alarm state as follows:

- a) P/S alarm
- b) Overtravel alarm
- c) Servo alarm

[Output conditions] These alarm signal is set to 1 when:

——The CNC is placed in the alarm state.

These alarm signals is set to 0 when:

——The alarm has been released by resetting the CNC.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
F001								AL

2.4 Mode selection

Signal mode check signal
F003#0~F003#7
 [Classification] Output signal
 [Function] Report the current selected operation mode

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
F003	MZRO	MEDT	MMEM	MRMT	MMDI	MJ	MH	MINC

2.5 Status output signal

Signal Rapid traversing signal
RPDO (F002#1)
 [Classification] Output signal
 [Function] This signal indicates that a move instruction is being executed at the rapid traverse.

[Output conditions:] 1: indicates an axis starts moving after rapid traverse has been selected;
 0: indicates that an axis starts moving after a federate other than rapid traverse has been selected. This holds true for both automatic and manual operation modes.

Cutting feed signal

CUT (F002#6)

[Classification] Output signal

[Function] These signals indicate that the cutting feed is being performed by automatic operation.

[Output conditions] These signals are 1 when:

Cutting feed is being performed by automatic operation (cutting feed for linear interpolation, circular interpolation, helical interpolation, thread cutting, skip cutting, or cutting in canned cycle).

Note:

Do not output the signal in the state of feed hold.

Output the signal during the interlock or the feedrate override is set to 0.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
F002		CUT					RPDO	

3 Manual Operation


3.1 JOG feed/incremental feed

General

JOG feed	In JOG mode, setting a feed axis and direction selection bit to 1 on the machine operator's panel moves the machine along the selected axis in the selected direction.
Incremental feed	In incremental feed mode, setting a feed axis and direction selection bit to 1 on the machine operator's panel moves the machine one step along the selected axis in the selected direction. The minimum distance the machine moves, is the least input increment. The step can be 10, 100, or 1000 times the least input increment.

The only difference between JOG feed and incremental feed is the method of selecting the feed distance. In JOG feed, the machine continues to be fed while the following signals selecting the feed axis and direction are 1: +J1, -J1, +J2, -J2, +J3, -J3, etc. In incremental feed, the machine is fed by one step. Using JOG feedrate override dial can regulate JOG feedrate. The step distance can be selected by MPG feed movement distance G026#0~G026#3.

Signal	<p>Feed axis and direction selection signal</p> <p>+J1~+J4 (G27#0~G27#3)</p> <p>-J1~-J4 (G28#0~G28#3)</p> <p>[Classification] Input signal</p> <p>[Function] In JOG feed or Incremental feed mode, select the required feed axis and direction. +/- in the signal name indicates the feed direction, the number corresponds to the controlled axis.</p>
--------	---



[Operation] When the signal is set to 1, the control unit operate as follows:
 When JOG feed or incremental feed is allowed, the control unit moves the specified axis in the specified direction.
 When the signal is set to 1 in JOG feed, the control unit continues to feed that axis while the signal is set to 1.

In incremental feed, the control unit feeds the requested axis by the step distance which is specified by the manual handle feed move distance selection signal, then the axis stops. Even if the signal is set to 0 while the axis is being fed, the control unit does not stop moving.

To feed the axis again set the signal to 0, then to 1 again.

Manual rapid traverse selection signal

RT (G024#7)

[Classification] Input signal

[Function] Select the rapid traverse rate in JOG feed or incremental feed mode.

[Use] When the signal becomes 1, the control unit operates as follows:

- The control unit executes the jog feed or incremental feed at a rapid traverse rate. The rapid traverse override is validated.
- When the signal is switched from 1 to 0 or vice versa in jog feed or incremental feed, the feedrate is decelerated until it reaches zero, then increased to the specified value. During acceleration and deceleration, the feed axis and direction selection signal can be kept 1.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G024	RT							
G027					+J4	+J3	+J2	+J1
G028					-J4	-J3	-J2	-J1

3.2 MPG/Step feed

General In MPG/Step feed mode, the machine moves by rotating the manual pulse generator(MPG)/Step. **Select the axis along which the machine moves with the MPG feed axis selection signal/axis move signal.**

Signal **MPG/Incremental select signal**
(G026#0~G026#3)

[Classification] Input signal

[Function] When the signal selects the MPG feed, MPG generates the movement distance of every pulse which also can select the movement distance per step of incremental feed .

4 Reference Point Return

4.1 Manual reference point return

General In manual reference point return mode, the machine tool move in the specified direction by setting the position parameter N0: 7#3~#7 to execute the reference point return. The selected axis on the panel reports the axis to execute the machine zero return, which is not related to the move direction of axis.

The following signals are related to the manual reference point return:

	Manual reference point return
Reference point return deceleration signal	DECX,DECY,DECZ,DECA
Reference point return completion signal	ZP1,P2, ,ZP3,ZP4

Reference point return completion signals

ZP1~ZP4(F016#0~F016#3)

[Classification] Output signal

[Function] These signals report that the machine tool is at the reference point on a controlled axis.

These signals correspond separately to all axes.

ZP1	X axis reference point return completion signal.
ZP2	Y axis reference point return completion signal.
ZP3	Z axis reference point return completion signal.
ZP4	A axis reference point return completion signal.

[Output conditions] When these signals becomes 1:

- Manual reference point return is completed and the current position is in the in-position area.
- The automatic reference point return(G28) is completed and the current position is in the in-position area.
- The reference point return check is completed and the current position is in the in-position area.
When the signal becomes 0:
 - The machine tool moves from the reference point.
 - The emergency stop signal appears.
 - The servo alarm appears.

Reference point return deceleration signal

DECX (X017#0) DECY (X017#1) DECZ (X017#2) DECA (X017#3)

[Classification] Input signal

[Function] These signals decelerate the feedrate for manual reference point return to a low feedrate.

4.2 Reference point return check signal

2nd reference point permission signal

PREF20---PREF23 (G057#0---#3)

3rd reference point permission signal

PREF30---PREF33 (G058#0---#3)

4th reference point permission signal

PREF40---PREF43 (G059#0---#3)

[Type] Input signal

[Function] When the signal is set to 1, the reference point return completion signals(F42, F43, F44) are enabled.

These signals correspond separately to all axes.

PREF*0	X axis reference point check permission signal
PREF*1	Y axis reference point check permission signal
PREF*2	Z axis reference point check permission signal
PREF*3	A axis reference point check permission signal

2nd reference point return completion signal

ZP21---ZP24 (F042#0---#3)

3rd reference point return completion signal

ZP31---ZP34 (F043#0---#3)

4th reference point return completion signal

ZP41---ZP44 (F044#0---#3)

[Type] output signal

[Function] These signals report that the machine tool is at the reference point on a controlled axis.

These signals correspond separately to all axes

ZP*1	X axis reference point return completion signal
ZP*2	Y axis reference point return completion signal
ZP*3	Z axis reference point return completion signal
ZP*4	A axis reference point return completion signal

[Output conditions] the signal is enabled when it is the reference point check permission signals(G57, G58, G59) become 1.

When these signals becomes 1:

- Manual reference point return is completed and the current position is in the in-position area.
- The automatic reference point return(G30) is completed and the current position is in the in-position area.
- The reference point return check is completed and the current position is in the in-position area.
When the signal becomes 0:
- The reference point check permission signal (G57, G58,G59) become 0,
- The machine tool moves from the reference point.
- The emergency stop signal appears.
- The servo alarm appears.

4.3 Area check signal

Area check signal

AQ1—AQ3 (F045#0---#2)

[Type] Output signal

[Function] These signals report that the machine tool is at the reference point on a controlled axis.

These signals correspond separately to all axes.

AQ1	X axis area check signal
AQ2	Y axis area check signal
AQ3	Z axis area check signal

[Output conditions]

When the machine is in the stored travel check 1(the data parameter set **P66~P75** the limit, and outside the stored travel check 2 (the data parameter **P76~P8** or program command can set the limit of this side), the signal becomes 1, otherwise becomes 0.

Signal addresses

	#7	#6	#5	#4	#3	#2	#1	#0
F016					ZP4	ZP3	ZP2	ZP1
F042					ZP24	ZP23	ZP22	ZP21
F043					ZP234	ZP33	ZP32	ZP31
F044					ZP44	ZP43	ZP42	ZP41
F045						AQ3	AQ2	AQ1
G017					DECA	DECZ	DECY	DECX
G057					PREF23	PREF22	PREF21	PREF20
G058					PREF43	PREF32	PREF31	PREF30
G059					PREF43	PREF42	PREF41	PREF40

Reference point return deceleration signal check

DECX (G017#0) DECY (G017#1) DECZ (G017#2) DECA (G017#3)

[Classification] Input signal

[Function] These signals decelerate the feedrate for manual reference point return to a low feedrate.

Reference point establishment signal

ZRF1~ZRF4(F060#0~F060#3)

[Classification] Output signal

[Function] These signals report the system that the reference point has been established.

These signals correspond separately to all-axis.

ZRF1	No. X axis reference point establishment signal
ZRF2	No. Y axis reference point establishment signal
ZRF3	No. Z axis reference point establishment signal
ZRF4	No. A axis reference point establishment signal

[Output conditions] These signals become 1 when:

- The reference point has been established after manual reference point return.
- When the reference point is established using the absolute-position detector at initial power-on.

These signals become 0 when:

- The reference point is lost.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
F004			MREF					
F016					ZP4	ZP3	ZP2	ZP1
F060					ZRF4	ZRF3	ZRF2	ZRF1
G017					DECA	DECZ	DECY	DECX

Parameter

	#7	#6	#5	#4	#3	#2	#1	#0
0004								JAX

[Data Classification] bit

JAX Number of axes controlled simultaneously in JOG feed, manual rapid traverse and manual reference point return.

0: multi-axis

1: single axis

	#7	#6	#5	#4	#3	#2	#1	#0
0006								ZRNx

[Data type] bit-axis

ZRNx When a instruction specifying the movement(except for G28) is issued in automatic operation(MEM, RMT or MDI) before referencing is completed.
 1: An alarm is generated (P/S alarm 224).
 0: No alarm is generated.

Note: When the parameter is changed, the power supply must be turned off before operation and then is turned on again.

	#7	#6	#5	#4	#3	#2	#1	#0
0007	ZMI5	ZMI4	ZMIz	ZMIy	ZMIx			

[Data Classification] bit-axis
 ZMI Direction of reference point return
 0: positive direction
 1: negative direction

	#7	#6	#5	#4	#3	#2	#1	#0
0009						ZCL		

[Data Classification] Bit
 ZCL Local coordinate system after the manual reference point return is executed.
 0: The local coordinate system is not canceled.
 1: The local coordinate system is canceled.

Note: After setting the parameter, the power supply must be turned off, and the parameter will take effect after restart.

5 Automatic Operation

5.1 Cycle start/feed hold

General

Start of automatic Operation(cycle start) When automatic operation start signal ST is set to 1 then 0 while the CNC is in memory mode, DNC operation mode or MDI mode, the CNC enters the automatic operation start state then starts operating.

The signal ST is ignored as follows:

1. When the CNC is in other modes except for MEM, RMT or MDI mode.
2. When the feed hold signal (SP) is set to 1.
3. The emergency stop signal (ESP) is set to 1.
4. When <RESET> on MDI panel is pressed.
5. When CNC is in the state of alarm.
6. When the automatic operation is started.
7. When the program restart signal (SRN) is set to 1.
8. When CNC is searching one sequence number.

The CNC enters the feed hold state and stops operation in automatic operation as follows:

In automatic operation, the CNC enters the feed hold and stops running as follows:

1. When the feed hold signal (SP) is set to 1.
2. When the mode is changed to manual operation mode.

In automatic operation, the CNC enters the feed hold and stops running as follows:

1. The single block instruction is end when the single block is running.
2. MDI operation is completed.
3. CNC alarms.
4. The single block instruction is end after the mode is changed to others or Edit mode.

In automatic operation, the CNC enters the reset and stops running as follows:

1. When the emergency stop signal (ESP) is set to 1.
2. When <RESET> on MDI panel is pressed.

* Halt of automatic operation

(Feed hold)

When the feed hold signal SP is set to 1 in automatic operation, the CNC enters the feed hold state and stops operation. At the same time, cycle start lamp signal STL is set to 0 and feed hold lamp signal SPL is set to 1. Re-setting signal SP to 0 in itself will not restart automatic operation. To restart automatic operation, first set signal SP to 0, then set signal ST to 1 and to 0.

When signal SP is set to during the execution of a block containing only the M, S, T function, signal STL is immediately set to 0, signal SPL is set to 1, and the CNC enters the feed hold state. If the FIN

signal is subsequently set from the PLC, the CNC executes processing up until the end of the block that has been halted. Upon the completion of that block, signal SPL is set to 0 (signal STL remains set to 0) and the CNC enters the automatic operation stop state.

1. Thread cutting

In the thread cutting, when the signal SP is set to 0, CNC enters the feed pause after the signal SP is set to 0.

In G92 (thread cutting cycle), SP signal is set to 0, SPL signal immediately becomes 1 but the operation is continuously executed till the tool retraction is completed after the thread cutting.

In G32(thread cutting), SP signal is set to 0, SPL signal immediately becomes 1 but the operation is continuously executed till the non thread cutting block is completed after the thread cutting block.
2. Tapping in canned cycle

In G84 (canned cycle tapping) SP signal is set to 0, SPL signal immediately becomes 1. But the operation is continuously executed till the tool returns to the starting point or R point after the tapping is completed.
3. A macro instruction is being executed

Operation stops after the currently executing macro instruction has been completed.


Signal Cycle start signal

ST (G023#6)

[Type] Input signal

[Function] Start the automatic operation.

[Operation] When signal ST is set to 1 then 0 in automatic operation(Auto), DNC and MDI mode, the CNC enters the cycle start state and starts operations.




Feed hold signal

SP (G023#7)

[Classification] Input signal

[Function] Halt the automatic operation

[Operation] In Auto mode, SP signal is set to 1, CNC enters the feed hold and stops running. When SP signal is set to 0, the automatic operation does not start.



Cycle start lamp signal

STL (F000#5)

[Classification] Output signal

[Function] The signal reports PLC that the automatic operation start is entered.

[Output conditions] The signal is set to 1 or 0, which is determined by CNC state as Fig. 5.1.

Feed hold lamp signal

SPL (F000#4)

[Classification] Output signal

[Function] The signal reports PLC that the feed hold is entered.

[Output conditions] The signal is set to 1 or 0, which is determined by CNC state as Fig. 5.1.

Automatic operation signal

OP (F000#7)

[Classification] Output signal

[Function] The signal reports PLC that the automatic operation is entered.

[Output conditions] The signal is set to 1 or 0, which is determined by CNC state as Fig. 5.1.

Table 5.1

	Cycle start lamp STL	Feed hold lamp SPL	Automatic operation lamp OP
Cycle start	1	0	1
Feed hold	0	1	1
Automatic operation	0	0	0
Reset	0	0	0

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G023	SP	ST						
F000	OP		STL	SPL				


5.2 Reset

General CNC is reset and enters the reset state.

1. When the emergency signal (ESP) is set to 1.
2. When <RESET> on MDI panel is pressed.

When the CNC is reset, the resetting signal RST is output to the PLC. The resetting signal RST is set to 0 when the resetting signal output time, set by No. 203, has elapsed after the above conditions have been released.

$$RST = T_{\text{reset}} (\text{Reset processing time}) + \text{parameter setting value by No. 203}$$



When the CNC is reset in automatic operation, the automatic operation is stopped and movement axis is decelerated and stopped. When the CNC is reset during the execution of the M, S, T function, signal MF, SF or TF is set to 0 within 16ms.

RST (F001 #1)

[Classification]

Output signal

[Function]

The signal reports PLC that CNC is reset.

[Output conditions]

The signal is set to 1 when:

- 1: When the emergency stop signal (ESP) is set to 1.
- 2: When <RESET> on MDI panel is pressed.

The signal is set to 0 when:

When the reset signal output time set by No. 203# is completed after the above are released and CNC is reset.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
F001							RST	

5.3 Testing a program

General Before machining is started, the automatic running check can be executed. It checks whether the established program can operate the machine as desired. This check can be accomplished by running the machine or view the position display change without running the machine.

5.3.1 Machine tool lock

General The change of the position display can be monitored without moving the machine.

When all-axis machine lock signal MMLK is set to 1, output pulses to the servo motors are stopped in manual or automatic operation. The instructions are distributed, however, updating the absolute and relative coordinates. The operator can therefore check if the instructions are correct by monitoring the position display.

all-axis machine lock signal

MMLK (F004#1)

[Classification] Output signal

[Function] The signal reports PLC of the state of all-axis machine tool lock signal.

[Output condition] When the signal is set to 1, all-axis machine tool lock signal is set to 1.

When the signal is set to 0, all axes machine tool lock signals are set to 0.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
F004							MMLK	

5.3.2 Dry run

General Dry run is valid only for automatic operation. The machine moves at a constant feedrate regardless of the feedrate specified in the program. The feedrate is set by P86.

This function is used to check the movement of the machine without a workpiece.

Signal Dry run signal

DRN (G021#2)

[Classification] Input signal

[Function] Enables dry run.

[Operation] When the signal is set to 1, the machine tool moves at the feedrate specified for dry run.

When the signal is 0, the machine tool normally moves.

Caution:

When the dry run signal is changed from 0 to 1 or 1 to 0 during the movement of the machine, the feedrate of the machine is first decelerated to 0 before being accelerated to the specified feedrate.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G021						DRN		

5.3.3 Single block

General The single block operation is valid in automatic operation mode (Auto mode).
 When the single block signal (SBK) is set to 1 during automatic operation, the CNC enters the automatic operation stop state after executing the current block. In subsequent automatic operation, the CNC enters the automatic operation stop state after executing each block in the program. When the single block signal (SBK) is set to 0, normal automatic operation is stored.

Signal **Single block signal**

SBK (G021 #1)

- [Classification] Input signal
- [Function] Enables single block operation.
- [Operation] Execute the single block when the signal is set to 1.
 Execute the normal operation when the signal is set to 0.

Single block check signal

MSBK (F004 #3)

- [Classification] Output signal
- [Function] The signal reports PLC of the state of single block signal.
- [Operation] The signal is set to 1 as follows:
 ——When the single block signal SBK is set to 1.
 The signal is set to 0 as follows:
 ——When the single block signal SBK is set to 0.

Note:

1. Operations in thread cutting
 When the SBK signal becomes 1 in thread cutting, the operation stops after the first non-thread cutting signal after thread cutting instruction.
2. Operation in canned cycle
 When the SBK signal becomes 1 during canned cycle operation, the operation stops at each positioning, approach, drilling and retraction instead of the end of the block. The SPL signal becomes 1 while the STL signal becomes 0, showing that the end of the block has not been reached. When the execution of one block is completed, the STL and SPL signals become 0 and the operation is stopped.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G021							SBK	
F004					MSBK			

5.4 Optional block skip

General When a slash followed by a number is specified at the head of a block, and optional block skip signal BDT is set to 1 during automatic operation, the block

is ignored.

Signal Skip optional block signal
BDT (G021#0)
 [Classification] Input signal
 [Function] Select whether a block with “/” is neglected.
 [Operation] During automatic operation, when BDT is 1, the block with “/” is neglected.
 The program is normally executed when BDT is 0.

Optional block skip check signal

MBDT (F004#0)
 [Classification] Output signal
 [Function] The signal reports PLC of the state of skip optional block BDT.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G021								BDT
F004								MBDT

5.5 Program restart

General A program may be restarted at a block by specifying the sequence number of the block, after automatic operation is stopped because of a broken tool or for holidays.

Signal Program restart signal
SRN<G021#6>
 [Classification] Input signal
 [Function] Select the program restart
 [Operation] When the program restart signal is set to 1 to search for the sequence number of the block to be restarted, the CRT screen changed to the program restart screen. When the program restart signal is set to 0, and automatic operation is activated, the machine moves back to the machining restart point at dry run speed along the axes one by one. When the machine moves to the restart point, machining restarts.

Signal during program restart

SRNMV<F002#4>
 [Classification] Output signal
 [Function] Report the program is started.
 [Output conditions] The signal becomes 1 when:
 —When G21#6 is 1 in automatic mode, the program restarting signal is set to 1.
 The signal becomes 0 when ::
 —The program restart sequence ends(all controlled axes of machine tool moves to the restart point).

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G021		SNR						
F002				SRNM				

6 Feedrate Control

6.1 Rapid traverse rate

General F0, 25%, 50%, 100%
 F0 : it is set by the data parameter P93.

Signal **Rapid traversing signal**

RPDO (F002#1)

[Classification] Output signal

[Function] This signal indicates that a move instruction is executed at rapid traverse.

[Output conditions] 1: indicates that an axis starts moving after rapid traverse has been selected.

0: indicates that an axis starts moving after a feedrate other than rapid traverse has been selected. This hold true for both automatic and manual operation modes.

Note:

1. The rapid traverse during automatic operation includes all rapid traverses during canned cycle positioning, automatic reference point return, etc., as well as the move instruction G00. the manual rapid traverse also includes the rapid traverse during reference point return.
2. Once rapid traverse has been selected, this signal remains “1”, including during a stop, until another feedrate has been selected and movement is started.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
F002							RPDO	

6.2 Feedrate override

General A programmed feedrate can be reduced or increased by a percentage selected by the override dial. This feature is used to check a program. For example, when a feedrate of 100 mm/minute is specified during the program, setting the override dial to 50% move the tool at 50 mm/min.

Signal Feedrate positive override signal (G24#0)

Feedrate negative override signal (G24#2)

[Classification] Input signal

[Function] Cutting feedrate override signal. 16 steps (0%~150%).

[Operation] Actual feedrate is obtained by multiplying the specified speed by the

override value selected by this signal.

6.3 Override cancel

General The override cancel signal fixes the feedrate override to 100%.

Signal Override cancel signal

OVC (G024#1)

[Classification] Input signal

[Function] The feedrate override is fixed to 100%.

[Operation] When the signal is 1, CNC operates as follows:

- The feedrate override is fixed to 100% irrespective of the feedrate override signal.
- Rapid traverse override and spindle speed override are not affected.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G024							OVC	

7 Auxiliary Function

7.1 Miscellaneous function (M code)

General * miscellaneous function (M code) When the M code is specified, the code signal (F26~F33) and strobe signal are transmitted to PLC which use these signals to start or cut off its relative functions.

Basic procedure

The following signals are used for the following functions.


Function	Program address	Output signal			Completion signal
		Code signal	Strobe signal	Distribution completion signal	
MF	M	M**		DEN	FIN

- (1) Suppose that MXXX is specified during a program:
If XXX is not specified, CNC alarms.
- (2) After M00~M399 is transmitted to machine interface, the strobe signal MF is set to 1. The code signal is the binary representation of the programmed value XXX.
If a move, dwell, spindle speed, or other function is specified during the same block as the miscellaneous function, the execution of the other function is started when the code signal of the miscellaneous function is transmitted.
- (3) When the strobe signal is set to 1, the PLC reads the code signal and performs the corresponding operation.
- (4) To execute an operation after the completion of the move, dwell or other function specified during the block, wait until distribution end signal DEN is set to 1.
- (5) Upon completion of the operation, the PLC set completion signal FDURING to 1. The completion signal is used by the miscellaneous function, spindle speed function, tool function. If any of these functions are executed simultaneously, the completion signal must be set to 1 upon completion of all the function.
- (6) If the completion signal remains set to 1 for a long time, the CNC sets the strobe signals to 0 and reports that the completion signal has been received.
- (7) When the strobe signal is 0, the FDURING signal is set to 0.
- (8) When the FDURING signal is 0, all code signals are set to 0 and all sequence operations of miscellaneous function is completed.
- (9) CNC executes the next block when other instruction has been completed during the same block.
 1. When the tool function is executed, the programmed tool number is transmitted S code, T code.
 2. When the spindle speed function, tool function is executed, the code signal is maintained until a new code for the corresponding function is specified.


Time sequence is as follows:

There is one miscellaneous function during a block.

Move instruction and the miscellaneous function during the same block. Execution of a miscellaneous function without waiting for move instruction completion:



Move instruction and a miscellaneous function during the same block. Execution of a miscellaneous function after move instruction completion:



Signal Miscellaneous function code signal
M00~M99 (F030~F033)
Miscellaneous function strobe signal
MFEFD (F007#0)
 [Classification] Output signal
 [Function] These signals report PLC the specification of miscellaneous function.
 [Output conditions] For relative output conditions and procedure, see Basic Procedure .

Note:

1. The following miscellaneous functions are only processed during CNC: they are not output when programmed.
 - * M98, M99, M198
 - * M codes for calling subprograms
 - * M codes for call during customer macro programs
2. Decode signals as well as the code signals and strobe signal are output for the miscellaneous function listed below.
M00, M01, M02, M30
3. M00~M39 with binary output to M code.
For example: M5 corresponds to 00000000, 00000000, 00000000, 00000101.

M decode signal**DM00 (F009#7)****DM01 (F009#6)****DM02 (F009#5)****DM30 (F009#4)**

[Classification] Output signal

[Function] These signals report particular miscellaneous functions are specified. The miscellaneous functions during a instruction program correspond to output signals as reported below.

Instruction	Output signal
M00	DM00
M01	DM01
M02	DM02
M30	DM30

[Output conditions] A decode M signal is 1 when:

- The corresponding miscellaneous function is specified, and any move instructions and dwell instructions specified during the same block are completed. These signals are not output when the end signal of the miscellaneous function is returned before completion of such move instructions and dwell instructions.

A decode M signal is 0 when:

- FDURING signal becomes 1.
- Reset.

Spindle speed code signal**S00~S31 (F022~F025)****Spindle speed strobe signal****TF (F007#2)**

[Classification] Output signal

[Function] These signals report the spindle speed functions have been specified.

[Output conditions] For the output conditions and procedure, see Basic Procedure.

Output with S code of analog spindle.

Note: Binary S00~S31 outputs to S code.

For example, S4 corresponds to 00000000, 00000000, 00000000, 00000100.

Tool function code signal

T00~T31 (F026~F029)

Tool function strobe signal

BF (F007 #3)

[Classification] Output signal

[Function] These signals report that tool function have been specified.

[Output conditions] For the output conditions and procedure, see Basic Procedure.

Note: Binary T00~T31 outputs to T code.

For example, T corresponds to 00000000, 00000000, 00000000, 00000011.

Miscellaneous function completion signal

FIN (G000 #0)

[Classification] Input signal

[Function] The signal reports the completion of miscellaneous function, spindle speed function and tool function.

[Operation] When the signal becomes 1, for the control unit operation and procedure, see Basic Procedure.

Warning Only one end signal is used for all functions above. The end signal must go “1” after all function are completed.

Distribution end signal

DEN (F001 #3)

[Classification] Output signal

[Function] The signal reports that all instructions are completed except those miscellaneous functions, spindle speed function, tool functions are contained during the same block and have been transmitted to PLC. They also report that the end signal from the PLC is being waited.

[Output conditions] DEN signal is 1 with the following conditions:

Waiting for the completion of miscellaneous functions, spindle speed functions, tool functions and all other instructions during the same block are completed.

DEN signal is 0 when:

The execution of one block is completed.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G000								FIN
F001					DEN			
F007					TF	SF		MF
F009	DM00	DM01	DM02	DM30				
F030	M07	M06	M05	M04	M03	M02	M01	M00
F031	M15	M14	M13	M12	M11	M10	M09	M08
F032	M23	M22	M21	M20	M19	M18	M17	M16
F033	M31	M30	M29	M28	M27	M26	M25	M24

F022	S07	S06	S05	S04	S03	S02	S01	S00
F023	S15	S14	S13	S12	S11	S10	S09	S08
F024	S23	S22	S21	S20	S19	S18	S17	S16
F025	S31	S30	S29	S28	S27	S26	S25	S24
F026	T07	T06	T05	T04	T03	T02	T01	T00
F027	T15	T14	T13	T12	T11	T10	T09	T08
F028	T23	T22	T21	T20	T19	T18	T17	T16
F029	T31	T30	T29	T28	T27	T26	T25	T24

7.4 Auxiliary function lock

General Inhibits execution of a specified M, S, and T function. That is, code signals and strobe signals are not issued. This function is used to check a program.

Signal Auxiliary function lock signal

AFL (G021 #3)

[Classification] Input signal

[Function] The signal selects the auxiliary function lock, i.e., the signal disables the execution of the specified M, S, T function.

[Operation] When the signal becomes 1, the control unit functions are as follows:

1. The control unit does not execute M, S, and T functions. That is, the control unit stops the output of code signals and strobe signals.
2. If this signal becomes "1" after code signal output, the output operation is executed during the ordinary manner until its completion(that is, until the FDURING signal is received, and the strobe signal becomes to "0".)
3. Among the miscellaneous function, M00,M01, M02 and M30 are executed even when this signal is "1". All code signals, strobe signals, decode signals are output during the ordinary manner.
4. Even when this signal is "1", M98 and M99 are executed during the control unit without outputting their execution results are executed during the ordinary manner.

Warning Even when this signal is "1", spindle analog output or spindle serial output is executed.

Auxiliary function lock check signal

MAFL (F004 #4)

[Classification] Output signal

[Function] The signal reports the state of auxiliary function lock signal AFL.

[Output conditions] When the signal is 1, the auxiliary function lock signal AFL is 1.
When the signal is 0, the auxiliary function lock signal AFL is 0.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G021					AFL			
F004				MAFL				

8 Spindle Speed Function

8.1 Spindle speed control mode


General For 218M system, the spindle is divided into gear spindle and analog spindle:

1. During gear spindle mode, CNC changes S code to switch value to output to the spindle to control the spindle speed.
2. During analog spindle, changes S code to analog value to output to the spindle to control the spindle speed. CNC transmits SIMSPL signal to report PLC the current CNC the mode of controlling spindle.

Spindle enable signal
ENB<F001#4>

The output signal related to the spindle control is the spindle enable signal ENB. When non-zero instruction outputs to the spindle, ENB signal is logic 1; if the instruction is 0, ENB signal becomes 0.

When the analog spindle is used and the instruction to the spindle is 0 (analog voltage), the spindle motor will rotate with the low speed because there is the drift voltage for the spindle speed amplifier. And so, the ENB signal can be used to completely stop motor.



8.1.1 Gear spindle

General The gear spindle is defined that the spindle S code is controlled by I/O point.

Signal Spindle speed code signal

TF (F007#2)

Gear spindle address signal

F22#0~F22#7

[Classification] Output signal

[Function] These signals report the actually specified the spindle speed function.

[Output conditions] For the output conditions and procedure, see “7.2 S code I/O control”.

Note: S code range: S0~S7, the system alarms if it exceeds the range, S0~S7 separately corresponds to F address signal F22#0#7. (For example, S1 corresponds to F22#1 of F address signal)

8.1.2 Analog spindle

General The analog spindle is defined that the spindle speed is controlled by the analog voltage value from CNC. So, CNC changes S code into the analog voltage value to output to the spindle of machine tool to control the spindle speed.

1. The actual output analog voltage value equals to the S value controlled by the spindle multiplying the spindle override.
2. CNC still reports the speed by S00~S31 signal but SF signal does not output.

Signal Spindle positive override signal (**G22#5**)
 Spindle negative override signal (**G22#3**)
 Spindle override cancel signal OVC (**G22#4**)
 [Classification] Input signal
 [Function] The signal specifies the S override change controlled by spindle.

Note: The spindle override function is invalid as follows:
 Tapping cycle
 Thread cutting

Gear change process:

Although S instructions the spindle speed, the actual is to control the spindle motor. So, CNC needs to confirm the corresponding relation between the spindle motor and gear. Like S instruction selection, CNC selects the gear according to the previously defined gear speed range by parameter to report PLC to select the corresponding the gear by using the gear change select signal (GR3, GR2, GR1). At the same time, CNC outputs the spindle motor speed according to the selected gear. CNC outputs the instruction corresponded to the spindle (GR1, GR2, GR3 output) speed by specifying S0~S99999 during MDI mode. 2 or 3 speed gear (GR1, GR2, GR3) is set by No.246~248 to simultaneously output to the gear select signal. When the gear select signal is changed, CNC simultaneously output SF signal). Specification of gear change signal is as follows:

	No. 2 gear	No. 3 gear	Remark
GR1	Low	Low	Low: low gear
GR2	High	Medium	Medium: middle gear
GR3		High	High: high gear

When the instruction voltage is 10V, the low gear spindle speed is A (parameter No.246) (min⁻¹) .
 When the instruction voltage is 10V, the high gear spindle speed is B (parameter No.247) (min⁻¹ (middle gear during 3rd gear)) .
 When the instruction voltage is 10V, the high gear spindle speed is Ac (parameter No.248) (3rd gear) .
 S and spindle motor speed instruction the voltage (0~10V) and gear select signal. (GR1, GR2, GR3) is as the above figure.

Signal: Gear select signal
 GR1,GR2,GR3
 <F034#0~#2>
 [Classification] Output signal
 [Function] These signals report PLC the selected gear.
 [Output conditions] For the definition of these signals, see Gear change Mode.


Gear change select signal (input)
GR1,GR2,GR3<G002#0~#2>
 [Classification] Input signal
 [Function] These signals report CNC the current selected gear.
 [Output conditions] For the definition of these signals, see Gear change Mode.

GEAR<G002#4>

9 Programmng Instruciton

9.1 Custom macro program

General Although subprograms are useful for repeating the same operation, the custom macro function also allows use of variables, arithmetic and logic operations, and conditional branches for easy development of general programs. A machining program can call a custom macro with a simple instruction, just like a subprogram.



This reports some function programmed by macro program can be taken as the general function.

i.e., the program can be written by the data variable(variable data or unknown data. For example, the custom program can be used for technology.

Signal Custom macro program input signal

UI000~UI015 (G054, G055)

[Classification] Input signal

[Function] The signals do not provide any functions for the control unit. These signals which are taken as one of system variable is read by macro program, used for the interface signal between macro program and PLC

The system variable corresponding to these signals are as follows:

Signal	Address	Variable
UI000	G54#0	#1000
UI001	G54#1	#1001
UI002	G54#2	#1002
UI003	G54#3	#1003
UI004	G54#4	#1004
UI005	G54#5	#1005
UI006	G54#6	#1006
UI007	G54#7	#1007
UI008	G55#0	#1008
UI009	G55#1	#1009
UI010	G55#2	#1010
UI011	G55#3	#1011

UI012	G55#4	#1012
UI013	G55#5	#1013
UI014	G55#6	#1014
UI015	G55#7	#1015
UI000~ UI015	G54, G55	#1032

Note: #1032 is variable with 16-bit as follows:

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
# 1032	UI007	UI006	UI005	UI004	UI003	UI002	UI001	UI000
# 1032	UI015	UI014	UI013	UI012	UI011	UI010	UI009	UI008

**Custom macro program output signal
UO000~UO015**

(F054~F055)

UO100~UO131

(F056~F059)

[Classification] Output signal

[Function] The signals do not provide any functions for the control unit. These signals which are taken as one of system variable are read/written by macro program, used for the interface signal between macro program and PLC.

The system variable corresponding to these signals are as follows:

Signal	Address	Variable
UO000	F54#0	#1100
UO001	F54#1	#1101
UO002	F54#2	#1102
UO003	F54#3	#1103
UO004	F54#4	#1104
UO005	F54#5	#1105
UO006	F54#6	#1106
UO007	F54#7	#1107
UO008	F55#0	#1108
UO009	F55#1	#1109
UO010	F55#2	#1110
UO011	F55#3	#1111
UO012	F55#4	#1112
UO013	F55#5	#1113
UO014	F55#6	#1114
UO015	F55#7	#1115
UO000~ UO015	F54, F55	#1132
UO100~ UO115	F56~F59	#1133

Note:

1132 is a variable with 16-bit.

1133 is a variable with 32-bit.

Composition is as follows:


	#7	#6	#5	#4	#3	#2	#1	#0
# 1132	UO007	UO006	UO005	UO004	UO003	UO002	UO001	UO000
# 1132	UO015	UO014	UO013	UO012	UO011	UO010	UO009	UO008
# 1133	UO107	UO106	UO105	UO104	UO103	UO102	UO101	UO100
# 1133	UO115	UO114	UO113	UO112	UO111	UO110	UO109	UO108
# 1133	UO123	UO122	UO121	UO120	UO119	UO118	UO117	UO116
# 1133	UO131	UO130	UO129	UO128	UO127	UO126	UO125	UO124

9.2 Canned cycle

General Canned cycles make it easier for the programmer to create programs. With a canned cycle, a frequently-used machining operation can be specified during a single block with a G function; without canned cycles, normally more than one block is required. During addition, the use of canned cycles can shorten the program to save memory. One canned cycle consists of a sequence of six operations:

- Operation 1: Positioning a hole
- Operation 2: Rapid traverse up to R level
- Operation 3: Hole machining
- Operation 4: Operation at the bottom of a hole
- Operation 5: Retraction to point R level
- Operation 6: Rapid traverse up to the initial point

Operation sequence of canned cycle is as follows:



The following canned cycles require spindle control:

- Reverse tapping cycle G74)
- Tapping cycle G84
- Back boring cycle G87
- Fine boring cycle G76)
- Boring cycle G86
- Boring cycle G88

For spindle control, the following normal miscellaneous functions are used:
See the description of the miscellaneous functions.

- M03: CW spindle rotation
- M04: CCW spindle rotation
- M05: Spindle stop
- M19: Spindle orientation

When the rotation direction of the spindle is to be switched from one direction to the other (for example, when M04 is output during M03 operation), a parameter can be specified whether to send M05 at the time switching).

- Tapping signal During the tapping cycle, output the tapping signal. When the tapping cycle G code is valid, CNC also outputs the tapping signal.
- Override During the tapping, the cutting feedrate override is always set to 100%.
- Feed hold During the tapping, the traverse does not stop immediately when the feed hold is pressed down. But it stops when the tool returns to R level.
- Dry run TDR (parameter 12#5) defines if the dry run is valid during the tapping.

Signal Tapping signal

TAP<F001 #5>

[Classification] Output signal

[Function] The signal reports CNC is during tapping mode.

[Output conditions] The signal is 1:

- CNC is during the tapping cycle mode G74, G84.
- CNC is during the tapping cycle mode G63. the signal is set to 0:
- CNC is not tapping cycle and tapping mode.
- The reset or emergency stop signal is input.

Signal address:

	#7	#6	#5	#4	#3	#2	#1	#0
F001			TAP	D TAP				

10 Display/Set

10.1 Clock Function

General Time is displayed during the hour/minute/second format on set screen.
The custom macro system variable can be used to read the time.
Time report can be read and written.

10.2 Displaying operation history

General This function displays a history of the key stroke and signal operations, performed by the CNC operator, when a failure or CNC alarm occurs.

10.3 Help function

General The help function displays on the screen detailed report about alarms issued during the CNC and about CNC operations. The screen displays detailed information about the alarms and how to recover from them. The detailed information is displayed only for a limited number of P/S alarms. These alarms are often misunderstood and are rather difficult to understand.

11 Measurement

11.1 Skip function

General Linear interpolation can be commanded by specifying axial following the G31 instruction, like G01. If an external skip signal is input during the execution of this instruction, execution of the instruction is halted and the next block is executed. The skip function is used when the end of machining is not programmed but specified with a signal from the machine, for example, during grinding. It is used also for measuring the dimensions of a workpiece.

The coordinate values when the skip signal is turned on can be used during a custom macro because they are stored during the custom macro system variable #5061~#5068, as follows:

#5061 1st axis coordinate value
 #5062 2nd axis coordinate value
 #5063 3rd axis coordinate value

:

Signal **Skip signal**
SKIPP <G001#1>

[Classification] Input signal

[Function] This signal terminates skip cutting. That is, the position where a skip signal turns to “1” during a block containing G31 is stored during a custom macro variable, and the move instruction of the block is terminated at the same time.

[Operation] When a skip signal turns to “1”, the control unit works as described

below.

- When a block contains a skip cutting instruction G31, the control unit reads and stores the current position of the specified axis at that time. The control unit stops the axis, then cancels the remaining distance that the block was supposed to be moved.
- The skip signal is monitored not for a rising edge, but for its state. So, if a skip signal continues to be “1”, a skip condition is assumed to be satisfied immediately when the next skip cutting is specified.

Note:

The skip signal width requires at least 10ms.

Signal address

G001							SKIPP	
------	--	--	--	--	--	--	-------	--

12 Panel locked setting

Signal **Lock edit signal**

LEDT (G016#6)

[Type] Input signal

[Function] The signal locks the press key on the edit panel.

[Operation] When the signal is set to 1, all keys on the panel are locked and disenabled.

When the signal is set to 0, all keys on the panel are enabled.

Lock machine signal

LSYS (G016#7)

[Type] Input signal

[Function] The signal locks the press key on the machine panel.

[Operation] When the signal is set to 1, all keys on the panel are locked and disenabled.

When the signal is set to 0, all keys on the panel are enabled.

Signal address

	#7	#6	#5	#4	#3	#2	#1	#0
G016	LSYS	LEDT						

Appendix

Signal list (During order of address)

Addresses between PLC and CNC

1. CNC→PLC address: F000 ---- F064

Signal name	Symbol	Address
Feed hold alarm signal	SPL	F000#4
Cycle start alarm signal	STL	F000#5
Servo ready completion signal	SA	F000#6
Automatic operation signal	OP	F000#7
Alarm signal	AL	F001#0
Resetting signal	RST	F001#1
Tapping signal	TAP	F001#5
Tapping in process signal	D TAP	F001#6
Thread cutting signal	THRD	F002#3
Program start signal	SRNMV	F002#4
Cutting feed signal	CUT	F002#6
Dry run check signal	MDRN	F002#7
Incremental feed select check signal	MINC	F003#0
MPG feed select check signal	MH	F003#1
JOG feed select check signal	MJ	F003#2
Manual data input select check signal	MMDI	F003#3
DNC operation selection confirm signal	MRMT	F003#4
Automatic operation select check signal	MMEM	F003#5
Memory edit select check signal	MEDT	F003#6
Machine zero return select check signal	MZRO	F003#7
Skip optional block check signal	MBDT	F004#0
All-axis machine lock check signal	MMLK	F004#1
Single block check signal	MSBK	F004#3
Auxiliary function lock signal	MAFL	F004#4
Manual reference point return check	MREF	F004#5
Feedrate override OFF check signal	CFORD	F005#0
Spindle override OFF check signal	CSORD	F005#1
M function strobe signal	MFEFD	F007#0
S function strobe signal	TF	F007#2
T function strobe signal	BF	F007#3
Decode M signal	DM30	F009#4
	DM02	F009#5
	DM01	F009#6
	DM00	F009#7
Axis moving direction signal	MV1 --- MV5	F017
Axis moving direction signal	MVD1 --- MVD5	F019
Spindle speed code signal	S00 --- S31	F22#0---#7
Miscellaneous function code signal	M**	F026 --- F033 (see III Operation 3.5)
Gear select signals	GR1,GR2,GR3	F034#0 --- #2
2nd reference point return completion signals		F042#0---#3
3rd reference point return completion signals		F043#0---#3

4th reference point return completion signals		F044#0---#3
Area check signals		F045#0---#2
Customer macro program output signal	U000 --- U015 U100 --- U131	F054,F055 F056 --- F059
Reference point establishment signal	ZRF1 ---- ZRF5	F060

2. PLC→CNC address: G000 ----- G064

Signal name	Symbol	Address
Miscellaneous function completion signal	FIN	G000#0
M function completion signal	MFIN	G000#1
S function completion signal	SFIN	G000#4
T function completion signal	TFIN	G000#5
Emergency stop signal	*ESP	G001#0
Skip signal	SKIPP	G001#1
Interlock signal	*IT	G001#2
Reset signal	RST	G001#3
Gear select signal (input)	GR1,GR2, GR3	G002#0 --- #2
Gear change completion signal	GEAR	G002#4
Rigid tapping signal	RGTAP	G003#1
Overtravel signal	*+L1 --- *+L5 *-L1 ---- *-L5	G012#0 ---- #4 G013#0 ---- #4
Edit lock signal	LEDT	G016#6
Operator panel lock signal	LSYS	G016#7
Zero return deceleration signal check		G017#0 ---- #4
Zero return completion signal check		G018#0 ---- #4
Edit mode		G20.0
Auto mode		G20.1
MDI mode		G20.2
Zero return mode		G20.3
Step mode		G20.4
Manual mode		G20.5
MPG mode		G20.6
DNC mode		G20.7
Skip		G21.0
Single block		G21.1
Dry run		G21.2
Auxiliary lock		G21.3
Machine lock		G21.4
Optional stop		G21.5
Program restart		G21.6
Spindle override(-)		G22.3
Spindle override OFF		G22.4
Spindle override (+)		G22.5
Spindle JOG		G22.6
Cycle start		G23.6
Feed hold		G23.7
Feedrate override (+)		G24.0
Feedrate override OFF		G24.1
Feedrate override (-)		G24.2
Rapid switch		G24.7
Rapid Fo		G25.0
Rapid 25%		G25.1
Rapid 50%		G25.2
Rapid 100%		G25.3
Incremental step length 0.001		G26.0
Incremental step length 0.01		G26.1
Incremental step length 0.1		G26.2
Incremental step length 1		G26.3

MPG step length 0.001		G26.4
MPG step length 0.01		G26.5
MPG step length 0.1		G26.6
Manual feed axis +X		G27.0
Manual feed axis +Y		G27.1
Manual feed axis +Z		G27.2
Manual feed axis +Th4		G27.3
Manual feed axis +Th5		G27.4
Manual feed axis -X		G28.0
Manual feed axis -Y		G28.1
Manual feed axis +Z		G27.2
Manual feed axis +Th4		G27.3
Manual feed axis +Th5		G27.4
Manual feed axis -X		G28.0
Manual feed axis -Y		G28.1
Manual feed axis +Z		G27.2
Manual feed axis +Th4		G27.3
Manual feed axis +Th5		G27.4
Manual feed axis -X		G28.0
Manual feed axis -Y		G28.1
Manual feed axis -Z		G28.2
Manual feed axis -Th4		G28.3
Manual feed axis -Th5		G28.4
Spindle orientation		G29.0
Overtravel release		G30.0
User macro program interruption signal	UINT	G031#1
User macro program input signal	UI000 --- UI015	G054,G055
2 nd reference point check permission signal	PREF20----PREF23	G057#0 ----- #3
3 rd reference point check permission signal	PREF30----PREF33	G058#0 ----- #3
4 th reference point check permission signal	PREF40----PREF43	G059#0 ----- #3

III Operation

1 PLC Window Display

1.1 Automatic operation when GSK218M PLC power on

When PLC includes the enabled sequence program, it starts immediately the automatic operation by the setting of the keep relay after power on. PLC screen are not needed to display every power-on to execute the sequence program.

Note: The keys during < > are the panel; the ones in **【 】** are the soft keys; **【 】** is the window corresponding the current soft key; **◆** reports there is the sub-menu during the menu; all operations during PCL are executed during MDI mode and only view and search can be executed during other modes.

1.2 INFO window display

1.2.1 INFO window

1. Press <INFO> key on the panel to enter the default INFOR window as Fig. 1-2-1. If the **【INFO】** soft key has not found on the below of the screen, the bit parameter No: N0: 26#6=1 can be defined to set the key on the PLC window, and then <INFO> is pressed to enter INFO window. There is the version number of GSK218M, modification data, PLC I/O interface definition state and so on INFO interface.




Fig. 1- 2- 1-1

4 soft keys on the below of the screw are 4 kind of information display window of PLC.

2. Press PageUp/PageDown in INFO window to enter the next window of INFO as follows:

```

PLCINFO                                     RUN
  MT NAME      :Ladder01
  VERSION      :
  VINDICATOR   : GSK Coder
  MODIFY DATE  : 2007-01-06 15: 54
  LADDER MAX ROW : 0803/1600 LEVEL 1 020 LEVEL 2 0783
  EXECUTE MAX ROW: 3055/4700 LEVEL 1 086 LEVEL 2 2969

Ladder00 105472
Ladder01 105472
Ladder04 0

DATA
MDI
【INFO】 【◆PLCGRA】 【◆PLCPAR】 【PLCDGN】 【PLCTRA】

```

Fig. 1-2-1-2

1. The system appears the ladder name which is running in the window. The ladder is divided into three: the ladder is the only one that is running, other 15 ladders in No.0-15 ladder besides the one is running, up to 4 ladders which can be editable or referred.(they can be named with 2-digit serial number except for 0-15).
2. When the system is turned on, the bit parameter 53#0~#3 setting value is the binary combination parameter, when the setting value is 0, No.0 ladder is used; when it is1~15, No. 0~15 parameter is used. After the system determines to load some ladder which is running (the operation maybe appear the danger, it is enabled after the system restarts). If the format is incorrect, the ladder is deleted to recreated, and the user needs to specify the running ladder No. carefully. Names of all ladder files must be with "ladderXX.grp" (XX is the serial number) , otherwise, the system does not identify the files. The file format is determined by the system, and the user cannot modify the file outside of the system, otherwise, the file maybe be deleted or cannot be identified.
3. When the system uses No. 0 ladder, M6 cannot call macro program, when uses No. 1~15 ladder, M6 separately call O91001~O91015 macro program.
4. Selecting ladder. Move the cursor or input "LX"/"LXX" (X/XX is number) to specify the file name, the system checks whether "X"/"XX" is the known file number after "Enter" is pressed, if the system has not checked it, it creates an ladder with the name "ladder0X.grp" or "ladderXX.grp" . The system automatically creates "END1" and "END2" to ensure that the user continuously operates the ladder file (if the open file does not convert, the INSTRUCTION list will be always empty) when the file is created. The user can copy or clip the ladder (it does not exceed 100 rows, otherwise the system only copy or clip the front 100 rows) which is normally opened, For security, after the system opens one file to edit, the system will automatically save the current file and then open another file, the system will execute the grammar check before saving, and will abandon the save after it finds out the error.
5. The ladder format has been adjusted, and the file head includes the basic information of file, such as row number, step number. The step information is the new one when it is converted. The user can delete the ladder which is not opened and is not running, which must be executed orderly. After the user opens the ladder which is not running, the system stops refreshing the ladder network information to avoid the mistake. The ladder which is running can be copied or saved to conveniently copy the content in the file to others, before the users edits the ladder which is running, it should be stopped. When the cursor

stops in the background edit file the user can press “Ctrl+CHG” to open Info to modify the edit file.

1.2.2 PLCGRA window

Press **【PLCGRA】** to enter **PLCGRA** window or define the bit parameter N0: 26#6=1 to press <INFO> key on the PLC window to enter **PLCGRA** window as Fig.1-2-2.

PLCGRA	Ln: 000/429	RUN
X001.4		G001.0
X000.0		G012.0
X000.1		G012.1
X000.2		G012.2
X000.3		G012.3
X000.4		G013.0
X000.5		G013.1
X000.6		G013.2
X000.7		G013.3
X001.0 G020.0 G020.4 G020.5 G020.6		G017.0
DATA	MEA Emergency switch	
		MDI
【INFO】	【◆PLCGRA】	【◆PLCPAR】
		【PLCDGN】
		【◆PLCTRA】

Fig. 1- 2- 2

Contents and operations on **PLCGRA** window:

Line: current line position specified by the cursor during the ladder

RUN: operation state of ladder

Diagram: ladder program

Data/serial number: displaying input data. The serial number appears by pressing <SEARCH> on the panel to search the data. The CNC returns to the data displaying window after press <CANCEL>.

MEA: Commentaries of element positioned by the cursor.

MDI mode: current operation mode(note: the ladder can be modified only during MDI mode).

Press the Page Up/Page Down, four Direction keys to search, view and modify the elements.

1.2.3 PLCPAR window

Press **【PLCGRA】** to enter **PLCPAR** window or define the bit parameter N0: 26#6=1 to press <INFO> key on the PLC window to enter **PLCPAR** window as Fig.1-2-3.

PLCPara	RUN							
ADDR	N.7	N.6	N.5	N.4	N.3	N.2	N.1	N.0
K000	0	0	0	0	0	0	0	0
K001	0	0	0	0	1	0	0	0
K002	0	0	0	0	0	0	0	0
K003	0	0	0	0	0	0	0	0
K004	0	0	0	0	0	0	0	0
K005	0	0	0	0	0	1	0	0
K006	0	0	0	0	0	0	1	1
K007	0	0	0	0	0	0	0	0
K008	0	0	0	0	0	0	0	0
K009	0	0	0	0	0	0	0	0
K010	0	0	0	0	0	0	0	0
K011	0	0	0	0	0	0	0	0
DATA	MDI							
【INFO】【◆PLCGRA】【◆PLCPAR】【PLCDGN】【◆PLCTRA】								

Fig. 1- 2- 3

Contents and operations on **PLCPAR** window:

RUN: operation state of ladder
 NO: parameter serial number
 ADDRESS: parameter address
 CURRENT: current value of parameter
 SET: preset value of parameter

Data/serial number: displaying input data. The serial number appears by pressing **<SEARCH>** on the panel to search the data. The CNC returns to the data displaying window after press **<CANCEL>**.

MDI mode: current operation mode(note: the relative parameter of PLCPAR can be modified only during MDI mode).

Press the Page Up/Page Down, four Direction keys to search, view and modify the elements.

1.2.4 PLCGND window

Press **【PLCGDN】** to enter PLCGND window or define the bit parameter N0: 26#6=1 to press **<INFO>** key on the PLC window to enter PLCGND window as Fig.1-2-4.

PLCDGN	RUN							
ADDR	N. 7	N. 6	N. 5	N. 4	N. 3	N. 2	N. 1	N. 0
F000	0	1	0	0	0	0	0	0
F001	0	0	0	0	1	0	0	0
F002	0	0	0	0	0	0	0	0
F003	0	0	0	0	0	0	0	0
F004	0	0	0	0	0	0	0	0
F005	0	0	0	0	0	0	0	0
F006	0	0	0	0	0	0	0	0
F007	0	0	0	0	0	0	0	0
F008	0	0	0	0	0	0	0	0
F009	0	0	0	0	0	0	0	0
F010	0	0	0	0	0	0	0	0
F011	0	0	0	0	0	0	0	0

NO.

MDI

【INFO】 【◆PLCGRA】 【◆PLCPAR】 【PLCDGN】 【◆PLCTRA】

Fig. 1- 2- 4

Contents and operations on **PLCGDN** window:

RUN: operation state of ladder

ADDR: : address of diagnosis number

N.0~N.7 : bit number state of diagnosis address. 1: the signal is connected; 0: the signal is not connected.

CURRENT: current value of parameter

SET: preset value of parameter

Data/serial number: displaying input data. The serial number appears by pressing <SEARCH> on the panel to search the data. The CNC returns to the data displaying window after press <CANCEL>.

MDI mode: current operation mode.

Press the Page Up/Page Down, four Direction keys to search the corresponding diagnosis number.

1.2.5 PLCTRA window

Press **【PLCTRA】** to enter PLCTRA window or define the bit parameter N0: 26#6=1 to press <INFO> key on the PLC window to enter PLCTRA window as Fig.1-2-5:




Fig. 1-2-5

Contents and operations on **PLCTRA** window:

RUN: operation state of ladder.

ADDR: address of diagnosis number.

0000 : bit number state of diagnosis address.

0016 : bit number state of diagnosis address. Sum by subtracting the previous data is Bit number state of diagnosis address on the screen.

Data: displaying input data. Input the required address. Diagnose the address, and cannot execute the input when the diagnosis is being executed. The serial number appears by pressing <SEARCH> on the panel to search the data. The CNC returns to the data displaying window after press <CANCEL>.

MDI mode: current operation mode.

Press the Page Up/Page Down, four Direction keys to search the corresponding diagnosis number.

2.1 General

GSK218M CNC PLC operations are performed during the corresponding windows.
 There are two windows:

1. PLCGRA window include: basic instruction, function instruction and instruction list.

Press **【PLCGRA】** to enter PLCGRA window as Fig. 1-2-2. Press **【PLCGRA】** to enter PLCGRA window as Fig. 2-2-1.

PLCGRA [ladder01]	001/810	RUN
X001.4		G001.0
X000.0		G012.0
X000.1		G012.1
X000.2		G012.2
X000.3		G012.3
X000.4		G013.0
X000.5		G013.1
X000.6		G013.2
X000.7		G013.3
X001.0 G020.0 G020.4 G020.5 G020.6		G017.0
DATA	MEA:Emergency switch	MDI
【◆B. INST】【F. INST】【◆REPERT】【◆EDIT】【RETURN】		

Fig. 2- 1- 1

2. PLCPAR window includes CTR, TMR, DATA, KPAR and MDEC.

Press **【PLCPAR】** to enter PLCRAR window as Fig. 1-2-3. Press **【PLCPAR】** to enter PLCRAR window as Fig. 2-1-2.

PLCPara	RUN							
ADDR	N.7	N.6	N.5	N.4	N.3	N.2	N.1	N.0
K000	0	0	0	0	0	0	0	0
K001	0	0	0	0	1	0	0	0
K002	0	0	0	0	0	0	0	0
K003	0	0	0	0	0	0	0	0
K004	0	0	0	0	0	0	0	0
K005	0	0	0	0	0	1	0	0
K006	0	0	0	0	0	0	1	1
K007	0	0	0	0	0	0	0	0
K008	0	0	0	0	0	0	0	0
K009	0	0	0	0	0	0	0	0
K010	0	0	0	0	0	0	0	0
K011	0	0	0	0	0	0	0	0
NO.								
								MDI
【KPAR】	【TMR】	【DATA】	【CTR】	【RETURN】	【▶】			

Fig. 2-1-2

2.2 Basic instruction(B. INST)

Press **【B. INST】** during Fig. 2-1-2 to enter the basic instruction operation window as Fig.2-2-1.

PLCGRA [ladder01]	001/810	RUN		
X001.4		G001.0		
X000.0		G012.0		
X000.1		G012.1		
X000.2		G012.2		
X000.3		G012.3		
X000.4		G013.0		
X000.5		G013.1		
X000.6		G013.2		
X000.7		G013.3		
X001.0 G020.0 G020.4 G020.5 G020.6		G017.0		
DATA	MEA:Emergency switch			
		MDI		
【◆B. INST】	【F. INST】	【◆REPERT】	【◆EDIT】	【RETURN】

Fig. 2-2-1

Press **【▶】** to display other basic instructions as Fig. 2-2-2.




Fig. 2-2-2

The basic instructions are divided into 7 kind of graphic display:

- 【 】 : normally open contact
- 【 】 : normally closed contact
- 【 】 : output coil
- 【 】 : output coil reversing
- 【 】 : horizontal conductive line
- 【 】 : vertical conductive line
- 【 】 : deleting a vertical conductive line

Auxiliary soft key:

- 【 】 : Page Down
- 【 】 : Page Up
- 【 Esc 】 : return to the previous menu.

2.3 Operations of ladder

Adding an element: position the cursor to the required, press the corresponding menu to input the element name, press **<ENTER>** to confirm the addition after it is displayed behind the data. If the current position has element, the new element will replace the previous one.

Inserting an element: position the cursor to the required, press **<INSERT>** to insert empty position, and then add the new element as the above method. The cursor can insert orderly. (Note: ensure the indicator above **<CTRL>** key is OFF when inserting element.)

Deleting an element: press **<DELETE>** to delete the current element and the following one will

orderly move forward(Note: ensure the indicator above <CTRL> key is OFF when deleting element.)

Adding a vertical conductive line: press  to add one vertical conductive line under the lower-right of current cursor position.

Deleting a vertical conductive line: press  to delete one vertical conductive line under the lower-right of current cursor position.

Adding a horizontal conductive line: press  to add one horizontal conductive line before the cursor position, if the current position has element, the horizontal conductive line replace the element.

Inserting a line: position the cursor to the any line of target line, press <CTRL>, and then press <INSERT> after the indicator above <CTRL> is ON, insert the blank line at the place above of the specified line by cursor, and the sequent line will orderly move down one line.

Deleting a line: position the cursor to the target line, press <CTRL>, and then press <DELETE> to delete the current line after the indicator above <CTRL> is ON, and the sequent line will orderly move up one line.

Deleting a block: position the cursor to the initial position which will be deleted, Input the address number of target block's coil, and last press <ALT>.

Copying a block: position the cursor to the block head(first contact of left busbar) which will be copied, press <M> and input the block end(address number of coil of right busbar), and last press <ALT>.

Copying a block: position the cursor to the block head(first contact of left busbar) which will be copied, press <T> and input the block end(address number of coil of right busbar), and last press <ALT>.

Pasting a block: position the cursor to the any line of target line, press <F>, and then press <ALT>.

Search: directly input the required element name, press  to search up and press  to search down after the data on screen is displayed,

Save: press <STORE> to save the modified ladder.

Ladder programming example:

1. position the cursor to the initial position of programming, press  and there is normally-open contact symbol at the cursor position, directly input the element name X1.4 and press <ENTER> and X001.4 appears at the current cursor position.
2. right move the cursor, press , and there is there is normally-open contact symbol at the cursor position, directly input the element name X2.1 and press <ENTER> and X002.1 appears at the current cursor position.
3. position the cursor to the initial position of next line, press , there is there is normally-open contact symbol at the cursor position, directly input the element name X2.4 and press <ENTER> and X002.4 appears at the current cursor position.
4. right move the cursor, press , and draw a horizontal conductive line at the current cursor position.

- up move the cursor, press **【↑】**, and draw a vertical conductive at the current cursor position.
- press **【—()】** and the system automatic create the output coil, namely the necessary horizontal conductive line. Directly input the element name G1.0, press **<ENTER>** and G001.0 appears at the current cursor position.

The programmed ladder is as Fig. 2-3-1:




Fig. 2-3-1 Ladder example

Note: The green element in the ladder is turned on no matter that it is normally-open and normally-closed or outputs the coil, and the white indicates it is turned off (owing to the printing, the dark stands it is turned off, and the light stands it is turned on.)

2.4 Function instruction

Press **【B. INST】** during Fig. 2-1-1 to enter the basic instruction operation window as Fig. 2-4-1.

PLCGRA [ladder01]	001/810	RUN
X001.4		G001.0
X000.0		G012.0
X000.1		G012.1
X000.2		G012.2
X000.3		G012.3
X000.4		G013.0
X000.5		G013.1
X000.6		G013.2
X000.7		G013.3
X001.0 G020.0 G020.4 G020.5 G020.6		G017.0
DATA	MEA:Emergency switch	MDI
【◆B. INST】【F. INST】【◆REPERT】【◆EDIT】【RETURN】		

Fig. 2-4-1

There are 30 PLC function instructions during the function instruction list. For the format and use of function instruction, see Programming.

2.5 Instruction list

Press **【B. INST】** during PLCGRA window as Fig.2-1-1 to enter the operation window of instruction classification as Fig. 2-5-1.

PLCREPER		0000/1263	RUN
NO.	REPER		
0000	RD	X001.4	
0001	WRT	G001.0	
0002	RD	X000.0	
0003	WRT	G012.0	
0004	RD	X000.2	
0005	WRT	G012.1	
0006	RD	X000.4	
0007	WRT	G012.2	
0008	RD	X000.6	
0009	WRT	G012.3	
0010	RD	X000.1	
0011	WRT	G013.0	
DATA			MDI
【 CONVERT		【 DOWN】	【 STOP】
			【 RETURN】

Fig. 2-5-1

Contents and operations of instruction list window:

Step: the step number and total step number of current ladder run

RUN: operation state of ladder

Data/serial number: displaying input data. The serial number appears by pressing <SEARCH> on the panel to search the data. The CNC returns to the data displaying window after press <CANCEL>.

MDI mode: current operation mode.

【CHANGE】: ladder is changed into instruction list.

【DOWNLOAD】: the instruction list is downloaded to CNC to automatically operation the PLC ladder.

【STOP】: stop ladder running.

【Esc】: return to the up menu.

Press the Page Up/Page Down, four Direction keys to search and position, view the instruction list address.

2.6 Edit instruction

PLCGRA [ladder01]	001/810	RUN
X001.4		G001.0
X000.0		G012.0
X000.1		G012.1
X000.2		G012.2
X000.3		G012.3
X000.4		G013.0
X000.5		G013.1
X000.6		G013.2
X000.7		G013.3
X001.0 G020.0 G020.4 G020.5 G020.6		G017.0
DATA	MEA:Emergency switch	
		MDI
【COPY】	【PASTE】	【DEL】
	【REPLACE】	【RETURN】

Contents and operations on instruction list window:

LINE: displaying the current position of cursor and total line number of ladder

RUN: operation state of ladder

Data/serial number: displaying input data. The serial number appears by pressing <SEARCH> on the panel to search the data. The CNC returns to the data displaying window after press <CANCEL>.

MDI mode: current operation mode.

【COPY】 : after inputting G12.1, press it and the ladder between the cursor and G12.1 can be copied.

【PASTE】 : paste the copied ladder.

【DELETE】 : after inputting G12.1, press it and the ladder between the cursor and G12.1 can be deleted.

【CHANGE】 : input the signal address needed to change, and press the key, the system prompts if the address is changed or all addresses are changed.

Y: YES; N: NOT; A: ALL

Press the Page Up/Page Down, four Direction keys to search and position, view the instruction list address.

2.7 PLC operation step

PLC operation step:

1. Press<Setting> and input the password in **【PASSWORD】** window.
2. In PLCPAR window, press **【KPAR】** to enter the viewing and setting window of keep relay, operate PLC by modifying the related bit of K000, K001. (setting K000.0 to 1

can modify the ladder after saving). For the definition of related bit, see Connection, Appendix K INSTRUCTION List.

3. In **【PLCGRA】** window, press **【INSTRUCTION】** to press **【STOP】**, the system stops the running ladder(the modified ladder is not the current, the step can be omitted).
4. In **【PLCGRA】** window, complete PLC programming by executing **【B. INST】**, **【FUNCTION INST】**、**【EDIT INST】**. Press <SAVE>, the data field prompts “SAVE SUCCEEDED!” . The corresponding PLC alarms during saving when PLC is mistaken, please check PLC program.
5. In PLCGRA window, press <CHANGE>, the data field prompts “CHANGING.....”, and “CHANGE SUCCEEDED!”.
6. In PLCGRA window, press <INSTRUCTION LIST>, then press **【DOWNLOAD】**, and the data field prompts “DOWNLOADING.....”, and “DOWNLOAD SUCCEEDED!”, The ladder is changed into instruction list to download to CNC and automatically operates.

3 PLC Address, Parameter Setting

During PLC, the addresses and parameters of counter, timer, data list, keep relay are used, viewing and setting must be during the corresponding window. During PLCPAR window, press **【PLCPAR】** to enter PLC address, parameter setting window as Fig. 3-1, including counter, timer, data list, keep relay and so on, used for viewing and setting the addresses, parameter and data list.

PLCPara	RUN							
ADDR	N.7	N.6	N.5	N.4	N.3	N.2	N.1	N.0
K000	0	0	0	0	0	1	0	1
K001	0	0	0	0	1	0	0	1
K002	0	0	0	0	0	0	0	0
K003	0	0	0	0	0	0	0	0
K004	0	0	0	0	0	0	0	0
K005	0	0	0	0	0	0	0	0
K006	0	0	0	0	0	0	0	0
K007	0	0	0	0	0	0	0	0
K008	0	0	0	0	0	0	0	0
K009	0	0	0	0	0	0	0	0
K010	0	0	0	0	0	0	0	0
K011	0	0	0	0	0	0	0	0
NO.								
								MDI
								【KPAR】 【TMR】 【DATA】 【CTR】 【RETURN】 【▶▶】

Fig. 3-1

3.1 Counter

Press **【CTR】** during Fig. 3-1 to enter the view and the setting window of counter as Fig. 3-1-1.

PLCPara	RUN							
ADDR	N.7	N.6	N.5	N.4	N.3	N.2	N.1	N.0
K000	0	0	0	0	0	0	0	0
K001	0	0	0	0	1	0	0	0
K002	0	0	0	0	0	0	0	0
K003	0	0	0	0	0	0	0	0
K004	0	0	0	0	0	0	0	0
K005	0	0	0	0	0	1	0	0
K006	0	0	0	0	0	0	1	1
K007	0	0	0	0	0	0	0	0
K008	0	0	0	0	0	0	0	0
K009	0	0	0	0	0	0	0	0
K010	0	0	0	0	0	0	0	0
K011	0	0	0	0	0	0	0	0
NO.								
								MDI
								【KPAR】 【TMR】 【DATA】 【CTR】 【RETURN】 【▶▶】

Fig. 3-1-1

Contents and operations on counter window:

- OPERATION: operation state of ladder.
- N0.: counter number, cannot be changed.
- ADDRESS : counter address, cannot be changed.
- CURRENT: counter current value, cannot be changed.
- SET: counter preset value, can be changed during MDI mode.
- Data/serial number: displaying input data. The serial number appears by pressing **<SEARCH>** on the panel to search the data. The CNC returns to the data displaying window after press **<CANCEL>**.
- MDI mode: current operation mode.
- 【Esc】** : return to the up menu.

Press **<CHANGE>** to download the setting value to operation the CNC. When the change is completed, the system displays: CTR Downloaded OK ! , when the change is not completed, the system displays: Can't download !

(Note: press **【CHANGE】** after modification to save the modification and operation the CNC. Press the Page Up/Page Down, four Direction keys to search and position, view or modify the counter address.

3.2 Timer

Press **【TMR】** during Fig. 3-1 to enter the view and the setting window of counter as Fig. 3-2-1.

PLCPara				RUN
NO.	ADDRESS	CURRENT	SET	
0000	T000	00000	00100	
0001	T001	00000	00100	
0002	T002	00000	00100	
0003	T003	00000	00100	
0004	T004	00000	00100	
0005	T005	00000	00100	
0006	T006	00000	00100	
0007	T007	00000	00100	
0008	T008	00000	00100	
0009	T009	00000	00100	
0010	T010	00000	00100	
0011	T011	00000	00100	

NO.

MDI

【KPAR】 【TMR】 【DATA】 【CTR】 【RETURN】 【▶】

Fig. 3-2-1

Contents and operations on counter window:

- OPERATION: operation state of ladder。
- N0.: counter number, cannot be changed.
- ADDRESS: counter address, cannot be changed.
- CURRENT: counter current value, cannot be changed.
- SET: counter preset value, can be changed during MDI mode.
- Data/serial number: displaying input data. The serial number appears by pressing **<SEARCH>** on the panel to search the data. The CNC returns to the data displaying window after press **<CANCEL>**.

MDI mode: current operation mode.

【Esc】 : return to the up menu.

Press **<CHANGE>** to download the setting value to operation the CNC. When the change is completed, the system displays: CTR Downloaded OK ! , when the change is not completed, the system displays: Can't download !

(Note: press **【CHANGE】** after modification to save the modification and operation the CNC.

Press the Page Up/Page Down, four Direction keys to search and position, view or modify the counter address.

3.3 Data list

Press **【DATA】** during Fig. 3-1 to enter the view and the setting window of counter as Fig. 3-3-1.

PLCPara			RUN		
NO.	ADDRESS	DATA	NO.	ADDRESS	DATA
000	D000	00000	012	D012	00000
001	D001	00000	013	D013	00000
002	D002	00000	014	D014	00000
003	D003	00000	015	D015	00000
004	D004	00000	016	D016	00000
005	D005	00000	017	D017	00000
006	D006	00000	018	D018	00000
007	D007	00000	019	D019	00000
008	D008	00000	020	D020	00000
009	D009	00000	021	D021	00000
010	D010	00000	022	D022	00000
011	D011	00000	023	D023	00000

NO.

MDI

【KPAR】 【TMR】 【DATA】 【CTR】 【RETURN】 【▶】

Fig. 3-3-1

Contents and operations on data list window:

OPERATION : operation state of ladder.

NO. : data list number, cannot be changed.

ADDRESS : data list address, cannot be changed.

DATA : data list setting value, can be changed during MDI mode.

Data/serial number: displaying input data. The serial number appears by pressing **<SEARCH>** on the panel to search the data. The CNC returns to the data displaying window after press **<CANCEL>**.

MDI mode: current operation mode.

【Esc】 : return to the up menu.

Press **<CHANGE>** to download the setting value to operation the CNC. When the change is completed, the system displays: CTR Downloaded OK ! , when the change is not completed, the system displays: Can't download !

(Note: press **【CHANGE】** after modification to save the modification and operation the CNC.

Press the Page Up/Page Down, four Direction keys to search and position, view or modify the

data list address.

3.4 Keep relay

Press **【KPAR】** during Fig. 3-1 to enter the view and the setting window of counter as Fig. 3-4-1.

PLCPara			RUN
NO.	ADDRESS	CURRENT	SET
0000	C000	00000	00001
0001	C001	00000	00001
0002	C002	00000	00001
0003	C003	00000	00001
0004	C004	00000	00001
0005	C005	00000	00001
0006	C006	00000	00001
0007	C007	00000	00001
0008	C008	00000	00001
0009	C009	00000	00001
0010	C010	00000	00001
0011	C011	00000	00001

NO. MDI

【KPAR】 【TMR】 【DATA】 【CTR】 【RETURN】 【▶】

Fig. 3-4-1

Contents and operations on keep relay window: :

RNU: operation state of ladder.

ADDR: keep relay address.

N.0~N.7: bit number state of keep relay address. 1: After the CNC is turned off, the address keeps the state which is before power-off. 0: after the CNC is turned off, the address resets to the default state.

Data/serial number: displaying input data. The serial number appears by pressing **<SEARCH>** on the panel to search the data. The CNC returns to the data displaying window after press **<CANCEL>**.

MDI mode: current operation mode.

【Esc】 : return to the up menu.

Press **<CHANGE>** to download the setting value to operation the CNC. When the change is completed, the system displays: KPAR Downloaded OK ! , when the change is not completed, the system displays: Can't download !

(Note: press **【CHANGE】** after modification to save the modification and operation the CNC.

K000~~K005 is taken up by the CNC. For its definition, see Function, Appendix A.1

Press the Page Up/Page Down, four Direction keys to search and position, view or modify the data list address.

3.5 F address corresponded to M function

In Fig.3-1, press **【▶】** to enter the next page, press **【MDEC】** to enter the search and setting window of F address corresponded to M function as Fig. 3-5-1:

MCodeDEC (M00-M97~F026-F033)			RUN
MCODE	MEANING	ADDR	
M00	Program Stop	F031.7	
M01	Optional Stop	F*** *	
M02	End of Program	F*** *	
M03	Spindle forward	F030.0	
M04	Spindle backward	F030.1	
M05	Spindle stop	F030.2	
M06	Auto change tool	F*** *	
M07	STNANDBY	F***,*	
M08	Coolant on	F031.0	
M09	Coolant off	F031.1	
M10	A axis Clamp	F031.2	
M11	A axis Release	F031.3	
			MDI
			【RETURN】

【◀】 【MDEC】

Fig. 3-5- 1

Content and operation of F address corresponded to M function:

MCodeDEC: MDEC window.

M00-M97: setting range of M function INSTRUCTION.

F026-F033: setting range of F address.

RUN: run status of ladder.

MCODE: M function number.

MEANING: M function explanation.

ADDR: F address can be modified in MDI mode by inputting one which is higher than the terminal user password, and the modified is valid after the system restarts.

MDI mode: current operation mode.

【Esc】: escape from the upper menu.

【◀】: enter the upper menu.

After modification, the system “Alarm”, prompting “Power OFF”, and the setting is value after the system restarts. In PLC program, there is M function setting, and after the address is modified, the corresponding ladder should be modified to avoid the unexpected operation of machine tool.

Search or modify F address corresponded to M by PageUp/PageDown and four direction keys on the operator panel.

Note:

1. M00, M03, M04, M05 are used by the system and cannot be modified.
2. When the system manages the ladder files and configuration files, their number must be the same. When the user modifies the data list, the system saves it to the configuration file which corresponds to the current running ladder file number, the user should edit again the signal significations in the configuration file to ensure that the system correctly displays the information modified by the user. Chinese comment name in the configuration file is “LadChixx”, and English one is “LadEngxx”.

4 PLC address check operation

Press **【PLCTRA】** in **【PLCTRA】** to execute PLC address check operation as Fig. 4-1.




Fig. 4- 1

Content and operations of address check window:

RUN: ladder run state.

ADDR: address of diagnosis number.

0000 : bit number state of diagnosis address.

0016 : bit number state of diagnosis address. Sum by subtracting the previous data is bit number state of diagnosis address on the screen. The system can record up to 1024, otherwise restarts recording.

Data: display input data. Input the check address, Diagnose the address, and cannot execute the input when the diagnosis is being executed.

MDI mode: current operation mode.

【START】 : the system diagnoses the input address after it is pressed. The new address cannot be input and the user cannot view the history record when the diagnosis is being executed.

【STOP】 : the system stops the diagnosis in the input address window after it is pressed. The system permits inputting the new address which is to be diagnosed, and the user can view the history recorder of address with the direction key. The program is still running and so the address does although the window stops diagnosis.

【CLEAR】 : clear the graph and return to the start position.

【ESC】 : return to the previous menu.

Press the Page Up/Page Down, four Direction keys to search the corresponding diagnosis number.

5 Ladder edit software use

5.1 Summary


Presently, GSK218M system supports the matched GSK ladder edit software.

GSK ladder edit software is the ladder editor in PC of GSK218M series milling machine, machining center CNC system, providing the edit, change, searching error and print functions of GSK218M series ladder. The software can run in Windows 97, Windows Me, Windows 2000, Windows XP and Windows 2003.

5.2 Software introduction

5.2.1 Starting software

GSK ladder edit software is a green one that is not installed. The software package contains Lad Edit.exe, Diag.meas, and LadFile in which Ladder01 file is the system's standard ladder. Double-click Lad Edit.exe to run the software, and open Ladder01 ladder in LadFile as follows:



5.2.2 Function introduction

● File menu

The file menu contains New, Open and Save file, Create ladder or binary file, Print, Print Preview, Print Setup, Latest Open File List and other functions.

Note: use English instead of Chinese in “Ladder Version Number”, “Applicable Machine”, “ Last Editor” in “Edit Ladder Message”, otherwise, the error occurs

after the transmission is executed.

- **Edit menu**
Edit menu includes Cut, Copy, Paste, Search, Change, Edit and other functions
- **View menu**
Display or hide Tool Bar, Status Bar, Output Window and Instruction List Window.
- **Window menu**
Select and distribute each window.
- **Help menu**
Version information of the software.

5.3 Software operation

5.3.1 Tool bar

There are two tool bars which are not related to ladder edit in the main view frame,


5.3.1.1 Main tool bar

	creating a new ladder file
	opening a ladder file
	saving a ladder file
	cutting the selected content to the clipboard
	copying the selected content to the clipboard
	pasting the content from the clipboard
	changing a ladder
	searching a element
	printing a ladder
	about dialog box


5.3.1.2 Edit tool bar

	adding a normally open contact
	adding a normally closed contact
	adding a horizontal conduct
	adding a vertical conductive line(lower right of cursor)
	deleting some element or horizontal conductive line
	deleting a vertical conductive line at the lower right of element
	adding a output coil
	reversing an added output coil
	function command button, there are two methods to edit function instructions:

1. Click the cursor at the right of button and the system pops-up the menu to select the function instruction.




2. Or, click the button, and the system pops-up the function instruction dialog box to execute the function instruction setting.




5.3.2 Selecting a graph


In the edit view of ladder, the black rectangular shade is the cursor, and the user clicks the left mouse in the graphic edit area between the two busbars to select the position of the required edit graph as follows:



When the block is selected, the user should press the left key of mouse in its initial position to drag the mouse to the end of the row, and the surroundings of the selected area is appeared by a rectangle with many dotted line before releasing the key.



After the mouse is released, the whole ladder becomes black, i.e., the ladder in the range is selected, and the user can execute the next operation, such as clip, delete, copy and so on.



5.3.3 Editing a graph

5.3.3.1 Cutting

The user selects the required position to execute the operation by one of three methods as follows:

1. Click the right key of the mouse and the system pops-up the environmental menu to select the cut operation;
2. Click [Alt+E]--- [T] in the main menu;
3. Directly press the shortcut key [Ctrl+X];

After the cut content is placed to the clipboard, the user can execute the paste operation to copy it to the ladder.

5.3.3.2 Copying

The user selects the required position to execute the operation by one of three methods as follows:

1. Click the right key of the mouse and the system pops-up the environmental menu to select the copy operation;
2. Click [Alt+E]--- [C] in the main menu;

3. Directly press the shortcut key [Ctrl+C];

After the copy operation is executed and the cut content is placed to the clipboard, the user can execute the paste operation to copy it to the ladder.

5.3.3.3 Paste

The user selects the required position to execute the operation by one of three methods as follows::

1. Click the right key of the mouse and the system pops-up the environmental menu to select the paste operation;
2. Click [Alt+E]--- [P] in the main menu;
3. Directly press the shortcut key [Ctrl+V];

5.3.3.4 Deleting

The user selects the required position to execute the operation by one of three methods as follows:

1. Click the right key of the mouse and the system pops-up the environmental menu to select [Alt+B]----delete the node;
2. Click the button- [Delete node] in the edit bar;
3. Directly press the shortcut key [Delete];

5.3.3.5 Inserting one row

The user moves the cursor the required position to execute the operation by one of three methods as follows:

1. Click the right key of the mouse and the system pops-up the environmental menu to select the insert operation;
2. Click [Alt+E]--- [I] in the main menu;
3. Directly press shortcut key [Insert];

5.3.3.6 Deleting one row

The user selects the required position to execute the operation by one of three methods as follows:

1. Click the right key of the mouse and the system pops-up the environmental menu to select the deletion operation;
2. Click [Alt+E]--- [D] in the main menu;
3. Directly press shortcut key [Ctrl+Delete];

5.3.3.7 Converting


The user changes the ladder program of current edit window into the instruction list program by one of three methods as follows:

1. Click [Alt+E]--- [V] in the main menu;
2. Click [Convert ladder] in the edit bar;
3. Directly press shortcut key;

5.3.4 Ladder comment

5.3.4.1 Row comment


Double-click the left key outside the right busbar area of the ladder, and the edit box to edit the input comment.




5.3.4.2 Element comment

The user moves the cursor to the required position which element should be modified by one of two methods as follows:


1. Click the right key of mouse after the element is selected, and the system pops-up the environmental menu to select [Alt+M];




2. Click [Alt+E]--- [M] in the main menu;



After the system pops-up the dialog box, the user inputs the comment and then click OK to save it.



The saved comment appears in the output window at the bottom of the screen when the element is selected every time as follows:



5.3.5 Exporting

After the ladder is saved, the user should convert it to generate the executable file to send to CNC by the serial communication software. See **System Communication** in **GSK218M Programming and Operation Manual**.

Generate a ladder file

Click [Alt+F]---[L] in the main menu, input the name and path to save them, and the system generates ladder file ".grp" which is applied to the milling machine and machining center of GSK218M series.

IV Connection

1 System Structure and Installation

1.1 System composition

GSK218M CNC system mainly consists of the following units as Fig. 1.1.

- (1) GSK218M CNC system
- (2) Additional operator panel(optional)
- (3) Stepper driver(number AC servo driver)
- (4) Stepper motor(servo motor)
- (5) AC transformer




Fig. 1.1

1.2 System installation & connection

Firstly, check if the CNC system, driver, motor, and photoelectric encoder are ready, intact and matched.


The CNC system must be fixed stably, and there is some space around the system to ensure the air circulates, and the heat radiates. The installation position of CNC system must be convenient to the operation and avoid the position of processing chip and cooling.

The high/low voltage should be separated. The power supplies of CNC system and driver are provided by transformer, which are separated from the machine high voltage. All kind of signal line should be far from AC contactor to avoid the interference. The photoelectric encoder, limit signal and emergency stop signal should be directly connected to the CNC system. The power supply must be strictly grounded.


All kind of plug and bolt must be fixed stably, and forbid the signal connector is ON/OFF after the CNC system is turned on.

The system panel cannot be damaged by hard thing and sharp weapon when the CNC system is installed; the CNC system should be carried down to avoid dirtying the system panel.


There is no the source of high voltage, magnetic field around the CNC system, and the system should be far from the inflammable, explosive substance and all sort of dangerous thing.



3. Overlook



4. Back view



5. Additional panel

The user can select the additional panel for the system, and the functions of extension holes on the panel can be defined by the user, such as emergent stop, program lock, power on/off of the system, feed hold, cycle start, MPG and so on. The optional accessories of the system are as follows:


MPG: Changchun LGF-001-100;

Additional panel: (aluminum alloy 460×130mm) can be assembled under of GSK218M operator panel;

Emergency stop button: LAY3-02ZS/1


No. self-locking button: KH-516-B11 (green or red) ;

Self-locking button: KH-516-B21 (green or red) ;



2 Device Connection


2.1 CNC external connection



2.2 Connection between system and driver

Interfaces to driver include XS30 (X axis) , XS31 (Y axis) , XS32 (Z axis) , XS33 (4TH axis) .

2.2.1 System interface



2.2.2 Interface signal list

XS30: DB15 female (X axis)

1	XCP+	9	XCP-
2	XDIR+	10	XDIR-
3	XPC	11	0V
4	+24V	12	+5V
5	XDALM	13	+5V
6		14	0V
7	XEN	15	0V
8	0V		

XS31: DB15 female (Y axis)

1	YCP+	9	YCP-
2	YDIR+	10	YDIR-
3	YPC	11	0V
4	+24V	12	+5V
5	YDALM	13	+5V
6		14	0V
7	YEN	15	0V
8	0V		

XS32: DB15 female (Z axis)

1	ZCP+	9	ZCP-
2	ZDIR+	10	ZDIR-
3	ZPC	11	0V
4	+24V	12	+5V
5	ZDALM	13	+5V
6		14	0V
7	ZEN	15	0V
8	0V		

XS33: DB15 female (4TH axis)

1	4CP+	9	4CP-
2	4DIR+	10	4DIR-
3	4PC	11	0V
4	+24V	12	+5V
5	4DALM	13	+5V
6		14	0V
7	4EN	15	0V
8	0V		

2.2.3 Signal specification

1) Pulse motion instruction signal

XCP+, XCP-, YCP+, YCP-, ZCP+, ZCP-, 4CP+, 4CP- are instruction pulse signals, XDIR+, XDIR-, YDIR+, YDIR-, ZDIR+, ZDIR-, 4DIR+, 4DIR- are motion direction signal, and they are differential signals.

Connection is as follows:




Fig. 2-2-3-1

2) Driver alarm signal ALM (input)

The receiving method of signal at the CNC side is as follows. The parameter 019bit0 set if the driver fault is the low level "0" or the high level.




Fig. 2-2-3-2

The enabled level to the CNC can be set by customer if the low or the high is enabled. But the driver must provide the signal as follows:




Fig. 2-2-3-3

- 3) CNC ready completion signal EN(contact output) CNC
CNC ready has been completed when the contact is closed. When CNC has detected the alarm, the contact signal is OFF.
- 4) Reference point return with signal PC
The receiving method of signal at the CNC side is as follows.




Fig. 2-2-3-4

Wave of PC signal provided by customer is as follows:




Fig. 2-2-3-5

5) Connection method of one proximity switch as the deceleration switch and zero return switch.






Fig. 2-2-3-6

2.2.4 Cable connection

1. Cable for 218M connecting with DY3 series driver




2. Cable for 218M connecting with DA98 series servo driver



2.3 RS232 standard serial interface

GSK218M CNC system can communicate with the general-purpose PC (must match with 218M communication software) by RS232-C. Its connection is as follows:

Connection of cable is as follows:



2.4 MPG (handwheel), hand unit connection

2.4.1 Interface signal list

The 218M CNC system can be matched with MPG or hand unit. When it is matched with MPG, the MPG signal is connected to XS21 interface; with hand unit, the MPG signal of hand unit is connected to XS21 interface and other signals are connected to XS22.

XS21: DB9 female

1	+5V	6	VCOM
2	HA+	7	HA-
3	HB+	8	HB-
4	ESP1	9	ESP2
5	0V		

XS22: DB9 female

1	+5V	6	HX
2	HY	7	HZ
3	HU	8	H*1
4	H*10	9	H*100
5	0V		

2.4.2 Interface signal

HA+, HA-, HB+, HB-: MPG pulse signal;


ESP1, ESP2: hand unit emergency stop signal;

HX, HY, HZ, HU: are separately axis select signal of X, Y, Z, 4TH.


H*1, H*10, H*100: are separately the override of MPG pulse equivalent;

VCOM: hand unit common terminal.

[Connection diagram between 218M and differential MPG:](#)



Connection diagram between 218M and PSG series MPG:



2.5 Spindle unit connection

2.5.1 Interface signal list

The CNC interface is DB15 male and its pin definition is as follows:

XS23: DB15 male

1	SCOM	9	SVC
2		10	A+
3	A-	11	B+
4	B-	12	Z+
5	Z-	13	SDALM
6	+5V	14	
7	AxisEN	15	+24V
8	COM		

2.5.2 Interface signal

- (1) A+, A-, B+, B-, Z+, Z-: pulse signal of spindle encode;
- (2) SVC: spindle analog voltage signal;
- (3) SCOM: spindle analog power signal ground;
- (4) SDALM: spindle alarm input signal;
- (5) AxisEN: spindle enable signal.

2.6 Power supply interface

The input voltage of the CNC has two groups: +5V, +24V, among which +5V is for the CNC internal system, and +24V for external interface. The power supply interface is as follows:

3 Machine Control I/O Interface

3.1 Interface signal list

1	D000	14	D001
2	D002	15	D003
3	COM	16	+24V
4	+24V	17	D004
5	D005	18	D006
6	D007	19	COM
7	+24V	20	+24V
8	D008	21	D009
9	D010	22	D011
10	COM	23	+24V
11	+24V	24	D012
12	D013	25	D014
13	D015		

1	D016	14	D017
2	D018	15	D019
3	COM	16	+24V
4	+24V	17	D020
5	D021	18	D022
6	D023	19	COM
7	+24V	20	+24V
8	D024	21	D025
9	D026	22	D027
10	COM	23	+24V
11	+24V	24	D028
12	D029	25	D030
13	D031		

1	D032	14	D033
2	D034	15	D035
3	COM	16	+24V
4	+24V	17	D036
5	D037	18	D038
6	D039	19	COM
7	+24V	20	+24V
8	D040	21	D041
9	D042	22	D043
10	COM	23	+24V
11	+24V	24	D044
12	D045	25	D046
13	D047		

1	IN00	14	IN01
2	IN02	15	IN03
3	COM	16	COM
4	+24V	17	IN04
5	IN05	18	IN06
6	IN07	19	COM
7	COM	20	+24V
8	IN08	21	IN09
9	IN10	22	IN11
10	COM	23	COM
11	+24V	24	IN12
12	IN13	25	IN14
13	IN15		

1	IN16	14	IN17
2	IN18	15	IN19
3	COM	16	COM
4	+24V	17	IN20
5	IN21	18	IN22
6	IN23	19	COM
7	COM	20	+24V
8	IN24	21	IN25
9	IN26	22	IN27
10	COM	23	COM
11	+24V	24	IN28
12	IN29	25	IN30
13	IN31		

1	IN32	14	IN33
2	IN34	15	IN35
3	COM	16	COM
4	+24V	17	IN36
5	IN37	18	IN38
6	IN39	19	COM
7	COM	20	+24V
8	IN40	21	IN41
9	IN42	22	IN43
10	COM	23	COM
11	+24V	24	IN44
12	IN45	25	IN46
13	IN47		

Fig. 3-1

XS40, XS41, XS42 are output interfaces (DB25 female), XS43, XS44, XS45 are input interface.

3.2 Input interface

3.2.1 Input interface method

DC input signal A

DC input signal A is from the machine to the CNC, and they are from the press key at the machine side, limit switch and contact of relay.

a) Contacts at the machine side should meet the following:

Contact capacity: over DC30V, 16mA.

Leak current between contacts during open circuit: below 1mA(voltage 26.4).

Voltage-drop between contacts during closed-circuit: below 2V(current 8.5mA, including voltage-drop of cable).

b) Signal loop is as Fig 3-2-1-1:




Fig. 3-2-1-1

3.2.2 Input signal interface definition

Pin definition of input interface is as follows:

XS43 input 1

Pin	Mark	Label	Function
1	IN00	X0.0	X-axis positive travel limit switch is enabled when the normally close contact is OFF.
14	IN01	X0.1	X-axis negative travel limit switch is enabled when the normally close contact is OFF.
2	IN02	X0.2	Y-axis positive travel limit switch is enabled when the normally close contact is OFF.
15	IN03	X0.3	Y-axis negative travel limit switch is enabled when the normally close contact is OFF.
17	IN04	X0.4	Z-axis positive travel limit switch is enabled when the normally close contact is OFF.
5	IN05	X0.5	Z-axis negative travel limit switch is enabled when the normally close contact is OFF.
18	IN06	X0.6	4-axis positive travel limit switch is enabled when the normally close contact is OFF.
6	IN07	X0.7	4-axis negative travel limit switch is enabled when the normally close contact is OFF.
8	IN08	X1.0	X-axis positive travel limit switch is enabled when the normally close contact is OFF.
21	IN09	X1.1	Y-axis zero return deceleration switch is enabled when the normally close contact is OFF.
9	IN10	X1.2	Z-axis zero return deceleration switch is enabled when the normally close contact is OFF.
22	IN11	X1.3	4-axis zero return deceleration switch is enabled when the normally close contact is OFF.

24	IN12	X1.4	The emergency stop switch is enabled when the normally close contact is OFF.
12	IN13	X1.5	The external cycle start is enabled when the normally close contact is OFF.
25	IN14	X1.6	The external feed hold is enabled when the normally close contact is OFF.
13	IN15	X1.7	The press check switch is enabled when the normally close contact is OFF.

XS44 input 2

Pin	Mark	Label	Function
1	IN16	X2.0	The lubricant low is enabled when the normally close contact is OFF.
14	IN17	X2.1	The tool change permission is enable when the normally close contact is OFF.
2	IN18	X2.2	-axis zero return deceleration switch is enabled when the normally close contact is OFF.
15	IN19	X2.3	-axis zero return deceleration switch is enabled when the normally close contact is OFF.
17	IN20	X2.4	Undefined
5	IN21	X2.5	The tool release check is enabled when the normally close contact is OFF.
18	IN22	X2.6	The tool clamp check is enabled when the normally close contact is OFF.
6	IN23	X2.7	The spindle overheat is enabled when the normally close contact is OFF.
8	IN24	X3.0	Undefined
21	IN25	X3.1	Undefined
9	IN26	X3.2	Undefined
22	IN27	X3.3	Undefined
24	IN28	X3.4	Undefined
12	IN29	X3.5	Undefined
25	IN30	X3.6	Undefined
13	IN31	X3.7	Undefined

XS45 input 3

Pin	Mark	Label	Function
1	IN32	X4.0	Undefined
14	IN33	X4.1	The spindle gear stage 1 completion is enabled when the normally close contact is ON.
2	IN34	X4.2	The spindle gear stage 2 completion is enabled when the normally close contact is ON.
15	IN35	X4.3	The spindle gear stage 3 completion is enabled when the normally close contact is ON.
17	IN36	X4.4	Undefined
5	IN37	X4.5	Undefined
18	IN38	X4.6	The spindle speed completion is enabled when the normally close contact is ON.
6	IN39	X4.7	The spindle zero speed check is enabled when the normally close contact is ON.
8	IN40	X5.0	The spindle orientation completion is enabled when the normally close contact is ON.
21	IN41	X5.1	The tool magazine forward completion is enabled when the normally close contact is ON.

9	IN42	X5.2	The tool magazine backward completion is enabled when the normally close contact is ON.
22	IN43	X5.3	The tool magazine count is enabled when the normally close contact is ON. 刀
24	IN44	X5.4	The tool magazine zero return is enabled when the normally close contact is ON.
12	IN45	X5.5	The tool magazine air source check is enabled when the normally close contact is ON.
25	IN46	X5.6	Undefined
13	IN47	X5.7	The spindle alarm is enabled when the normally close contact is ON.

3.3 Output signal

3.3.1 Output interface method

a) Output transistor specification:

- ① When the output is ON, max. load current, including instantaneous current is below 200mA.
- ② When the output is ON and the current is 200mA, the saturation voltage is 1.6V and the typical value is 1V .
- ③ When the output is OFF, the withstand voltage including instantaneous voltage is below 24+20%.
- ④ When the output is OFF, the leak current is below 100μA.

b) Output loop:




Fig. 3-3-1-1

The output signals of the CNC are provided by Darlington pipe and Darlington pipe is conducted when the output is enabled. Except for TL-, TL+, SPZD are pulse signals, other outputs are the level signal and their common terminal is 24V.

3.3.2 Output signal interface definition

XS40 output 1

Pin	Mark	Label
1	DO00	Y0.0
14	DO01	Y0.1
2	DO02	Y0.2
15	DO03	Y0.3
17	DO04	Y0.4

5	DO05	Y0.5
18	DO06	Y0.6
6	DO07	Y0.7
8	DO08	Y1.0
21	DO09	Y1.1
9	DO10	Y1.2
22	DO11	Y1.3
24	DO12	Y1.4
12	DO13	Y1.5
25	DO14	Y1.6
13	DO15	Y1.7

XS41 Output 2

Pin	Mark	Label
1	DO16	Y2.0
14	DO17	Y2.1
2	DO18	Y2.2
15	DO19	Y2.3
17	DO20	Y2.4
5	DO21	Y2.5
18	DO22	Y2.6
6	DO23	Y2.7
8	DO24	Y3.0
21	DO25	Y3.1
9	DO26	Y3.2
22	DO27	Y3.3
24	DO28	Y3.4
12	DO29	Y3.5
25	DO30	Y3.6
13	DO31	Y3.7

XS42 output 3

Pin	Mark	Label
1	DO32	Y4.0
14	DO33	Y4.1
2	DO34	Y4.2
15	DO35	Y4.3
17	DO36	Y4.4
5	DO37	Y4.5
18	DO38	Y4.6
6	DO39	Y4.7
8	DO40	Y5.0
21	DO41	Y5.1
9	DO42	Y5.2
22	DO43	Y5.3
24	DO44	Y5.4
12	DO45	Y5.5
25	DO46	Y5.6
13	DO47	Y5.7

4 Debugging Machine

The chapter introduces the trial operation methods and steps after GSK218M CNC system is turned on firstly, and the corresponding machine operation can be performed after the following steps are done.

4.1 Debug preparation

GSK218M debug is as follows:

- System connection: the correct connection is the basis to successfully debug the system.
- PLC debug: it makes the safety functions(emergency stop, hardware limit) and operation functions be effective.
- Parameter setting of driver: set the motor type and control mode.
- Parameter setting of system: set the control parameter, speed parameter and so on.
- Data backup: after the system is debugged, the data including the parameter, the compensation data and PLC program is backup.

Notes before debugging GSK218M:

- To ensure all cables are connected correctly, please check the polarity of diode of relay, electromagnetic valve.
- Check the connection phase sequence of cable with high voltage of motor.
- The position cable, encoder feedback cable and motor cable with high voltage of AC servo feed device correspond one by one.
- Ensure the analog voltage instruction type received by the spindle.
- Ensure all grounding are stably connected.
- Ensure the emergency stop button and emergency stop circuit are valid. When the emergency stop button or emergency stop circuit is turned off, the power supply of drive device, spindle drive device can be turned off.
- Ensure the voltage and the polarity are correct.
- Ensure the specifications of power supply are correct.
- Ensure the specifications and the inlet/outlet directions of transformer are correct.
- Ensure the inlet/outlet lines of power supply of breakers are correct.

4.2 System power on

- Press the emergency stop button to ensure all air switches during the CNC are turned off.
- The power air switch during the electric cabinet is turned on.
- The air switch or the fuse is connected with DC 24V, and ensure DC24V is normal.
- Ensure other power supplies are normal.
- GSK218M CNC device is turned on.

4.3 Emergency stop and limit

The CNC has the soft limit function, it should be also adopted with the hardware limit function to get the safe operation, and the travel limit switch during the positive/negative direction of axis is installed.

The state of emergency stop signal can be monitored by parameters.

During Manual or MPG(handwheel) mode, the CNC can verify the validity of each axis overtravel limit switch, the accuracy of alarm display, and the validity of overtravel release button by slow moving each coordinate axis; when the overtravel occurs or the emergency stop is pressed, the CNC alarms, which can be released by pressing the overtravel releasing to execute the reverse move.

- Emergency stop signal

*ESP:

Parameter diagnosis(machine side input state)

state address								X1.4
Pin								XS43.24

- Limit signal

+L1~+L5, *-L1~*-L5: limit signal

Parameter diagnosis(machine side input state)

state address	X0.7	X0.6	X0.5	X0.4	X0.3	X0.2	X0.1	X0.0
Pin	XS43.6	XS43.18	XS43.05	XS43.17	XS43.15	XS43.02	XS43.14	XS43.01

State parameter No.011

0	1	1	BFA	LZR						
---	---	---	-----	-----	--	--	--	--	--	--

LZR =1: The travel check is executed during the period from power-on time to the completion of the manual reference point return.

=0: The travel check is not executed during the period from power-on time to the completion of the manual reference point return.

BFA =1: The CNC alarms after overtravel when it transmits the overtravel instruction.

=0: The CNC alarms before overtravel when it transmits the overtravel instruction.

System parameter number

0	3	1	G13							
---	---	---	-----	--	--	--	--	--	--	--

G13 =1: The system is executed by G13 when it is turned on or turned off.

=0: The system is executed by G12 when it is turned on or turned off.

System parameter number

0	6	1	LALM							
---	---	---	------	--	--	--	--	--	--	--

LALM =1: Ignore the limit alarm.

=0: Do not ignore the limit alarm.

4.4 Gear ratio adjustment

When the machine move distance is not uniform with the displacement distance of coordinate display, NO.160~ NO.169 are modified to adjust the electronic gear ratio to meet to the different machine driving ratio.

Division/multiplying of positioning INSTRUCTION pulse (electronic handwheel/MPG).

In position control mode, it can match with all pulse source by setting parameters to get the required resolution(angle/pulse).

Computation formula: $P \times G = N \times C \times 4$

$$G = \frac{\text{Division numerator}}{\text{Division nominator}}$$

Division numerator: INSTRUCTION multiplying coefficient (system parameter NO.160, NO.161, NO.162, NO.163, NO.164)

Division denominator: INSTRUCTION division coefficient (system parameter NO.165, NO.166, NO.167, NO.168, NO.169)

P: pulse quantity of input INSTRUCTION;

G: electronic gear ratio;

N: motor rotation rev;

C: photoelectric encoder lines/rev, the system C=2500.

【Example】 When the input instruction pulse is 6000, the servo motor rotates 1 rev.

$$G = \frac{N \times C \times 4}{P} = \frac{1 \times 2500 \times 4}{6000} = \frac{5}{3}$$

Data parameter NO. 160 (CMRX) =5, NO.165 (CMDX) =3;

The ratio between the system gear and the parameter has the same function that of digital servo gear and parameter. When the system is employed with the digital servo with the electronic gear ratio function, the electronic gear ratio is set to 1:1, which is set to the digital servo.

When the CNC is adopted with the stepper driver, it should use the stepper division driver as possible, v and the proper machine driving ratio, and set the electronic gear ratio to 1:1 to avoid the large difference between the numerator and denominator.

4.5 Backlash compensation

Use the gauge, micrometer gauge or laser master gauge to measure the backlash, the backlash compensation must be precise, otherwise it cannot improve the precision of processing and it is suggested that the following methods should be adopted to measure the leading screw backlash instead of MPG(handwheel) or single step:

- Edit program:


```
O0001;
N10 G01 G91 X1 F800 ;
N20 X1 ;
N30 X1 ;
N40 X-1 ;
N50 M30 .
```
- The backlash error compensation value is set to zero before measuring.
- The program runs during Single block mode, and the CNC looks for the measure datum point A after positioning two times, the program runs 1mm and reversely runs 1mm to B point, and the CNC reads the current data.




Fig. 4-5-1 backlash measure method

- Backlash error compensation value= |data recorded by A point –data recorded by B point|; input the operation result to the system parameter No.190.

Data A: read the data of gauge at the A point;

Data B: read the data of micrometer gauge at the B point;

Pulse equivalent: 1 micron

Note: 1. The system parameter NO.195~NO.199 can set the backlash compensation mode and the compensation frequency.

2. To get the high precision, the backlash must be checked after the machine has been used for 3 months.

4.6 Parameter of servo

System parameter number

0	1	8	RVCS			RBK	FFR			
---	---	---	------	--	--	-----	-----	--	--	--

FFR =1: in feedforward control mode, the cutting feed and rapid traverse are enabled.

=0: In feedforward control mode, only cutting feed is enabled.

RBK =1: the cutting feed and the rapid traverse separately executes the backlash.

=0: the cutting feed and the rapid traverse does not execute separately the backlash.

4.7 Machine pitch compensation

- **Setting compensation value**
 - ① The set compensation value is related to the position between the zero and compensation point machine move direction and compensation backlash and so on.
 - ② The compensation value of compensation point N(N=0,1,2,3,...127) is determined by the machine error between N, N-1.
 - ③ The machine zero is taken as the compensation origin point, and the set compensation of every axis is taken as the parameter value.
 - ④ Compensable axis: X, Y, Z, 4, 5 axis. Compensation points: 128 points for each axis.
 - ⑤ Compensation value range: each compensation point (-7~+7) × compensation override. The input exceeding -7~+7 is disabled.
 - ⑥ The setting method is the same that of input method of system parameter, see Operation.


- **Notes for compensation value setting**
 1. Bit parameter NO: 37#1 determines whether the pitch compensation is executed, and NO: 37#2 determines to select the unidirectional or bidirectional compensation.
 2. System parameter 216~220: pitch error compensation number of reference point of each axis(setting of compensation zero).
 3. System parameter 221~225: compensation points of pitch error compensation of each axis
 4. System parameter 226~230: pitch error compensation backlash of each axis. Execute the compensation with the value when the positive compensation value is input; execute the compensation with the absolute value of the value when the negative compensation value is input
 5. System parameter 231~235: pitch error compensation override of each axis. The CNC defaults 0.001.
 6. The compensation is not executed when the input compensation backlash is zero.
 7. After the pitch error parameter is set, the CNC is turned on again, and the pitch error parameter is enabled after the machine zero return is executed.

- The following is the compensation parameters, taking X axis as example:

Parameter	Setting value
NO.216: compensation number of X-axis reference point	0
NO.221: X-axis pitch error compensation points	128
NO.226: X-axis pitch error compensation backlash	10
NO.231: X-axis pitch error compensation override	0.001

The error compensation takes the machine zero as reference point. The pitch error compensation is executed when the positive coordinate system of machine zero is moving.

The set compensation value during 【Pitch compensation X】 .



The displayed compensation points during compensation list take the set compensation points as the reference, corresponding to the reference point (pitch error origin 0), the compensation point 1 corresponds to the position which is 10.000 from the reference point, the increment of 10.000 after it is taken as one compensation point, and the compensation value of No.127 compensation point is at 1270.000. So, at the compensation parameter number 0 during 【Compensation X】 , set the compensation value from 0 to 10.000, and set the compensation value from 10.000 to 20.000 at the compensation point 1. For the compensation point N, the CNC sets the compensation value from $N \times (\text{compensation backlash})$ to $(N+1) \times (\text{compensation backlash})$.

Actually, when the machine moves to +30.000 from the reference point, the compensation value of pitch error is:

$$(+7)+(-6)+(+4)=+5$$

● Bidirectional compensation setting takes X axis as the example:


The error compensation takes the machine zero as the reference point. The pitch error compensation can be executed when the positive/negative coordinate system of machine zero moves

Operation during the positive coordinate: the first compensation length is No. 000 set compensation value during 【Compensation X】 , the second is that of No. 001 and the N is that of No. N-1.

Operation during the negative coordinate: the first compensation length is No. 1000 set compensation value during 【Compensation X】 , the second is that of No. 1001 and the N is that of No. 1000+N-1.

Parameter	Setting value
NO.216: compensation number of X-axis reference point	40
NO.221: X-axis pitch error compensation points	128
NO.226: X-axis pitch error compensation during interval	50
NO.231: X-axis pitch error compensation override	0.001mm

Output the compensation value at the compensation point of corresponding area. The example for the compensation is as follows:



Positive pitch compensation (short line drawing):

Number	34	35	36	37	38	39	40	41	42	43	44	45	46	47	49
Compensation value	+1	+2	-1	-1	0	0	-1	+1	+3	+1	0	-1	-2	-2	+1

Negative pitch compensation (long line drawing):

Number	1034	1035	1036	1037	1038	1039	1040	1041	1042	1043	1044	1045	1046	1047
Compensation value	-1	-2	0	+2	+1	0	-1	-1	0	0	+3	+3	-2	-2

The chapter mainly introduces modifying the position parameters and data parameters of CNC to realize the different functions.

4.8 Machine zero return

- Signals
 - DECX: X-axis deceleration signal;
 - DECY: Y-axis deceleration signal;
 - DECZ: Z-axis deceleration signal;
 - DEC4: 4th-axis deceleration signal;

Parameter diagnosis(machine side input state)

State address					X1.3	X1.2	X1.1	X1.0
Pin					XS43.15	XS43.02	XS43.14	XS43.01

DEC =1: The machine zero return starts to decelerate when the deceleration signal is connected with 24V.

=0: The machine zero return starts to decelerate when the deceleration signal is not connected with 24V.

State parameter No.007

0	0	7	ZMI5	ZMI4	ZMIz	ZMIy	ZMIx			
---	---	---	------	------	------	------	------	--	--	--

ZMI =0 : The direction of machine zero return is positive.
 =1 : The direction of machine zero return is negative.

State parameter No.006

0	0	1	SJZ							
---	---	---	-----	--	--	--	--	--	--	--

SJZ =1: reference point memory: do.
 =0: reference point memory: not.

Data parameter No.099

0	9	9	ZRNFL
---	---	---	-------

ZRNFL: low rate of X, Y, Z-axis reference point return(all axes).

Data parameters No.100~No.104

1	0	0	X-axis reference point return speed
1	0	1	Y-axis reference point return speed
1	0	2	Z-axis reference point return speed
1	0	3	4TH-axis reference point return speed
1	0	4	5TH-axis reference point return speed

Speed setting of all-axis reference point return

4.9 Input/output signal control of spindle CW/CCW

- Signals

M03: spindle CCW

M04: spindle CW

M05: spindle stop

ENB: spindle enable

SAR: spindle speed arrival

ZSPD: spindle zero speed check

Parameter diagnosis(machine side output state)

state address	Pin	Y1.7	Y1.6						
		XS40.13	XS40.25						

Y1.6=spindle CCW signal output; Y1.7= spindle CW signal output.

state address	Pin		Y2.5					Y2.0
			XS40.05					XS40.01

Y2.0=spindle enable; Y2.5=spindle zero speed clamp signal output

Parameter diagnosis(machine side input state)

state address	Pin	X4.7	X4.6					
		XS45.06	XS45.18					

X4.6=spindle speed arrival signal input; X4.7=spindle zero speed check signal input.

Data parameter No.245

2	4	5	
---	---	---	--

Time for check spindle speed arrival signal

Data parameter No.257

2	5	7	
---	---	---	--

Spindle speed up limit during tapping cycle

Data parameter No.258

2	5	8	
---	---	---	--

Spindle speed up limit

● **Operation time sequence**

Time sequence of spindle operation is as Fig. 3-3-1:




Fig. 3-3-1 Spindle CW time sequence

● **Control logic**

- ① The spindle stops and M05 outputs when CNC is turned on;
- ② After M3/M4 is executed, it is enabled and M05 stops output.

4.10 Spindle automatic gear change control

● **Signals**

Y3.4~Y3.6: Spindle automatic gear shift output signal

X4.1~X4.3: Spindle gear change completion signal

When CNC selects the spindle frequency conversion control (0~10V analog voltage output), it can support 4-gear spindle automatic gear change control and 4-gear change completion check function.

● **Signal diagnosis**

Parameter diagnosis(machine side output state)

state address		Y3.6	Y3.5	Y3.4				
Pin		XS44.25	XS44.12	XS44.24				

Y3.4=spindle gear 1 output; Y3.5=spindle gear 2 output; Y3.6=spindle gear 3 output.

Parameter diagnosis(machine side input state)

state address				X4.3	X4.2	X4.1	
Pin				XS45.15	XS45.02	XS45.13	

X4.1= spindle gear 1 in-position; X4.2=spindle gear 2 in-position; X4.3=spindle gear 3 in-position.

● **Control parameter**

State parameter

0	0	1							SPT		
---	---	---	--	--	--	--	--	--	-----	--	--

SPT =1: Spindle control: I/O point.
 =0: Spindle control: frequency conversion or other modes.

Data parameter No.246

2	4	6									
---	---	---	--	--	--	--	--	--	--	--	--

Corresponding to max. speed of gear 1.

Data parameter No.247

2	4	7									
---	---	---	--	--	--	--	--	--	--	--	--

Corresponding to max. speed of gear 2.

Data parameter No.248

2	4	8									
---	---	---	--	--	--	--	--	--	--	--	--

Corresponding to max. speed of gear 3.

● **Control logic**

- ③ Up to 1 of S1~S3 is enabled;
- ④ S1~S3 stops output after S0 is executed;
- ⑤ When some S** is executed, the corresponding S** output is enabled and kept, and CNC automatically stops other S** output.

4.11 External cycle start and feed hold

● **Signals**

ST: external automatic cycle start signal has the same function that of automatic cycle start key on the machine panel.

*SP: feed hold signal has the same function that of the feed hold key on the machine panel.

● **Signal diagnosis**

Parameter diagnosis(machine side output state)

State address		X1.6	X1.5					
Pin		XS43.25	XS43.12					

● **Internal circuit of signal**

*SP/ST internal circuit is as Fig. 3-5-1:




Fig.3-5-1

- External circuit
*SP, ST external circuit is as Fig. 3-5-2.




Fig. 3-5-2

4.12 Cooling, lubricant and chip removal control

- Signals
M08: cooling ON
M32: lubricant ON
M35: Chip removal ON
- Signal diagnosis

Parameter diagnosis(machine side output state)

State address							Y0.1	
Pin							XS40.14	

Y0.1=cooling switch control

Parameter diagnosis(machine side output state)

State address						Y1.2	Y1.1	
Pin						XS40.14	XS40.14	

Y1.1=chip removal switch control; Y1.2=lubricant switch control.

- Internal circuit is as Fig. 3-6-1:




Fig.3-6-1 M08 internal circuit

4.13 Parameters of axis control

System parameter number

0	0	3			DIR5	DIR4	DIRZ	DIRY	DIRX	INM
----------	----------	----------	--	--	-------------	-------------	-------------	-------------	-------------	------------

- INM** =1: Least instruction increment on the linear axis: inch.
=0: Least instruction increment on the linear axis: metric.
- DIRX** =1: X-axis feed direction.
=0: X-axis feed reverse.
- DIRY** =1: Y-axis feed direction.
=0: Y-axis feed reverse.
- DIRZ** =1: Z-axis feed direction.
=0: Z-axis feed reverse.

System parameter number

0	1	9				MAL5	MAL4	MALZ	LAMY	MALX
----------	----------	----------	--	--	--	-------------	-------------	-------------	-------------	-------------

- MALX** =1: When the driver alarms, the high level is enabled.
=0: When the driver alarms, the low level is enabled.
- MALY** =1: When Y axis drive alarms, the high level is enabled.
=0: When Y axis drive alarms, the low level is enabled.
- MALZ** =1: When Z axis drive alarms, the high level is enabled.
=0: When Z axis drive alarms, the low level is enabled.
- MAL4** =1: When TH4 axis drive alarms, the high level is enabled.
=0: When TH4 axis drive alarms, the low level is enabled.
- MAL5** =1: When TH5 axis drive alarms, the high level is enabled.
=0: When TH5 axis drive alarms, the low level is enabled.

System parameter number

0	0	4	IDG			XIK	AZR	SFD		JAX
----------	----------	----------	------------	--	--	------------	------------	------------	--	------------

- JAX** =1: Simultaneous controlled axis during JOG, manual rapid, manual reference point mode: 3 .
=0: Simultaneous controlled axis during JOG, manual rapid, manual reference point mode: 1.

- DLZ** =1: Function for setting the reference point without dogs: enabled.
=0: Function for setting the reference point without dogs: disabled.
- AZR** =1: When the reference point is not set, G28: alarm.
=0: When the reference point is not set, G28: use dogs.
- XIK** =1: Non-linear positioning axis is interlocked: all-axis stops moving.
=0: Non-linear positioning axis is interlocked: interlock.

4.14 Parameter of coordinate system

System parameter number

0	0	9					ZCL		
---	---	---	--	--	--	--	-----	--	--

- ZCL** =1: The local coordinate system is canceled when the manual reference point return is performed.
=0: The local coordinate system is canceled when the manual reference point return is not performed.

4.15 Parameter of feedrate

System parameter number

0	1	2		FDR	RDR	TDR	RFO		LRP	RPD
---	---	---	--	-----	-----	-----	-----	--	-----	-----

- RPD** =1: Manual rapid traverse during the period from power-on time to the completion of the reference point return is enabled.
=0: Manual rapid traverse during the period from power-on time to the completion of the reference point return is disabled.
- LRP** =1: The positioning(G00) interpolation is performed with the linear.
=0: The positioning(G00) interpolation is performed with the non-linear.
- RFO** =1: The machine tool stops moving when the feedrate override is F0 during rapid traverse.
=0: The machine tool does not stop moving when the feedrate override is F0 during rapid traverse.
- TDR** =1: The dry run is enabled during the tapping.
=0: The dry run is disabled during the tapping.
- RDR** =1: The dry run is enabled.
=0: The dry run is disabled.
- FDR** =1: When the rapid position is being executed, the dry run is enabled.
=0: When the rapid position is being executed, the dry run is disabled.

System parameter number

0	1	4						DLF	HFC
---	---	---	--	--	--	--	--	-----	-----

- HFC** =1: Clamped so that the composite feedrate along an arc and linear axis does not exceed the maximum cutting federate specified by the parameter.
=0: Clamped so that the composite feedrate along an arc and linear axis do not

exceed the maximum cutting federate specified by the parameter.

0086	Dry run speed	5000
------	---------------	------

Set range: 0~9999 (mm/min)

0087	The cutting feedrate during Auto mode when power-on.	300
------	--	-----

Set range: 0~9999 (mm/min)

0088	X-axis rapid operation speed	5000
------	------------------------------	------

Set range: 0~9999 (mm/min)

0089	Y-axis rapid operation speed	5000
------	------------------------------	------

Set range: 0~9999 (mm/min)

0090	Z-axis rapid operation speed	5000
------	------------------------------	------

Set range: 0~9999 (mm/min)

0091	4TH-axis rapid operation speed	5000
------	--------------------------------	------

Set range:0~9999 (mm/min)

0092	5TH-axis rapid operation speed	5000
------	--------------------------------	------

Set range: 0~9999 (mm/min)

0093	All-axis rapid operation override F0 speed (all axes)	30
------	---	----

Set range: 0~9999 (mm/min)

0094	Max. feedrate(all axes)	8000
------	-------------------------	------

Set range: 0~9999 (mm/min) max. controlled speed in non-prediction control mode

0095	Min. feedrate(all axes)	0
------	-------------------------	---

Set range:0~500 (mm/min) min. controlled speed in non-prediction control mode

0096	Max. control speed during predict control mode(all axes)	6000
------	--	------

Set range: 0~9999 (mm/min)

- DRL** =1: The relative position display takes into account the tool length compensation.
 =0: The relative position display does not take into account the tool length compensation.
- DRC** =1: The relative position display takes into account the tool nose radius compensation.
 =0: The relative position display does not take into account the tool nose radius compensation.
- DAL** =1: The absolute position display takes into account the tool length compensation.
 =0: The absolute position display does not take into account the tool length compensation.
- DAC** =1: The absolute position display takes into account the tool nose radius compensation.
 =0: The absolute position display does not take into account the tool nose radius compensation.

System parameter number

0	2	3		POSM		SUK		DNC		
---	---	---	--	------	--	-----	--	-----	--	--

- NAM** =1: Program list displays program number and program name.
 =0: Program list displays program number.
- DNC** =1: Upon reset, the program display for DNC operation is cleared.
 =0: Upon reset, the program display for DNC operation is not cleared.
- SUK** =1: The program list is displayed during order of program number.
 =0: The program list is displayed during order of logging time.
- POSM** =1: The modal state on the program position screen is displayed.
 =0: The modal state on the program position screen is not displayed.
- MDL** =1: The modal state on the program display screen is displayed.
 =0: The modal state on the program display screen is not displayed.

System parameter number

0	2	4	RHD	NPA					
---	---	---	-----	-----	--	--	--	--	--

- NPA** =1: It is switched to the alarm screen when CNC alarms.
 =0: It is not switched to the alarm screen when CNC alarms.
- RHD** =1: The MPG halt relative position display is changed.
 =0: The MPG halt relative position display is not changed.

0	2	9		MCM		IWZ	WZO	MCV	GOF	WOF
---	---	---	--	-----	--	-----	-----	-----	-----	-----

- WOF** =1: The tool offset value by MDI key input is disabled.
 =0: The tool offset value by MDI key input is not disabled.
- GOF** =1: The tool geometric offset value by MDI key input is disabled.
 =0: The tool geometric offset value by MDI key input is not disabled.
- MCV** =1: Macro variable setting by MDI input is disabled.
 =0: Macro variable setting by MDI input is not disabled.
- WZO** =1: Setting a workpiece zero point offset value by MDI key input is disabled.
 =0: Setting a workpiece zero point offset value by MDI key input is not disabled.
- IWZ** =1: Setting a workpiece zero point offset value by MDI key input during halt state is disabled.

=0: Setting a workpiece zero point offset value by MDI key input during halt state is not disabled.

MCM =1: The setting of custom macros by MDI key operation is enabled only during the MDI mode.

=0: The setting of custom macros by MDI key operation is enabled regardless of the mode.

System parameter number

0	2	8	MCL			MKP				
---	---	---	-----	--	--	-----	--	--	--	--

MKP =1: The written program is cleared when M02, M30 or is executed in MDI mode.

=0: The written program is not cleared when M02, M30 or is executed in MDI mode.

MEE =1: The program is not edited during operation in MDI mode.

=0: The program can be edited during operation in MDI mode.

MER =1: The program can be edited during operation execution in MDI mode.

=0: The executed program is not deleted when the last has been executed in MDI mode.

MCL =1: Upon the reset key, the written program is deleted during MDI mode.

=0: Upon the reset key, the written program is not deleted during MDI mode.

System parameter number

0	3	0			ABS	MAB				DPI
---	---	---	--	--	-----	-----	--	--	--	-----

DPI =1: The decimal point during programming is omitted: mm, sec.

=0: The decimal point during programming is omitted: min. setting unit.

MAB =1: Use parameters to set the absolute or relative during MDI mode.

=0: Use G90/G91 to set the absolute or relative during MDI mode.

ABS =1: The instruction is absolute during MDI mode.

=0: The instruction is relative during MDI mode.

4.17 Parameters of tool compensation

System parameter number

0	3	9		EVO		EVR				TLC
---	---	---	--	-----	--	-----	--	--	--	-----

TLC =1: Tool length compensation: B

=0: Tool length compensation: A

EVR =1: Enables the change, starting from that block where buffering is next performed.

=0: Enables the change, starting from that block where the next block is specified.

EVO =1: A block to be buffered next and subsequent blocks becomes valid.

=0: A block specifying the next becomes valid.

System parameter number

0	4	0	ODI					CCN		SUP
---	---	---	-----	--	--	--	--	-----	--	-----

SUP =1: Start up during tool nose radius compensation : B

=0: Start up during tool nose radius compensation: A

- CCN** =1: The tool nose radius compensation vector is cancelled when G28 is during movement to an intermediate position.
 =0: The tool nose radius compensation vector is not cancelled when G28 is during movement to an intermediate position.
- ODI** =1: A tool nose radius compensation amount is set by diameter.
 =0: A tool nose radius compensation amount is set by radius.

System parameter number

0	4	1		CN1	G39				CIM	OIM
----------	----------	----------	--	------------	------------	--	--	--	------------	------------

- OIM** =1: When the unit is switched between the inch and metric systems, the automatic tool offset value conversion is performed.
 =0: When the unit is switched between the inch and metric systems, the automatic tool offset value conversion is not performed.
- CIM** =1: The workpiece coordinate system automatically switches inch/metric system.
 =0: The workpiece coordinate system does not automatically switch inch/metric system.
- G39** =1: The corner rounding function is enabled in radius compensation mode.
 =0: The corner rounding function is disabled in radius compensation mode.
- CN1** =1: The tool nose radius compensation (C) is executed the halt check.
 =0: The tool nose radius compensation(C) is not executed the halt check.

Appendix:

Guide for GSK218M matching with ladder

1. Notices of GSK218M matching with turret tool magazine

- (1) Install wiring according to the ladder.
- (2) Set PLC parameters correctly to ensure that the ladder matches with the machine tool when the ladder is used
- (3) The machine tool has special control requirements. When the program is added to the ladder, the persons responsible for modification should be master the electric and PLC method, and the ladder.
- (4) The ladder is only suitable for general CNC milling machine and the machining center with the turret tool magazine, otherwise, other machine tools may result in the unexpected accident.
- (5) The ladder is referred, and the ladder is different for the different machine tool.

2. Allocation and definition of PLC IO address, auxiliary relay and register

Table 1 Input signal interface definition

Address	Signal interface	Interface pin	Definition	Contact selection
X000.0	XS43	1	X axis positive travel limit signal	Normally closed contact
X000.1	XS43	14	X axis negative travel limit signal	Normally closed contact
X000.2	XS43	2	Y axis positive travel limit signal	Normally closed contact
X000.3	XS43	15	Y axis negative travel limit signal	Normally closed contact
X000.4	XS43	17	Z axis positive travel limit signal	Normally closed contact
X000.5	XS43	5	Z axis negative travel limit signal	Normally closed contact
X000.6	XS43	18	Th4 axis positive travel limit signal	Normally closed contact
X000.7	XS43	6	Th4 axis negative travel limit signal	Normally closed contact
X001.0	XS43	8	X axis zero return deceleration signal	Normally closed contact
X001.1	XS43	21	Y axis zero return deceleration signal	Normally closed contact
X001.2	XS43	9	Z axis zero return deceleration signal	Normally closed contact
X001.3	XS43	22	Th4 axis zero return deceleration signal	Normally closed contact
X001.4	XS43	24	Emergency stop switch	Normally closed contact
X001.5	XS43	12	External cycle start	Normally open contact
X001.6	XS43	25	External feed hold	Normally open contact
X001.7	XS43	13	Undefined	
X002.0	XS44	1	Undefined	
X002.1	XS44	14	Undefined	
X002.2	XS44	2	Undefined	
X002.3	XS44	15	Undefined	
X002.4	XS44	17	External clamping/releasing tool control	Normally open contact
X002.5	XS44	5	Releasing tool check	Normally open contact
X002.6	XS44	18	Clamping tool check	Normally open contact
X002.7	XS44	6	Undefined	
X003.0	XS44	8	Edit lock	Normally open contact

X003.1	XS44	21	Operation lock	Normally open contact
X003.2	XS44	9	Undefined	
X003.3	XS44	22	Undefined	
X003.4	XS44	24	Undefined	
X003.5	XS44	12	Undefined	
X003.6	XS44	25	Undefined	
X003.7	XS44	13	Undefined	
X004.0	XS45	1	Undefined	
X004.1	XS45	14	Spindle gear-1 in-position	Normally open contact
X004.2	XS45	2	Spindle gear-2 in-position	Normally open contact
X004.3	XS45	15	Spindle gear-3 in-position	Normally open contact
X004.4	XS45	17	Spindle speed/position status output	Normally open contact
X004.5	XS45	5	Undefined	
X004.6	XS45	18	Spindle speed arrival	Determined by the parameter
X004.7	XS45	6	Spindle zero speed arrival	Normally closed contact
X005.0	XS45	8	Spindle orientation in-position	Determined by the parameter
X005.1	XS45	21	Tool magazine forward in-position	Determined by the parameter
X005.2	XS45	9	Tool magazine backward in-position	Determined by the parameter
X005.3	XS45	22	Tool magazine CCW/CW in-position	Determined by the parameter
X005.4	XS45	24	Tool magazine zero return in-position	Determined by the parameter
X005.5	XS45	12	Undefined	
X005.6	XS45	25	Undefined	
X005.7	XS45	13	Undefined	
X006.0	XS22	6	External MPG X axis selection	Normally open contact
X006.1	XS22	2	External MPG Y axis selection	Normally open contact
X006.2	XS22	7	External MPG Z axis selection	Normally open contact
X006.3	XS22	3	External MPG A axis selection	Normally open contact
X006.4	XS22	8	External MPG step 0.001	Normally open contact
X006.5	XS22	4	External MPG step 0.01	Normally open contact
X006.6	XS22	9	External MPG step 0.1	Normally open contact
X006.7	XS21	ESP (4, 9)	External emergency stop	Normally closed contact

Note:

- (1) Refer to **Volume Four** about PLC input (X) connection method.
- (2) Contact selection: normally open contact and normally closed contact. The contact is determined to be normally open or normally closed,
- (3) When the ladder is used, the user can add the new function for the undefined input.

Table 2 Output signal interface definition

Address	Signal interface	Interface pin	Definition
Y000.0	XS40	1	Z axis holding brake
Y000.1	XS40	14	Cooling
Y000.2	XS40	2	Tool releasing/clamping
Y000.3	XS40	15	Undefined
Y000.4	XS40	17	Spindle brake
Y000.5	XS40	5	Spindle impulse
Y000.6	XS40	18	Red alarm light
Y000.7	XS40	6	Yellow alarm light
Y001.0	XS40	8	Green alarm light
Y001.1	XS40	21	Chip removal control
Y001.2	XS40	9	Lubrication control

Y001.3	XS40	22	Machine light control
Y001.4	XS40	24	Undefined
Y001.5	XS40	12	Spindle blowing
Y001.6	XS40	25	Undefined
Y001.7	XS40	13	Undefined
Y002.0	XS41	1	Spindle enabling
Y002.1	XS41	14	Spindle orientation
Y002.2	XS41	2	Spindle CCW
Y002.3	XS41	15	Spindle CW
Y002.4	XS41	17	Undefined
Y002.5	XS41	5	Undefined
Y002.6	XS41	18	Undefined
Y002.7	XS41	6	Undefined
Y003.0	XS41	8	Tool magazine CCW
Y003.1	XS41	21	Tool magazine CW
Y003.2	XS41	9	Tool magazine forward
Y003.3	XS41	22	Tool magazine backward
Y003.4	XS41	24	Spindle gear 1(frequency conversion\IO point control)
Y003.5	XS41	12	Spindle gear 2(frequency conversion\IO point control)
Y003.6	XS41	25	Spindle gear 3(frequency conversion\IO point control)
Y003.7	XS41	13	Spindle gear 4(frequency conversion\IO point control)
Y004.0	XS42	1	Undefined
Y004.1	XS42	14	Undefined
Y004.2	XS42	2	Undefined
Y004.3	XS42	15	Undefined
Y004.4	XS42	17	Undefined
Y004.5	XS42	5	Undefined
Y004.6	XS42	18	Undefined
Y004.7	XS42	6	Undefined
Y005.0	XS42	8	Undefined
Y005.1	XS42	21	Undefined
Y005.2	XS42	9	Undefined
Y005.3	XS42	22	Undefined
Y005.4	XS42	24	Undefined
Y005.5	XS42	12	Undefined
Y005.6	XS42	25	Undefined
Y005.7	XS42	13	Undefined

Note:

- (1) Refer to **Volume Four** about PLC input (X) connection method.
- (2) When the ladder is used, the user can add the new function for the undefined input.

Table 3 KAPA address definition

Address	Definition	Status 0	Status1	Setting value by customer
K000.0	Permit PLC parameter to be modified	No permission	Permission	
K000.1	Permit PLC signal to be debugged	No permission	Permission	
K000.2	All Y signals are cleared after PLC enters the debugging mode.	Not clearing	Clearing	
K000.3	Undefined	No permission	Permission	
K000.4	Undefined	No permission	Permission	
K000.5	Undefined	No permission	Permission	
K000.6	Undefined	No permission	Permission	
K000.7	Permit the instruction table to be operated	No permission	Permission	
K001.0	Permit the tool magazine to be used	No permission	Permission	
K001.1	Whether the ladder downloads automatically when it is converted	No.	Yes	
K001.2	Reversed			
K001.3	Reversed			
K001.4	Reversed			
K001.5	Reversed			
K001.6	Reversed			
K001.7	Reversed			
K002.0	Reversed			
K002.1	Reversed			
K002.2	Reversed			
K002.3	Reversed			
K002.4	Reversed			
K002.5	Reversed			
K002.6	Reversed			
K002.7	Reversed			
K003.0	Reversed			
K003.1	Reversed			
K003.2	Reversed			
K003.3	Reversed			
K003.4	Reversed			
K003.5	Reversed			
K003.6	Reversed			
K003.7	Reversed			
K004.0	Whether the spindle uses the gear control(I/O point)	No	Yes	
K004.1	If the manual reference point controls one axis	Many axes	1 axis	
K004.2	Reversed			
K004.3	Reversed			
K004.4	Reversed			

K004.5	Reversed			
K004.6	Reversed			
K004.7	Reversed			
K005.0	Whether the machine tool has external handwheel(MPG)	No	Yes	
K005.1	Whether the machine tool has external cycle Start function	No	Yes	
K005.2	Whether the system enters the debugging mode	No	Yes	
K005.3	Reversed			
K005.4	Reversed			
K005.5	Reversed			
K005.6	Reversed			
K005.7	Reversed			
K006.0	X axis limit switch selection	2 PCS	1 PCS	
K006.1	Y axis limit switch selection	2 PCS	1 PCS	
K006.2	Z axis limit switch selection	2 PCS	1 PCS	
K006.3	4TH axis limit switch selection	2 PCS	1 PCS	
K006.4	Reversed			
K006.5	Reversed			
K006.6	Reversed			
K006.7	Reversed			
K007.0	X axis limit alarm reverse			
K007.1	Y axis limit alarm reverse			
K007.2	Z axis limit alarm reverse			
K007.3	4TH axis limit alarm reverse			
K007.4	Reversed			
K007.5	Reversed			
K007.6	Reversed			
K007.7	Reversed			
K008.0	Whether the 4 TH axis is used	No	Yes	
K008.1	The tool clamping/releasing control selection	External button	Button on panel	
K008.2	Whether the tool clamping/releasing device is used or not?	Yes	No	
K008.3	Whether the automatic lubricating control is used or not?	Yes	No	
K008.4	Whether the spindle has the gear change device or not?			
K008.5	Whether spindle speed (speed mode)/position (position mode) check arrival is the normally closed or not?			
K008.6	Whether the check switch is closed or not (it is turned off in position mode) in the spindle speed mode?			
K008.7	Whether the spindle position/speed mode conversion checks the signal or not?			
K009.0	Whether the spindle position arrival signal checks the signal or not?			
K009.1	Reversed			

K009.2	Reversed			
K009.3	Reversed			
K009.4	Reversed			
K009.5	Reversed			
K009.6	Reversed			
K009.7	Reversed			
K010.0	The tool magazine rotation in-position mode selection	No reaction	Reaction	
K010.1	Whether the tool magazine has the zero switch	No	Yes	
K010.2	The tool magazine zero return contact selection	Normal open	Normal close	
K010.3	The tool magazine infeed tool contact selection	Normal open	Normal close	
K010.4	The tool magazine tool retraction contact selection	Normal open	Normal close	
K010.5	The tool counting switch contact selection	Normal open	Normal close	
K010.6	Whether the tool origin point setting is enabled	Disabled	Enabled	
K010.7	Whether the tool magazine enters the regulation mode	No	Yes	
K011.0	Whether the manual tool clamping/releasing prompts the tool number which corresponds to the spindle	Yes	No	
K011.1	Whether the manual operation returns the tool change position	No	Yes	
K011.2	Reversed			
K011.3	Reversed			
K011.4	Reversed			
K011.5	Reversed			
K011.6	Reversed			
K011.7	Reversed			
K015.0	Whether it is the operator panel B or not	No	Yes	

KAPA use notes:

1. When the system normally runs, K0000, K0001, K0002, K0003, K0004, K0005, K0006, K0007, K0052, K0107 must be 0, otherwise there may be the unexpected accident.
2. The modified K0010 is valid when the system is started again, when K0010=0(i.e. the tool magazine is not used)
3. When K0010=1(i.e. the tool magazine is enabled), K0082 setting is disabled.
4. When K0082=0(i.e. the tool clamping/releasing device is used), K0081 setting is disabled.

5. K006.0 setting:

When two travel limit switches on X axis have been installed (the positive limit switch connects with X0.0, the negative limit switch connects with X 0.1) , K0060 set to 0 is enabled, and K0070 setting is disabled.

When one travel limit switch on X axis is installed (connecting with X0.0) k0060 set to 1 is enabled,

When the system alarms or X axis moves in the negative direction to the limit, the system alarms for the positive direction, when the K0080 is modified, the alarm reverses, namely, the error alarm is regulated.

The settings of K0061 and K0071 on Y axis, K0062 and K0072 on Z axis, K0063 and K0073 on the 4TH axis are the same that of X axis.

6. K008.3=1: the lubricating ON/OFF time is controlled by the system, i.e. by regulating CTR101(lubricating OFF time: default: minute) and CTR102(lubricating ON time: default: second), when K008.3=0, the lubricating is not controlled by the system.
7. K0052=1, all alarm interlocks are released, and the system enters the debugging mode, which is used when the system is being tested, when the system run normally, the parameter is set to 0, otherwise, there may be the unexpected accident.
8. K0100, K0101, K0102, K0103, K0104, K0105, K0106, K0107, K0110, K0111.
9. K004.0 (When the spindle uses I/O control or not) =1: K008.4 (whether the spindle has the gear change device or not?) setting is disabled, i.e. the spindle has no gear change device.
10. K015.0=0: the user should use the operator panel of GSK218M; K015.0=1: use that of GSK990MA.

Table 4 PLC external alarm definition

PLC alarm number	A address	Alarm content
1200	A0000	Air pressure check abnormal
1201	A0001	Lubricating check abnormal
1202	A0002	Lubricating motor check abnormal
1203	A0003	Cooling motor check abnormal
1204	A0004	Chip removal motor check abnormal
1205	A0005	Pressure oil pump check abnormal
1206	A0006	Spindle cooling unit check abnormal
1207	A0007	Machine tool light check abnormal
1208	A0010	Machine tool control box
1209	A0011	Machine tool bed temperature check abnormal
1210	A0012	Machine tool vibration check abnormal
1211	A0013	Pressure oil temperature check abnormal
1212	A0014	Oil pressure low
1213	A0015	Machine not ready
1214	A0016	Reversed
1215	A0017	Reversed
1216	A0020	Do not rotate the spindle when the tool releases
1217	A0021	The tool cannot release when the spindle rotates
1218	A0022	Confirm the tool number when the tool magazine stops normally
1219	A0023	The spindle cannot rotate when the tool magazine is the infeed tool position
1220	A0024	Spindle tool clamping abnormal
1221	A0025	Spindle tool releasing check abnormal

1222	A0026	Spindle unit temperature check abnormal
1223	A0027	Spindle speed check abnormal
1224	A0030	Spindle motor enabling check abnormal
1225	A0031	Spindle orientation in-position check abnormal
1226	A0032	Spindle gear change abnormal
1227	A0033	The tool magazine cannot rotate when it is not in the origin point
1228	A0034	The tool magazine cannot execute the cycle start in the infeed tool position
1229	A0035	Set spindle tool number
1230	A0036	The tool change cannot be executed when the spindle tool releases
1231	A0037	The tool change cannot be executed when the tool magazine is in the retraction position
1232	A0040	The tool magazine rotation in-position check abnormal
1233	A0041	When the tool magazine rotates, the motor check is abnormal
1234	A0042	The program stops run when the tool magazine is in the infeed position
1235	A0043	The tool magazine move in-position check abnormal
1236	A0044	The tool magazine zero return check abnormal
1237	A0045	It needs to execute the zero return when the tool magazine position lose
1238	A0046	The infeed in-position check abnormal
1239	A0047	The retraction in-position check abnormal
1240	A0050	The tool magazine executes the zero return because of the abnormal
1241	A0051	The tool magazine infeed check abnormal
1242	A0052	The tool magazine retraction check abnormal
1243	A0053	The tool magazine zero position setting is valid
1244	A0054	Stop the abnormal tool change
1245	A0055	There is no T number or there is the repetitive tool number
1246	A0056	The infeed tool cannot be executed because it is not in tool change position
1247	A0057	The tool magazine does not execute the infeed tool

		because the spindle does not perform the positioning
1248	A0060	The tool magazine does not execute the retraction when the tool is released
1249	A0061	The spindle with the tool does not execute the infeed tool
1250	A0062	The spindle and the current tool number of tool magazine does not execute the infeed tool
1251	A0063	Please cut off
1252	A0064	The tool clamps
1253	A0065	Debug the tool magazine carefully
1254	A0066	The system does not execute The cycle start when the tool magazine is in the debugging mode
1255	A0067	The clamped tool cannot return to the origin position
1256	A0070	The clamped tool cannot return to the tool change position
1257	A0071	The spindle cannot return to the tool exchange position
1258	A0072	The tool magazine cannot return to the tool change position
1259	A0073	Reversed
1260	A0074	The cycle start cannot be executed when returning to the tool change position is executed manually
1261	A0075	The retraction cannot be executed in the origin position
1262	A0076	Exceed the safety position
1263	A0077	The cycle start cannot be executed in the debugging mode
1264	A0080	The spindle speed mode conversion is abnormal
1265	A0081	The spindle position speed mode conversion is abnormal

PLC alarm diagnosis:

Alarm information: 1200 the air pressure check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1201 the lubricant check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1202 the lubricating motor check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1203 the cooling motor check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1204 the chip removal check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1205 the pressure oil pump motor check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1206 the spindle cooling unit check is abnormal

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1207 the machine light check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 120 the machine control box temperature check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1209 the machine bed temperature check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1210 the machine vibration frequency check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1211 pressure oil temperature check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1212 the oil pressure is low.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1213 the machine is not ready.

Fault cause: defined by customer

[Troubleshooting:](#)

Alarm information: 1214 reserved

Fault cause:

Troubleshooting:

Alarm information: 1215 reversed

Fault cause:

Troubleshooting:

Alarm information: 1216 do not rotate the spindle when the tool releases.

Fault cause: execute the spindle rotating when the tool releases: in Manual mode, press the spindle CCW, CW, JOG, POSITION, or execute M03,M04, M19 in AUTO mode, the spindle will rotate.

Troubleshooting: in Manual mode, press "CLAMP/RELEASE", and the tool is clamped (i.e. Y2=0) to check whether the tool clamp check switch is 1, when it is 1, the rotating spindle does not appear alarm.

Alarm information: 1217 the tool does not release when the spindle rotates.

Fault cause: the tool release instruction is executed when the spindle rotates.

Troubleshooting: when the spindle stops, the tool release instruction is executed to avoid the alarm.

Alarm information: 1218 confirm the tool number again because the tool magazine abnormally stops.

Fault cause: M6 is executed when the tool magazine rotates, the alarm appears, or press "RESET", the alarm appears.

Troubleshooting: 1. the tool magazine executes the zero return.
2. set the spindle tool number and tool magazine number again.

Alarm information: 1219 the spindle cannot rotate when the tool magazine in the infeed position

Fault cause: the spindle rotation is executed when the tool magazine does not retract to the in-position.

Troubleshooting: execute the tool magazine returning to the retraction position (whether the tool magazine has returned to the retraction position by X5.2).

Alarm information: 1220 the clamped tool corresponding to the spindle is abnormal.

Fault cause: when the tool is clamped(i.e.Y0.2=0), the tool magazine clamp check switch (X2.6) is not closed during the time set by T010.

Troubleshooting: 1. check whether the tool magazine clamp check switch is normal.
2. check whether Y0.2 outputs.
3. regulate again T010 time.

Alarm information: 1221 the released tool corresponding to the spindle is abnormal.

Fault cause: when the tool is clamped(i.e.Y0.2=1), the tool magazine clamp check switch (X2.5) is not closed during the time set by T009.

Troubleshooting: 1. check whether the tool magazine release check switch is normal.
2. check whether Y0.2 outputs.
3. regulate again T009 time.

Alarm information: 1222 the spindle unit temperature check is abnormal

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1223 the spindle speed is abnormal

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1224 the spindle motor enabling check is abnormal.

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1224 the spindle motor enabling check is abnormal.

Fault cause: when the tool is clamped(i.e.Y2.1=1), the tool magazine clamp check switch (X2.5) is not closed during the time set by T013.

Troubleshooting: 1. the spindle driver or spindle encoder is normal.

2. check whether Y2.1 outputs.

3. regulate again T013 time.

Alarm information: 1226 the spindle gear change is abnormal

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1227 the tool magazine which is not in the origin point cannot rotate.

Fault cause: the tool magazine is not in the retraction position and Z axis is not in the origin point, or press "MAG. CCW" or "MAG. CW", the alarm appears.

Troubleshooting: the tool magazine returns the retraction position or Z axis returns to the origin point.

Alarm information: 1228 the tool magazine cannot execute the cycle start when it is in the infeed position

Fault cause: when the tool magazine is not in the retraction position, or press "CYCLE START", the alarm appears.

Troubleshooting: the tool magazine returns the retraction position

Alarm information: 1229 please set the spindle tool number

Fault cause: press "CLAMP/RELEASE" when the tool number is 0, which causes the alarm appears.

Troubleshooting: the alarm only prompts the tool cannot be installed on the spindle but KAPA0110 is modified to shield the alarm when the tool number is 0

Alarm information: 1230 the tool change cannot be executed when the spindle tool is released.

Fault cause: when the tool is released(Y0.2=1), M06 or M50 is executed.

Troubleshooting: ensure that the spindle is clamped(Y0.2=0).

Alarm information: 1231 the tool change cannot be executed when the tool magazine is not in the retraction position.

Fault cause: Execute M06 or M50 when the tool magazine is not in the retraction position.

Troubleshooting: ensure that the spindle is clamped

Alarm information: 1232 the tool magazine rotating in-position check is abnormal

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1233 the motor check is abnormal when the tool magazine rotates

Fault cause: defined by customer

Troubleshooting: no

Alarm information: 1234 the program stops the run when the tool magazine is in the infeed position.

Fault cause: when the program is running, the tool is not in the retraction position, which causes the alarm appears.

Troubleshooting: the program is executed when the tool magazine is in the retraction position.

Alarm information: 1235 the tool magazine moving in-position check is abnormal

Fault cause: reserved

Troubleshooting:

Alarm information: 1236 the tool magazine zero return check is abnormal

Fault cause: reserved

Troubleshooting:

Alarm information: 1237 the tool magazine needs to return to zero because its origin is lost.

Fault cause:

Troubleshooting:

Alarm information: 1238 the infeed in-position check is abnormal

Fault cause: Reversed

Troubleshooting: Reversed

Alarm information: 1239 the retraction in-position check is abnormal.

Fault cause: Reversed

Troubleshooting: Reversed

Alarm information: 1240 the tool magazine needs to return the zero again because it is abnormal.

Fault cause: 1. the tool magazine stops the rotation in the time set by T102, the system has checked that the tool magazine count switch(X5.3) abnormally creates the pulse signal.

2. when the tool magazine rotates, the system checks that the tool magazine count switch 0 or 1 exceeds the time set by T103.

Troubleshooting: 1. the tool magazine CCW or CW output (Y3.0 Y3.1) is abnormal.

2. the tool magazine count switch is abnormal.

3. set T102 T103 value again.

Alarm information: 1241 the tool magazine infeed check is abnormal

Fault cause: when the tool magazine executes the infeed(i.e. Y3.2=1), the tool magazine infeed check switch (X5.1) has no operation.

Troubleshooting: 1. check whether the tool magazine infeed check switch is normal.

Alarm information: 1242 the tool magazine retraction check is abnormal

Fault cause: the tool magazine executes the retraction in the time set by T105, the tool magazine infeed check switch (X5.2) has no operation.

Troubleshooting: 1. check whether the tool magazine infeed check switch is normal.
2. check whether Y3.3 outputs.
3. regulate again T105 time

Alarm information: 1243 the tool magazine zero setting is enabled.

Fault cause: when the tool magazine has no zero return switch(i.e. K0101=0), and K0106=1, the system alarms and prompts the tool magazine zero setting is enabled.

Troubleshooting: set K0106 to 0.

Alarm information: 1244 the tool change is stopped because of its abnormal run

Fault cause: when the tool magazine executes automatically the tool change, the tool change stops because of its abnormal run, which causes the system alarms and prompts there may be the disorder of tool magazine and the spindle tool number

Troubleshooting: press RESET" to clear the alarm.

Alarm information: 1245 there is T tool number or repeated tool number in the tool list.

Fault cause: there is no tool number specified by T code or there is the repeated tool number specified by T code in the tool list (D001-D099).

Troubleshooting: modify the value in the tool list.

Alarm information: 1246 the tool magazine cannot execute the tool change because it is not in the tool change position.

Fault cause: Z axis is not the tool change position, and the tool magazine infeed is executed.

Troubleshooting: execute G91G30Z0 to make Z axis return to the tool change position.

Alarm information: 1247 the tool magazine cannot execute the infeed because the spindle does not position.

Fault cause: the spindle does not position and the tool magazine infeed is executed.

Troubleshooting: position the spindle.

Alarm information: 1248 the tool magazine does not execute the retraction when the tool is released.

Fault cause: the retraction is executed when the spindle tool is released.

Troubleshooting: execute the retraction after the spindle tool is clamped.

Alarm information: 1249 the spindle with the tool cannot execute the infeed.

Fault cause: the infeed is executed when Z axis is in the origin and the spindle has the tool.(D245 is not 0)

Troubleshooting: dismount the tool on the spindle and set D245 to 0.

Alarm information: 1250 the infeed cannot be executed because the tool number on the spindle is not the same that of the current tool magazine.

Fault cause: Z axis is in the tool change position, and the infeed is executed when the tool number

on the spindle is not the same that of the current tool magazine.

Troubleshooting: rotate the tool magazine to ensure the tool number on the spindle is the same that of current tool magazine.

Alarm information: 1251 please turn off the power supply

Fault cause: the modified parameter is enabled after power-off.

Troubleshooting: start the system again.

Alarm information: 1252 Z axis cannot move because the tool is clamped.

Fault cause: when the tool is in the infeed position and the spindle tool is clamped, Z axis moves.

Troubleshooting: 1. the tool magazine is in the retraction position.

2. the spindle tool is released.

Alarm information: 1253 carefully operate the system because the tool magazine is in the debug mode.

Fault cause: When K0107 is set to 1, the system alarms, which prompts the tool magazine enters the debug mode, and which is not related to its other alarms and interlock signal, at this time, we should carefully operate the system, otherwise, there maybe damage the machinery.

Troubleshooting: press "RESET".

Alarm information: 1254 the system cannot execute the cycle start

Fault cause: when K0107 is set to 1, the "CYCLE START" is pressed in AUTO or MDI or DNC mode, which causes the system alarms.

Troubleshooting: set K0107 to 0.

Alarm information: 1255 the tool cannot return to the origin point because it is clamped.

Fault cause: Z axis is executed to return to the origin point when the tool magazine is in the infeed position and the spindle tool is clamped.

Troubleshooting: 1. the tool magazine is in the retraction position.

2. the spindle tool is released.

Alarm information: 1256 the tool cannot return the tool change position because it is clamped.

Fault cause: Z axis is executed to return to the tool change position when the tool magazine is in the infeed position and the spindle tool is clamped.

Troubleshooting: 1. the tool magazine is in the retraction position.

2. the spindle tool is released.

Alarm information: 1257 the spindle cannot return the tool change

Fault cause: Z axis is executed to return to the tool change position when the tool magazine is in the infeed position and the spindle is not positioned.

Troubleshooting: 1. the tool magazine is in the retraction position.

2. the spindle tool is released.

Alarm information: 1258 the tool magazine cannot return to the tool change position because it is abnormal.

Fault cause: reserved

Troubleshooting: no

Alarm information: 1259 reversed

Fault cause:

Troubleshooting:

Alarm information: 1260 the system cannot execute the cycle start because the manual tool change is executed.

Fault cause: when K0111 is set to 1(i.e. the manual tool change position return is enabled), the “CYCLE START” is pressed in AUTO or MDI or DNC mode, which causes the system alarms.

Troubleshooting: set K0111 to 0.

Alarm information: 1261 the tool cannot execute the retraction because it is not in the origin point.

Fault cause: the tool magazine retraction is executed when the tool magazine is in the infeed position and Z axis is not in the origin point.

Troubleshooting: the retraction is executed after Z axis returns to the origin point.

Alarm information: 1262 exceed the safety position.

Fault cause: Z axis exceeds the tool change position when the tool magazine is in the infeed position and Z axis moves.

Troubleshooting: move Z axis to the position between the tool change position and origin point.

Alarm information: 1263 the system cannot execute the cycle start when it is in the debug mode.

Fault cause: reserved

Troubleshooting: reserved

Alarm information: 1264 the spindle position mode conversion is abnormal

Fault cause: when M28 is executed, the system has not received the spindle position mode completion signal in the time set by T24.

Troubleshooting: regulate T24 setting time or ensure the spindle position mode completion signal outputs

Alarm information: 1265 the spindle speed mode conversion is abnormal

Fault cause: when M28 is executed, the system has not received the spindle speed mode completion signal in the time set by T28.

Troubleshooting: regulate T28 setting time or ensure the spindle position mode completion signal outputs

Note: when the alarm is for “User definition” and there is no the alarm in the ladder, the user should modify the ladder to increase it.

Table 5 TMR parameter definition

Address	Statement	Initial value (ms)	Setting value by customer (ms)
T0001	Delay timer for spindle CCW completion	500	
T0002	Delay timer for spindle CW completion	500	
T0003	Delay timer for spindle gear change completion	500	
T0004	Delay timer for spindle positioning completion	0	
T0005	Delay timer for auxiliary function(M.S.T) completion	0	
T0006	Timer for spindle gear change check	500	
T0007	Delay timer for spindle tool release completion	0	
T0008	Delay timer for spindle tool clamp completion	0	
T0009	Time setting for spindle tool release check	8000	
T0010	Time setting for spindle tool clamp check	8000	
T0011	Pulse signal time 1 in 1 second	500	
T0012	Pulse signal time 2 in 1 second	500	
T0013	Time setting for spindle positioning check time	8000	
T0014	Time setting for spindle CCW check	500	
T0015	Time setting for spindle CW check	500	
T0016	Time unit setting for lubricating	60000	
T0017	Time unit setting for lubricating	1000	
T0018	Time setting for spindle positioning delay check	2000	
T0019	Delay timer for spindle JOG	2000	
T0020	Delay timer for program restart	10	
T0021	Delay timer for spindle gear 1	10000	
T0022	Delay timer for spindle gear 2	10000	
T0023	Delay timer for spindle gear 3	10000	
T0024	Check time of spindle speed position mode conversion	10000	
T0025	Completion time of M29 execution (enabled without check signal)	4000	
T0026	Positioning completion time in spindle position mode(enabled without check signal)	1500	
T0027	Completion time of M28 execution(enabled without check signal)	2000	
T0028	Check time of spindle position speed mode conversion	10000	
T0100	Delay time 1 for turret tool magazine manually rotating	2000	
T0101	Delay time 2 for turret tool magazine manually rotating	2000	
T0102	Delay check time setting for turret tool magazine stopping	2000	
T0103	Delay check time setting for turret tool magazine rotating	3000	
T0104	Delay check time setting for tool magazine infeed	10000	
T0105	Delay check time setting for turret tool magazine retraction	10000	
T0106	Delay timer for turret tool magazine infeed completion	0	
T0107	Delay timer for turret tool magazine retraction	0	

	completion		
--	------------	--	--

Notes:

1. PLC pulse signal period is 1s, set T0011 and T0012 to 500.
2. T016 setting will change C101 unit. For example: C101 unit is 60000ms(i.e. 1m) when T0016 is set to 60000.
3. T017 setting will change C102 unit. For example: C102 unit is 1000ms(i.e. 1s) when T0017 is set to 10000.

Table 6 DATA parameter definition

Definition	Statement	Setting value by customer
D000	Spindle tool number display	Cannot set
D001	No.1 tool number	
D002	No.2 tool number	
⋮	⋮	
D098	No.98 tool number	
D099	No.99 tool number	
D100	Tool magazine capacity	
D241	T code tool number	Cannot set
D243	Current tool magazine number	Cannot set
D245	Spindle tool number	

Notes:

1. D100 setting value must be less than 100, and must be the same that of CTR100, otherwise, there may be the abnormal.
 For example: D100=16, the data table D001-D016 is enabled.
 D100=24, the data table D001-D024 is enabled.
2. D000 only displays the spindle tool number, the spindle tool number cannot be modified at the D000 but at the D245.
3. D241 value cannot be modified.
4. D240~D247 is used by the system and cannot be defined by the user.

Table 7 CTR parameter definition

Address	Statement	Initial value	Setting value by customer
C100	Tool magazine capacity setting	16	
C101	Automatic lubricating OFF time setting	30	
C102	Automatic lubricating ON time setting	30	

Notes:

1. CTR100 setting value must be less than 100 and must be the same that of D100, otherwise there may be the abnormal.
 For example: CTR100 =16, the total tool magazine number is 16.
 CTR100=24, the total tool magazine number is 24.
2. C101 unit is related to T0016.
 For example: T0016 is set to 60000, C101 unit is 1m, and C101 is set to 30, the lubricating OFF

time is 30ms(minutes).

3. C102 unit is related to T0017

For example: T0017 is set to 1000, C102 unit is 1s, and C102 is set to 10, the lubricating OFF time is 10s.

Table 8 M code definition

M code	F signal	Function	Remark
M00	F0317	Program pause	
M01	F0304	Selection stop	
M02	F0305	End of program	
M03	F0300	Spindle CCW	
M04	F0301	Spindle CW	
M05	F0302	Spindle stop	
M06	F0303	Automatic tool change	
M08	F0310	Cooling ON	
M09	F0311	Cooling OFF	
M10	F0312	A axis clamp	Reversed
M11	F0313	A axis release	Reversed
M16	F0260	Spindle release instruction	Reversed
M17	F0261	Spindle clamp instruction	Reversed
M18	F-001	Cancel the spindle exact stop	
M19	F0262	Spindle exact stop	
M21	F0263	Search tool instruction when retraction	
M22	F0264	Search tool instruction when startup the current tool	
M23	F0265	Tool magazine forward	
M24	F0266	Tool magazine backward	
M26	F***.*	Start chip removal lift conveyor	
M27	F***.*	Close chip removal lift conveyor	
M28	F0323	Rigid tapping instruction OFF	
M29	F0322	Rigid tapping instruction	
M30	F0280	End of program	
M32	F0314	Lubricating ON	
M33	F0315	Lubricating OFF	
M35	F***.*	Start helical chip removal conveyor	
M36	F***.*	Close helical chip removal conveyor	
M40	F***.*	X axis image	
M41	F***.*	Y axis image	
M42	F***.*	Z axis image	
M43	F***.*	Cancel image	
M44	F0267	Start spindle blow	
M45	F0270	Stop spindle blow	
M50	F0271	Start automatic tool change	
M51	F0272	End of automatic tool change	
M53	F0273	Judge whether the tool is correct after the tool change is executed	Reversed
M55	F0274	Judge whether the spindle has the tool	Reversed

Note:

1. "F***.*" and M instructions with "Reserved" in F signal table cannot be used.
2. M16, M17, M21, M22, M23 and M24 are enabled when the tool change is being executed, and they cannot run separately.

3. Usage and maintenance of GSK 218M CNC System matching with turret tool magazine

Tool magazine preparation and use

1. Tool magazine installation and related PLC parameter setting

Operation aim: ensure the ladder fit to the allocation of tool magazine

A. requirements of the ladder matched with the turret tool magazine to the machine tool:

1. The machine tool has the spindle tool automatically clamping/releasing device which has the normally open in-position check switch.
2. The spindle has the positioning function and its positioning angle can be regulated.
3. The tool magazine capacity must be less than 100.
4. The tool magazine can execute CCW/CW.
5. The tool magazine has the count switch, forward in-position check switch, and retraction in-position check switch.
6. The tool magazine has zero return switch(selection).

B. Wire connection related to tool magazine

1) Input .

Address	Statement	Remark
X0024	External clamp/release control	Selection
X0025	Release check	Normally open contact
X0026	Clamp check	Normally open contact
X0050	Spindle orientation in-position	Normally-closed contact
X0051	Tool magazine forward in-position	Normal open or normal close
X0052	Tool magazine backward in-position	Normal open or normal close
X0053	Tool magazine CCW/CW in-position	Normal open or normal close
X0054	Tool magazine zero return in-position	Selection

2) . Output:

Address	Statement	Remark
Y0002	Tool release/clamp	
Y0020	Spindle enabling	
Y0021	Spindle orientation	
Y0030	Tool magazine CCW	
Y0031	Tool magazine CW	
Y0032	Tool magazine forward	
Y0033	Tool magazine backward	

C. Tool magazine switch type and rotation in-position mode selection

- Tool magazine no zero return switch set K0101 to 0
- Tool magazine zero return switch set K101 to 1
- Tool magazine zero return switch is normal open set K0102 to 0
- Tool magazine zero return switch is normal close set K0102 to 1
- Tool magazine infeed switch is normal open set K0103 to 0
- Tool magazine infeed switch is normal close set K0103 to 1
- Tool magazine retraction switch is normal open set K0104 to 0

Tool magazine retraction switch is normal close	set K0104 to 1
Tool magazine count switch is normal open	set K0105 to 0
Tool magazine count switch is close open	set K0105 to 1
Tool magazine rotation in-position A mode	set K0100 to 0
Tool magazine rotation in-position B mode	set K0100 to 1

Note:

1. K0102 setting is disabled when K0101 is set to 0.
2. The tool magazine rotation in-position A mode: when the tool magazine rotates the normal stop position, the tool magazine count switch has not responded the block(See Fig. A).
3. The tool magazine rotation in-position B mode: when the tool magazine rotates the normal stop position, the tool magazine count switch has responded the block(See Fig. B).




Fig. A




Fig. B

K0101=0 K0102=0 K0103=0 K0104=0 K0105=0 K0100=0

For example: the tool magazine has no zero return switch, all check switches are normal open and the rotation in-position is A mode, the parameter setting is as follows:

K0101=0 K0102=0 K0103=0 K0104=0 K0105=0 K0100=0

D. tool magazine capacity setting

Input tool magazine capacity in DATA100 and CTR100

Notes:

1. The tool magazine capacity is defined that total tool magazine numbers in the tool magazine.
2. DATA100 and CTR100 setting values must be less than 100.

E. Tool number setting:

Data table D001-D099 separately correspond to the tool magazine number 1-99, and the setting values in the data table D001-D009 separately corresponds to the tool number in the tool magazine number 1-99. D245 is the spindle tool number.

Notes:

1. In D001-D099, there is no the same tool number(except for 0), otherwise the system alarms when the tool change is executed.
2. The tool number setting range meets the requirements set by the parameter 0206, otherwise the system alarm when the T instruction is executed.

For example: when the tool magazine capacity is 16:

When the tool magazine is set orderly to 1-16 in D1-D16, and T8M6 is executed, the tool change is executed after No. 8 tool magazine number will rotate to the tool change position.

When the tool magazine is set orderly to 10, 20, 30...160 in D1-D16, and T80M6 is executed, the tool change is executed after No. 8 tool magazine number will

rotate to the tool change position

When D1 and D2 are set to 8, and T8M6 is executed, the system alarms.

F. Time parameter setting related to the tool magazine:

Address	Statement	Setting range	Initial value (ms)
T0004	Delay timer for spindle positioning	More than or less than 0	0
T0007	Delay timer for spindle tool releasing completion	More than or equal to 0	0
T0008	Delay timer for spindle tool clamping completion	More than or equal to 0	0
T0009	Time setting for spindle tool releasing check	More than releasing tool time	8000
T0010	Time setting for spindle tool clamping check	More than clamping tool time	8000
T0013	Time setting for spindle positioning check	More than positioning time	8000
T0018	Time setting for spindle positioning delay check	Related to the positioning width	2000
T0100	Delay time 1 for turret tool magazine manually rotating	More than rotating one tool selection	2000
T0101	Delay time 2 for turret tool magazine manually rotating	More than rotating one tool selection	2000
T0102	Delay check time for turret tool magazine stopping	More than rotating one tool selection	2000
T0103	Delay check time for tool magazine rotating	More than rotating one tool selection	3000
T0104	Delay check time for turret tool magazine infeed	More than infeed time	10000
T0105	Delay check time for turret tool magazine retracting	More than retraction time	10000
T0106	Delay timer for turret tool magazine infeed completion	More than or equal to 0	0
T0107	Delay timer for turret tool magazine retraction completion	More than or equal to 0	0

Notes:

1. The above parameter(TMR) is related to the tool magazine type, the tool magazine speed and other performances. Please refer to the tool magazine performance to properly set the parameter.
2. when the above parameter (TMR) setting is not proper, the system alarms to cause that the tool change is not executed normally.

The ladder match with the tool magazine after the above A-F steps are operated, but the tool magazine cannot normally run, the tool magazine executes the CCW, CW, infeed and retraction in Manual mode to check whether each operation of tool magazine is normal through the following No. 2 setting and operation(i.e. 2. Tool magazine manual and zero return operation).

1. Tool magazine manual and zero return operation

Operation aim: check whether the each operation of tool magazine is normal.

The detailed operation is as follows:

A. the tool magazine is enabled.

1. Because the tool magazine is turret, and the following bit parameter must be set.
Bit parameter 53.0=1 bit parameter 53.1=0 bit parameter 53.2=0 bit parameter 53.3=0

B. Confirming the rotation direction of tool magazine

In Manual mode, press “MAG. CCW” and the tool magazine rotates according to the prescribed positive direction of machine tool, press “MAG. CW” and the tool magazine rotates according to the prescribed negative direction of machine tool, otherwise, the tool magazine count will be disorder to cause that the tool change is executed wrongly, which can be resolved by regulating the phase sequence of the motor.

C. Tool magazine zero return:

Tool magazine zero return operation is divided into zero return switch and no zero return switch.

1. The tool magazine has the zero return switch: press “MAG. ZERO” in “ZERO RETURN” mode, and the zero return is completed when the indicator is light(the light flashing indicates the tool magazine is executing the zero return.)
2. The tool magazine has no the zero return switch
 - a. In Manual mode, press “CCW” or “CW” to make the No. tool magazine number rotate to the tool change position.
 - b. set K0106 to 1 in MDI mode.
 - c. press “MAG. ZERO” in zero return mode until its indicator is light.
3. Spindle positioning angle and tool change coordinate position regulation
 - a. the spindle positioning angle regulation refers to the explanation of spindle driver.
 - b. Z axis has two positions including origin point and tool change position when the tool magazine executes the tool change.

The parameter 0047 must be set to 0 when the tool magazine returns to the origin point, otherwise, there maybe the accident to damage the machine.

We can correctly execute the tool change through the above operations. Operating T and M instructions are as follows:

- TxxM6; it has the same execution effect that of Txx;M6;
- T0M6; the spindle tool retracts to the tool magazine.

Warning: the tool must not be installed on the spindle when the spindle tool number is 0, otherwise, there maybe the accident when the tool change is executed to damage the machine.

4. Macro program statement of GSK218M CNC System matching with turret tool magazine

Macro program statement of GSK218M CNC System matching with turret tool magazine

- O91001; (program name)
- G65 H81 P50 Q#1003 R1; (M.S.T and machine are locked, execute N50, end of program)
- G69 G50 G15 G80; (cancel the related modes)
- M50; (start the tool change and check its conditions of tool change, if not, the system alarms.)
- G65 H81 P40 Q#1001 R1; (spindle tool number=T tool number: not execute the tool change but N40, end of program)
- G65 H81 P20 Q#1000 R1; (spindle tool number=0: the spindle has no tool, execute N20 instead of the retraction tool instruction)
- M19 G91 G30 Z0; (spindle positioning, return to the coordinate position of tool change)
- M21; (retraction-> tool magazine rotating tool magazine forward spindle releasing)
- N20 M19 G91 G28 Z0; (return to machine’s origin point)
- G65 H81 P30 Q#1002 R1; (T code tool number=0: not execute the tool search but N30)
- M22; (tool search ->tool magazine rotating tool magazine forward spindle releasing tool)
- G91 G30 Z0; (return to coordinate point of tool change)

N30 M17;	(spindle clamping tool)
M24;	(tool magazine retraction)
N40 M51;	(end of tool change)
N50 M99;	(end of program)

广州数控设备有限公司
GSK CNC EQUIPMENT CO., LTD.

Add: No.52, 1st . Street, Luochong North Road, Luochongwei, Guangzhou, 510165, China

Website: <http://www.gsk.com.cn>

E-mail: gsk@gsk.com.cn

Tel: 86-20-81796410/81797922

Fax: 86-20-81993683

All specifications and designs are subject to change without notice Nov. 2007/Edition 3

Nov. 2007/Printing 3